




## Communications Network

### Special Tool(s)

	Fluke 77-IV Digital Multimeter FLU77-4 or equivalent
	Vehicle Communication Module (VCM) and Integrated Diagnostic System (IDS) software with appropriate hardware, or equivalent scan tool
	Flex Probe Kit NUD105-R025D or equivalent

### Principles of Operation


Both High Speed Controller Area Network (HS-CAN) and Medium Speed Controller Area Network (MS-CAN) use an unshielded twisted pair cable of data (+) and data (-) circuits. The HS-CAN operates at a maximum data transfer speed of 500 Kbps and designed for real-time information transfer and control. The MS-CAN operates at a maximum data transfer speed of 125 Kbps for bus messages and is designed for general information transfer.

### Controller Area Network (CAN) Fault Tolerance

**NOTE:** The oscilloscope traces below are from the Integrated Diagnostic System (IDS) oscilloscope taken using the IDS pre-configured CAN settings. The traces are for both data (+) and data (-) taken simultaneously (2-channel) at a sample rate of 1 mega-sample per second (1MS/s) or greater.

Traces below are viewed at 500mV per division (vertical axis) and 20 microseconds (20µs) per division (horizontal axis). Readings taken with a different oscilloscope vary from those shown. Compare any suspect readings to a known good vehicle.


### Normal CAN Operation



The data (+) and data (-) circuits are each regulated to approximately 2.5 volts during neutral or rested network traffic. As messages are sent on the data (+) circuit, voltage is increased by approximately 1.0 volt. Inversely, the data (-) circuit is reduced by approximately 1.0 volt when a message is sent.

Successful communication of a message can usually be identified by the slight spike at the end of a message transmission. Any signals that are significantly different than the normal CAN waveform may cause network DTCs (U-codes) to set or may cause a complete network outage.

**CAN Circuits Shorted Together**




In the event the data (+) and data (-) circuits become shorted together, the signal stays at base voltage (2.5V) continuously and all communication capabilities are lost.

**CAN (+) Circuit Shorted To Ground**




In the event the data (+) circuit becomes shorted to ground, both the data (+) and data (-) circuits are pulled low (0V) and all communication capabilities are lost.

**CAN (-) Circuit Shorted To Ground**




In the event the data (-) circuit becomes shorted to ground, the data (-) circuit is pulled low (0V) and the data (+) circuit reaches near-normal peak voltage (3.0V) during communication but falls to 0V instead of normal base voltage (2.5V). Communication may continue but at a degraded level.

**CAN (+) Circuit Shorted To Battery Voltage**




In the event the data (+) circuit becomes shorted to battery voltage, the data (+) circuit is pulled high (12V) and the data (-) circuit falls to abnormally high voltage (above 5V) during communication and reaches battery voltage (12V) for peak voltage. Communication may continue but at a degraded level.

**CAN (-) Circuit Shorted To Battery Voltage**



In the event the data (-) circuit becomes shorted to battery voltage, both the data (+) and data (-) circuits are pulled high (12V) and all communication capabilities are lost.

**CAN Circuit Signal Corruption**



Rhythmic oscillations, inductive spikes or random interference can disrupt the network communications. The corruption signal source may be outside electrical interference such as motors or solenoids or internal interference generated from a module on the network. In some cases, an open in either the data (+) or data (-) circuit to a network module may cause the module to emit interference on the one circuit which is still connected. The trace shown is an example of a "sawtooth" pattern transmitted from a module with one open network circuit.

Other corruptions may be present when a module is intermittently powered up and down. The module on power up may initiate communication out of sync with other modules on the network causing momentary communication outages.

**Controller Area Network (CAN) Multiplex Messages**

Modules on the CAN utilize simultaneous communication of two or more messages on the same network circuits. The following chart summarizes the messages sent and received on the network.

**CAN Module Communication Message Chart**

**NOTE:** This chart describes the specific High Speed Controller Area Network (HS-CAN) and Medium Speed Controller Area Network (MS-CAN) messages broadcast by each module, and the module(s) that receive the message.

Broadcast Message	Originating Module	Network Type	Receiving Module(s)
A/C clutch engagement request	HVAC module	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
A/C clutch engagement request (gateway)	<u>IPC</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• PCM</li> </ul>
A/C clutch engagement status	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
A/C clutch engagement status (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• HVAC module</li> </ul>
A/C recirculation mode request	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
A/C recirculation mode request (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• HVAC module</li> </ul>
ABS event in progress	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• PCM</li> <li>• <u>RCM</u></li> </ul>
ABS Roll Stability Control (RSC®) chime malfunction status	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
ABS warning indicator request	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> <li>• <u>RCM</u></li> </ul>
Accelerator pedal position	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> </ul>
Accelerometer and yaw sensor data	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> <li>• <u>PSCM</u></li> </ul>
Accelerometer and yaw sensor data (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>GPSM</u></li> </ul>
Accessory delay status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>BCM-B</u></li> <li>• <u>FCIM</u></li> <li>• <u>FDIM</u></li> </ul>

Broadcast Message	Originating Module	Network Type	Receiving Module(s)
Airbag deployment eCall confirmation	<u>APIM</u>	<u>HS-CAN</u>	• <u>RCM</u>
Airbag deployment eCall notification	<u>RCM</u>	<u>HS-CAN</u>	• <u>APIM</u>
Airbag deployment event data record	<u>PCM</u>	<u>HS-CAN</u>	• <u>RCM</u>
Airbag deployment status	<u>RCM</u>	<u>HS-CAN</u>	• <u>IPC</u> • <u>OCSM</u> • <u>PCM</u>
Airbag deployment status (gateway)	<u>IPC</u>	<u>MS-CAN</u>	• <u>SJB</u>
Airbag warning indicator request	<u>RCM</u>	<u>HS-CAN</u>	• <u>IPC</u>
Airbag warning indicator status	<u>IPC</u>	<u>HS-CAN</u>	• <u>RCM</u>
Ambient lighting color	<u>IPC</u>	<u>MS-CAN</u>	• <u>BCM-B</u>
Ambient lighting dimming level	<u>IPC</u>	<u>MS-CAN</u>	• <u>BCM-B</u>
Ambient lighting status	<u>BCM-B</u>	<u>MS-CAN</u>	• <u>IPC</u>
Ambient temperature, inferred	<u>PCM</u>	<u>HS-CAN</u>	• <u>ABS module</u> • <u>IPC</u>
Autolamp delay command	<u>IPC</u>	<u>MS-CAN</u>	• <u>SJB</u>
Autolamp delay status	<u>SJB</u>	<u>MS-CAN</u>	• <u>IPC</u>
Autolock command	<u>IPC</u>	<u>MS-CAN</u>	• <u>SJB</u>
Autolock status	<u>SJB</u>	<u>MS-CAN</u>	• <u>IPC</u>
Auto-unlock command	<u>IPC</u>	<u>MS-CAN</u>	• <u>SJB</u>
Auto-unlock status	<u>SJB</u>	<u>MS-CAN</u>	• <u>IPC</u>
Average fuel economy data	<u>IPC</u>	<u>MS-CAN</u>	• <u>ACM</u>

Broadcast Message	Originating Module	Network Type	Receiving Module(s)
Average fuel economy reset request (navigation)	<u>ACM</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Axle ratio	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> </ul>
Barometric pressure	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> </ul>
Barometric pressure (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>SJB</u></li> </ul>
Belt-Minder® warning status	<u>RCM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Belt-Minder® programming request	<u>RCM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Brake (red) warning indicator request	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> <li>• <u>RCM</u></li> </ul>
Brake fluid level low	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Brake fluid level low (gateway)	<u>IPC</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> </ul>
Brake lamp switch status	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> </ul>
Charging system status	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Charging system warning indicator request	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> <li>• <u>PSCM</u></li> </ul>
Compass display data	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>FDIM</u></li> </ul>
Compass zone and calibration status	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>FDIM</u></li> </ul>
Convertible top position status	<u>BCM-B</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• HVAC module</li> </ul>
Decklid ajar status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Door ajar status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>

Broadcast Message	Originating Module	Network Type	Receiving Module(s)
Door lock command	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Door lock command source	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Engine coolant temperature	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> </ul>
Engine coolant temperature (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• HVAC module</li> </ul>
Engine fail-safe cooling mode status	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Engine fail-safe Electronic Throttle Control (ETC) warning indicator request	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Engine Malfunction Indicator Lamp (MIL) request	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Engine off timer	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> </ul>
Engine off timer (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• HVAC module</li> </ul>
Engine RPM	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> <li>• <u>PSCM</u></li> </ul>
Engine RPM (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>APIM</u></li> <li>• HVAC module</li> </ul>
Engine torque data	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>APIM</u></li> </ul>
Engine torque reduction request	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• PCM</li> </ul>
Engine turbocharger boost	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Engine type	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> </ul>
English/metric display (navigation)	<u>ACM</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
English/metric mode	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> </ul>



Broadcast Message	Originating Module	Network Type	Receiving Module(s)
			<ul style="list-style-type: none"> <li>HVAC module</li> </ul>
Front Controls Interface Module (FCIM) button press data	<u>FCIM</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li><u>ACM</u></li> <li><u>APIM</u></li> <li><u>IPC</u></li> </ul>
Fuel cap off indicator request	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li><u>IPC</u></li> </ul>
Fuel flow data	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li><u>APIM</u></li> <li><u>IPC</u></li> </ul>
Fuel level (instant)	<u>IPC</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>PCM</li> </ul>
Fuel level status	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li><u>ACM</u></li> </ul>
Fuel level status	<u>IPC</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li><u>APIM</u></li> </ul>
Global Positioning System (GPS) data	Global Positioning System Module (GPSM)	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li><u>APIM</u></li> </ul>
Headlamp high beam indicator request	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li><u>IPC</u></li> </ul>
Headlamp low beam status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li><u>IPC</u></li> </ul>
Headlamps on warning chime command	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li><u>IPC</u></li> </ul>
Hood ajar status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li><u>IPC</u></li> </ul>
HVAC button status	<u>FCIM</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>HVAC module</li> </ul>
HVAC button status, navigation Audio Front Control Module (ACM)	<u>ACM</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>HVAC module</li> </ul>
HVAC indicator status	HVAC module	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li><u>ACM</u></li> <li><u>FCIM</u></li> </ul>
HVAC module display data	HVAC module	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li><u>ACM</u></li> <li><u>FDIM</u></li> </ul>
HVAC voice request	<u>ACM</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>HVAC module</li> </ul>

Broadcast Message	Originating Module	Network Type	Receiving Module(s)
Ignition switch position	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>APIM</u></li> <li>• <u>BCM-B</u></li> <li>• <u>FCIM</u></li> <li>• <u>FDIM</u></li> <li>• <u>GPSM</u></li> <li>• HVAC module</li> <li>• <u>IPC</u></li> </ul>
Ignition switch position (gateway)	<u>IPC</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• PCM</li> </ul>
Integrated Keyhead Transmitter (IKT) programming request	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>SJB</u></li> </ul>
<u>IKT</u> programming status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Illuminated exit status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Instrument illumination level	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>BCM-B</u></li> <li>• <u>FCIM</u></li> <li>• <u>FDIM</u></li> <li>• HVAC module</li> <li>• <u>IPC</u></li> </ul>
Interior courtesy lamp battery saver status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Interior courtesy lamp delay status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Interior courtesy lamp door status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Interior courtesy lamp illuminated entry status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Key-in-ignition status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>APIM</u></li> </ul>
Key-in-ignition warning chime command	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Low odometer status	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• HVAC module</li> <li>• <u>SJB</u></li> </ul>
Manual transmission clutch top travel switch status	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> </ul>

Broadcast Message	Originating Module	Network Type	Receiving Module(s)
Manual transmission upshift indicator request	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Navigation rolling wheel count	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Navigation rolling wheel count (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>GPSM</u></li> </ul>
Occupant Classification System (OCS) calibration data	<u>OCSM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>RCM</u></li> </ul>
<u>OCS</u> fault status	<u>OCSM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>RCM</u></li> </ul>
<u>OCS</u> sensor data	<u>OCSM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>RCM</u></li> </ul>
<u>OCS</u> serial number	<u>OCSM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>RCM</u></li> </ul>
Odometer rolling count	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>APIM</u></li> <li>• <u>IPC</u></li> </ul>
Park brake chime request	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Park brake status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>IPC</u></li> </ul>
Park brake status (gateway)	<u>IPC</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• PCM</li> </ul>
Park lamp status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>FCIM</u></li> <li>• <u>FDIM</u></li> <li>• HVAC module</li> <li>• <u>IPC</u></li> </ul>
Passenger seat belt buckle status	<u>RCM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>OCSM</u></li> </ul>
Passive Anti-Theft System (PATS) security data	<u>IPC</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• PCM</li> </ul>
<u>PATS</u> security data	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
<u>PATS</u> security data	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>SJB</u></li> </ul>
Perimeter alarm chime request	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>

Broadcast Message	Originating Module	Network Type	Receiving Module(s)
Perimeter alarm courtesy lamp status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Perimeter alarm event trigger source	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Perimeter alarm inclination armed status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Perimeter alarm inclination sensor status	<u>BCM-B</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>SJB</u></li> </ul>
Perimeter alarm inclination/intrusion sensor fault	<u>BCM-B</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Perimeter alarm intrusion armed status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Perimeter alarm intrusion sensor status	<u>BCM-B</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>SJB</u></li> </ul>
<u>PSCM</u> fault status	<u>PSCM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Restraints Control Module (RCM) serial number	<u>RCM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>OCSM</u></li> </ul>
Remote start status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>APIM</u></li> </ul>
Seat belt indicator request	<u>RCM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Seat belt warning chime request	<u>RCM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Seat belt warning chime status	<u>IPC</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>RCM</u></li> </ul>
Slow vehicle speed puddle lamp status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Speed control indicator status	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> </ul>
Stability control event in progress	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• PCM</li> <li>• <u>RCM</u></li> </ul>
Stability control indicator status	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> <li>• <u>RCM</u></li> </ul>
Stability control message center text	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>

Broadcast Message	Originating Module	Network Type	Receiving Module(s)
Steering wheel angle	<u>PSCM</u>	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS Module</li> <li>• <u>RCM</u></li> </ul>
Steering wheel angle offset	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>PSCM</u></li> </ul>
Tire revolutions per mile	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Tire size information	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> <li>• PCM</li> </ul>
Tire size information (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>GPSPM</u></li> </ul>
Tire Pressure Monitoring System (TPMS) indicator command	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>APIM</u></li> <li>• <u>IPC</u></li> </ul>
<u>TPMS</u> sensor status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>APIM</u></li> </ul>
<u>TPMS</u> system status	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>APIM</u></li> <li>• <u>IPC</u></li> </ul>
<u>TPMS</u> tire pressure data	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>APIM</u></li> </ul>
Traction control disable switch status	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Traction control event in progress	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• PCM</li> <li>• <u>RCM</u></li> </ul>
Transmission malfunction indicator request	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Transmission overdrive cancel status	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Transmission selector (PRNDL) status	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> <li>• <u>RCM</u></li> </ul>
Transmission selector (PRNDL) status (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>BCM-B</u></li> <li>• <u>GPSPM</u></li> <li>• <u>SJB</u></li> </ul>
Transmission shift in progress	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS</li> </ul>

Broadcast Message	Originating Module	Network Type	Receiving Module(s)
Transmission type	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> </ul>
Turn signal command	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>IPC</u></li> </ul>
Turn signal outage, LR	<u>BCM-B</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>SJB</u></li> </ul>
Turn signal outage, RR	<u>BCM-B</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>SJB</u></li> </ul>
Turn signal sequential command	<u>SJB</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>BCM-B</u></li> </ul>
Vehicle speed	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>IPC</u></li> <li>• <u>OCSM</u></li> </ul>
Vehicle speed (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• <u>APIM</u></li> <li>• <u>BCM-B</u></li> <li>• <u>GPSM</u></li> <li>• HVAC module</li> <li>• <u>SJB</u></li> </ul>
Vehicle type information	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>APIM</u></li> <li>• <u>IPC</u></li> </ul>
Vehicle type information (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>ACM</u></li> <li>• HVAC module</li> </ul>
Vehicle Identification Number (VIN) information	PCM	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• ABS module</li> <li>• <u>APIM</u></li> <li>• <u>IPC</u></li> <li>• <u>OCSM</u></li> <li>• <u>RCM</u></li> </ul>
<u>VIN</u> information (gateway)	<u>IPC</u>	<u>MS-CAN</u>	<ul style="list-style-type: none"> <li>• <u>APIM</u></li> <li>• <u>ACM</u></li> <li>• HVAC module</li> <li>• <u>SJB</u></li> </ul>
Wheel speed data	ABS module	<u>HS-CAN</u>	<ul style="list-style-type: none"> <li>• PCM</li> </ul>

1. Verify the customer concern.
2. Visually inspect for obvious signs of electrical damage.
  - If an obvious cause for an observed or reported concern is found, correct the cause (if possible) before proceeding to the next step.

## Visual Inspection Chart

### Electrical

- Battery Junction Box (BJB) fuse(s):
  - 18 (20A) (no communication with the Body Control Module B (BCM-B) )
  - 23 (10A) (no communication with the PCM)
  - 45 (5A) (no communication with the PCM and the Power Steering Control Module (PSCM) )
  - 47 (15A) (no communication with the PCM)
- Smart Junction Box (SJB) fuse(s):
  - 3 (15A) (no communication with the Accessory Protocol Interface Module (APIM) )
  - 5 (10A) (no communication with the SJB )
  - 14 (10A) (no communication with the Front Controls Interface Module (FCIM) , Front Display Interface Module (FDIM) (without navigation), Global Positioning System Module (GPSM) )
  - 15 (10A) (no communication with the HVAC module)
  - 20 (15A) (no power to the scan tool)
  - 26 (10A) (no communication with the Instrument Panel Cluster (IPC) )
  - 31 (10A) (no communication with the Restraints Control Module (RCM) )
  - 32 (10A) (no communication with the Parking Aid Module (PAM) )
  - 34 (5A) (no communication with the ABS module)
  - 35 (10A) (no communication with the BCM-B )
  - 36 (5A) (no communication with the IPC )
  - 39 (20A) (no communication with the Audio Front Control Module (ACM) )
  - 46 (7.5A) (no communication with the Occupant Classification System Module (OCSM) )
- Data Link Connector (DLC)
- Wiring harness
- Wiring, terminals or connectors

3. Connect the scan tool to the DLC .

- **NOTE:** *Make sure to use the latest scan tool software release.*

**NOTE:** *The Vehicle Communication Module (VCM) LED prove-out confirms power and ground from the DLC are provided to the VCM .*

If the Integrated Diagnostic System (IDS) does not communicate with the VCM :

- Check the VCM connection to the vehicle.
- Check the scan tool connection to the VCM .
- [GO to Pinpoint Test R](#), to diagnose No Power To The Scan Tool.

4. Establish a scan tool session.

- **NOTE:** *The scan tool first attempts to communicate with the PCM, after establishing communication with the PCM, the scan tool then attempts to communicate with all other modules on the vehicle.*

If an IDS session cannot be established with the vehicle, (IDS may state "No communication can be established with the PCM"):

- Choose "NO" when the scan tool prompts whether or not to retry communication.
- Enter either a PCM part number, tear tag or calibration number to identify the vehicle and start a session (the PCM part number and 4-character tear tag are printed on the PCM label).
- [GO to Pinpoint Test A](#), to diagnose The PCM Does Not Respond To The Scan Tool.

5. Carry out the network test.

- If the network test passes, retrieve and record the continuous memory DTCs and proceed to Step 6.
- If the network test fails, GO to [Symptom Chart](#) to diagnose the failed communication network.
- If a module fails to communicate during the network test, GO to [Symptom Chart](#).

6. Retrieve and review the DTCs.

- If the DTCs retrieved are related to the concern, go to DTC Charts. Follow the non-network DTC diagnostics (B-codes, C-codes, P-codes) prior to the network DTC diagnostics (U-codes). For all other DTCs, refer to the Diagnostic Trouble Code (DTC) Chart in [Section 419-10](#).
- If no DTCs related to the concern are retrieved, GO to [Symptom Chart](#).

**DTC Charts**

**NOTE:** Network DTCs (U-codes) are often a result of intermittent concerns such as faulty wiring or low battery voltage occurrences. Additionally, vehicle service procedures such as module reprogramming will often set network DTCs. Replacing a module to resolve a network DTC is unlikely to resolve the concern. To prevent repeat network DTC concerns, inspect all network wiring, especially connectors. Test the vehicle battery, refer to [Section 414-01](#).

**Communication Network DTC Chart**

**NOTE:** DTC U1900 will set in a module that is reporting a communication fault from another module on the data bus. The module that reports the fault is not the problem module.

DTC	Description	Action
U0028:08	Vehicle Communication Bus A: Bus Signal / Message Failure	The module could not communicate on the network at a point in time. The fault is not currently present (the module had to communicate with the scan tool to report this DTC). CLEAR the DTC. REPEAT the Network Test with the scan tool. VERIFY the integrity of the connectors and wiring Refer to Wiring Diagrams Cell <a href="#">14</a> , Module Communications Network for schematic and connector information.
U0028:88	Vehicle Communication Bus A: Bus off	The module could not communicate on the network at a point in time. The fault is not currently present (the module had to communicate with the scan tool to report this DTC). CLEAR the DTC. REPEAT the Network Test with the scan tool. VERIFY the integrity of the connectors and wiring Refer to Wiring Diagrams Cell <a href="#">14</a> , Module Communications Network for schematic and connector information.
U0073	Control Module Communication Bus Off	The module could not communicate on the network at a point in time. The fault is not currently present (the module had to communicate with the scan tool to report this DTC). CLEAR the DTC. REPEAT the Network Test with the scan tool. VERIFY the integrity of the connectors and wiring Refer to Wiring Diagrams Cell <a href="#">14</a> , Module Communications Network for schematic and connector information.
U2472	Unexpected Ignition State	This DTC is only set when an on-demand self-test is run with the test entry conditions not correct. CLEAR the DTC. REPEAT the self-test with the ignition in the ON position and the vehicle stationary.
U2473	Unexpected Vehicle Speed	This DTC is only set when an on-demand self-test is run with the test entry conditions not correct. CLEAR the DTC. REPEAT the self-test with the ignition in the ON position and the vehicle stationary.
-	All network DTCs referenced to 418-00 from another section	GO to <a href="#">Symptom Chart</a> .
-	All other DTCs	REFER to <a href="#">Section 419-10</a> .

**Symptom Chart**

**Symptom Chart**

Condition	Possible Causes	Action
<ul style="list-style-type: none"> <li>• The vehicle will not start with the scan tool connected to the <u>DLC</u> and/or multiple malfunction indicators are on only while the scan tool is connected to the <u>DLC</u> .</li> </ul>	<ul style="list-style-type: none"> <li>• <u>DLC</u> ground</li> <li>• Wiring, terminals or connectors</li> <li>• Scan tool</li> </ul>	<ul style="list-style-type: none"> <li>• <a href="#">GO to Pinpoint Test R.</a></li> </ul>
<ul style="list-style-type: none"> <li>• The PCM does not respond to the scan tool</li> </ul>	<ul style="list-style-type: none"> <li>• Wiring, terminals or connectors</li> <li>• PCM</li> </ul>	<ul style="list-style-type: none"> <li>• REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual, Section 5, pinpoint test QA before proceeding to Pinpoint Test A. If</li> </ul>



		pinpoint test QA has been completed, <a href="#">GO to Pinpoint Test A.</a>
• The ABS module does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• ABS module</li> </ul>	• <a href="#">GO to Pinpoint Test B.</a>
• The Instrument Panel Cluster (IPC) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>IPC</u></li> </ul>	• <a href="#">GO to Pinpoint Test C.</a>
• The Restraints Control Module (RCM) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Case ground open</li> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>RCM</u></li> </ul>	• <a href="#">GO to Pinpoint Test D.</a>
• The Occupant Classification System Module (OCSM) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>OCSM</u></li> </ul>	• <a href="#">GO to Pinpoint Test E.</a>
• The Smart Junction Box (SJB) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>SJB</u></li> </ul>	• <a href="#">GO to Pinpoint Test F.</a>
• The Body Control Module B (BCM-B) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>BCM-B</u></li> </ul>	• <a href="#">GO to Pinpoint Test G.</a>
• The HVAC module does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• HVAC module</li> </ul>	• <a href="#">GO to Pinpoint Test H.</a>
• The Audio Front Control Module (ACM) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>ACM</u></li> </ul>	• <a href="#">GO to Pinpoint Test I.</a>
• The Front Controls Interface Module (FCIM) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>FCIM</u></li> </ul>	• <a href="#">GO to Pinpoint Test J.</a>
• The Front Display Interface Module (FDIM) does not respond to the scan tool (without navigation)	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>FDIM</u></li> </ul>	• <a href="#">GO to Pinpoint Test K.</a>
• The Global Positioning System Module (GPSM) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>GPSM</u></li> </ul>	• <a href="#">GO to Pinpoint Test L.</a>
• The Accessory Protocol Interface Module (APIM) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>APIM</u></li> </ul>	• <a href="#">GO to Pinpoint Test M.</a>
• The Power Steering Control Module (PSCM) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> <li>• Wiring, terminals or connectors</li> <li>• <u>PSCM</u></li> </ul>	• <a href="#">GO to Pinpoint Test N</a>
• The Parking Aid Module (PAM) does not respond to the scan tool	<ul style="list-style-type: none"> <li>• Fuse</li> </ul>	• <a href="#">GO to Pinpoint Test O</a>

	<ul style="list-style-type: none"> <li>Wiring, terminals or connectors</li> <li><u>PAM</u></li> </ul>	
<ul style="list-style-type: none"> <li>No Medium Speed Controller Area Network (MS-CAN) communication, all modules are not responding</li> </ul>	<ul style="list-style-type: none"> <li>Wiring, terminals or connectors</li> <li><u>APIM</u> (if equipped)</li> <li><u>ACM</u></li> <li><u>BCM-B</u></li> <li><u>FCIM</u></li> <li><u>FDIM</u> (without navigation)</li> <li>HVAC module (if equipped)</li> <li><u>IPC</u> (gateway module)</li> <li><u>SJB</u></li> </ul>	<ul style="list-style-type: none"> <li><a href="#">GO to Pinpoint Test P.</a></li> </ul>
<ul style="list-style-type: none"> <li>No High Speed Controller Area Network (HS-CAN) communication, all modules are not responding</li> </ul>	<ul style="list-style-type: none"> <li>Wiring, terminals or connectors</li> <li>ABS module</li> <li><u>APIM</u> (if equipped)</li> <li><u>IPC</u></li> <li><u>OCSM</u></li> <li><u>PAM</u></li> <li>PCM</li> <li><u>PSCM</u></li> <li><u>RCM</u></li> </ul>	<ul style="list-style-type: none"> <li><a href="#">GO to Pinpoint Test Q.</a></li> </ul>
<ul style="list-style-type: none"> <li>No power to the scan tool</li> </ul>	<ul style="list-style-type: none"> <li>Fuse</li> <li>Wiring, terminals or connectors</li> <li>Scan tool</li> <li>Data Link Connector (DLC)</li> </ul>	<ul style="list-style-type: none"> <li><a href="#">GO to Pinpoint Test R.</a></li> </ul>

**Pinpoint Tests**

**Pinpoint Test A: The PCM Does Not Respond To The Scan Tool**

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [24](#) , Electronic Engine Controls - 5.0L for schematic and connector information.

Refer to Wiring Diagrams Cell [25](#) , Electronic Engine Controls - 5.4L for schematic and connector information.

Refer to Wiring Diagrams Cell [26](#) , Electronic Engine Controls - 3.7L for schematic and connector information.

**Normal Operation**

The PCM communicates with the scan tool through the High Speed Controller Area Network (HS-CAN) .

**This pinpoint test is intended to diagnose the following:**

- Wiring, terminals or connectors
- PCM

**PINPOINT TEST A : THE PCM DOES NOT RESPOND TO THE SCAN TOOL**

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

**A1 VERIFY WHETHER OTHER HS-CAN MODULES PASS THE NETWORK TEST**

- Enter the following diagnostic mode on the scan tool: Network Test .
- In the left hand pane of the IDS network test display screen, verify whether any HS-CAN modules passed the network test.

**Is the text "pass" or a DTC listed next to any of the following modules: ABS module, Instrument Panel Cluster (IPC) , Occupant Classification System Module (OCSM) , PCM, PSCM or Restraints Control Module (RCM) ?**

<b>Yes</b>	If "pass" or a DTC was listed next to the PCM, a network fault is not currently present. <a href="#">GO to Pinpoint Test P</a> to diagnose an intermittent <u>HS-CAN</u> fault condition. If "pass" or a DTC was listed next to one or more modules other than the PCM, GO to <a href="#">A2</a> .
<b>No</b>	No modules are currently communicating on the <u>HS-CAN</u> . <a href="#">GO to Pinpoint Test Q</a> to diagnose no <u>HS-CAN</u> communication.

## **A2 PC/ED MANUAL PINPOINT TEST QA VERIFICATION CHECK**


- Verify that the Powertrain Control/Emissions Diagnosis (PC/ED) pinpoint test QA has been performed.

**Has pinpoint test QA been performed?**

<b>Yes</b>	GO to <a href="#">A3</a> .
<b>No</b>	REFER to the Powertrain Control/Emissions Diagnosis (PC/ED) manual, Section 5, pinpoint test QA to diagnose no communication with the PCM.

## **A3 CHECK THE HS-CAN TERMINATION RESISTANCE**

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the Data Link Connector (DLC) [C251](#) Pin 6, circuit VDB04 (WH/BU), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.




N0026427

**Is the resistance between 54 and 66 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">A5</a> .
<b>No</b>	GO to <a href="#">A4</a> .


## **A4 CHECK THE CAN CIRCUITS BETWEEN THE PCM AND THE DLC FOR AN OPEN**

- Disconnect: PCM [C175B](#) or [C1381B](#) .
- Measure the resistance between the PCM [C175B](#) Pin 59 or [C1381B](#) Pin 59, circuit VDB04 (WH/BU), harness side and the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side.



N0077607

- Measure the resistance between the PCM [C175B](#) Pin 58 or [C1381B](#) Pin 58, circuit VDB05 (WH), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.



N0113941

**Are the resistances less than 5 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">A5</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

### A5 CHECK FOR CORRECT PCM OPERATION

- Disconnect all the PCM connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the PCM connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new PCM. REFER to <a href="#">Section 303-14</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

### Pinpoint Test B: The ABS Module Does Not Respond To The Scan Tool

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [42](#) , Vehicle Dynamic Systems for schematic and connector information.

### Normal Operation

The ABS module communicates with the scan tool through the High Speed Controller Area Network (HS-CAN) .

This pinpoint test is intended to diagnose the following:

- Fuse
- Wiring, terminals or connectors
- ABS module


**PINPOINT TEST B : THE ABS MODULE DOES NOT RESPOND TO THE SCAN TOOL**

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

**B1 CHECK THE ABS MODULE VOLTAGE SUPPLY CIRCUITS FOR AN OPEN**

- Ignition OFF.
- Disconnect: ABS Module [C135](#) .
- Ignition ON.
- Measure the voltage between the ABS module [C135](#) Pin 30, circuit CBP34 (VT/BN), harness side and ground.




Are the voltages greater than 10 volts?

<b>Yes</b>	GO to <a href="#">B2</a> .
<b>No</b>	VERIFY the <a href="#">SJB</a> fuse 34 (5A) is OK. If OK, REPAIR the circuit. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short. CLEAR the DTCs. REPEAT the network test with the scan tool.

**B2 CHECK THE ABS MODULE GROUND CIRCUITS FOR AN OPEN**

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the ABS module [C135](#) Pin 13, circuit GD120 (BK/GN), harness side and ground; and between the ABS module [C135](#) Pin 38, circuit GD120 (BK/GN), harness side and ground.




Are the resistances less than 5 ohms?


<b>Yes</b>	GO to <a href="#">B3</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

**B3 CHECK THE HS-CAN CIRCUITS BETWEEN THE ABS MODULE AND THE DLC FOR AN OPEN**

- Measure the resistance between the ABS module [C135](#) Pin 5, circuit VDB04 (WH/BU), harness side and the Data Link Connector (DLC) [C251](#) Pin 6, circuit VDB04 (WH/BU), harness side.



- Measure the resistance between the ABS module [C135](#) Pin 6, circuit VDB05 (WH), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.



**Are the resistances less than 5 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">B4</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

**B4 CHECK FOR CORRECT ABS MODULE OPERATION**

- Disconnect the ABS module connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the ABS module connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new ABS module. REFER to <a href="#">Section 206-09</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

**Pinpoint Test C: The Instrument Panel Cluster (IPC) Does Not Respond To The Scan Tool**

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [60](#) , Instrument Cluster for schematic and connector information.

**Normal Operation**

The Instrument Panel Cluster (IPC) communicates with the scan tool through the High Speed Controller Area Network (HS-CAN) and the Medium Speed Controller Area Network (MS-CAN) .

**This pinpoint test is intended to diagnose the following:**

- Fuse(s)
- Wiring, terminals or connectors
- IPC


**PINPOINT TEST C : THE IPC DOES NOT RESPOND TO THE SCAN TOOL**

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

**C1 CHECK THE HS-CAN TERMINATION RESISTANCE**

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Disconnect the scan tool cable from the Data Link Connector (DLC) .
- Measure the resistance between the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.




**Is the resistance between 54 and 66 ohms?**


<b>Yes</b>	GO to <a href="#">C3</a> .
<b>No</b>	GO to <a href="#">C2</a> .

**C2 CHECK THE HS-CAN CIRCUITS BETWEEN THE IPC AND THE DLC FOR AN OPEN**

- Disconnect: [IPC C220](#) .
- Measure the resistance between the [IPC C220](#) Pin 13, circuit VDB04 (WH/BU), harness side and the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side.



- Measure the resistance between the [IPC C220](#) Pin 12, circuit VDB05 (WH), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.




N0099862

Are the resistances less than 5 ohms?

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">C7</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

### C3 CHECK THE MS-CAN TERMINATION RESISTANCE

- Measure the resistance between the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.




N0050701

Is the resistance between 54 and 66 ohms?

<b>Yes</b>	GO to <a href="#">C5</a> .
<b>No</b>	GO to <a href="#">C4</a> .

### C4 CHECK THE MS-CAN CIRCUITS BETWEEN THE IPC AND THE DLC FOR AN OPEN


- Disconnect: [IPC C220](#) .
- Measure the resistance between the [IPC C220](#) Pin 26, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side.



N0099863

- Measure the resistance between the [IPC C220](#) Pin 25, circuit VDB07 (VT/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.






N0099864

Are the resistances less than 5 ohms?

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">C7</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

### C5 CHECK THE IPC GROUND CIRCUIT FOR AN OPEN

- Disconnect: [IPC C220](#) .
- Measure the resistance between the [IPC C220](#) Pin 8, circuit GD116 (BK/VT) harness side and ground.




N0099888

Is the resistance less than 5 ohms?

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">C6</a> .
<b>No</b>	REPAIR the circuit. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

### C6 CHECK THE IPC VOLTAGE SUPPLY CIRCUITS FOR AN OPEN

- Ignition ON.
- Measure the voltage between the [IPC C220](#) Pin 1, circuit SBP26 (YE/RD), harness side and ground; and between the [IPC C220](#) Pin 3, circuit CBP36 (BU/BN), harness side and ground.



N0099860

Are the voltages greater than 10 volts?

<b>Yes</b>	TURN the key to the OFF position. GO to <a href="#">C7</a> .
------------	--

<b>No</b>	VERIFY the <u>SJB</u> fuse 26 (10A) or fuse 36 (5A) is OK. If OK, REPAIR the circuit in question. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the short circuit. CLEAR the DTCs. REPEAT the network test with the scan tool.
-----------	--

## C7 CHECK FOR CORRECT IPC OPERATION

- Disconnect the IPC connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the IPC connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	INSTALL a new <u>IPC</u> . REFER to <a href="#">Section 413-01</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

## Pinpoint Test D: The Restraints Control Module (RCM) Does Not Respond To The Scan Tool

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [46](#) , Supplemental Restraint System for schematic and connector information.


### Normal Operation

The Restraints Control Module (RCM) communicates with the scan tool through the High Speed Controller Area Network (HS-CAN) .

### This pinpoint test is intended to diagnose the following:

- Fuse
- Wiring, terminals or connectors
- Case ground open
- RCM

## PINPOINT TEST D : THE RCM DOES NOT RESPOND TO THE SCAN TOOL

 **WARNING:** Never disassemble or tamper with seat belt deployable components, including pretensioners, load limiters and inflators. Never back probe deployable device electrical connectors. Tampering or back probing may cause an accidental deployment and result in personal injury or death.

 **WARNING:** Never probe the electrical connectors on airbag, Safety Canopy or side air curtain assemblies. Failure to follow this instruction may result in the accidental deployment of these assemblies, which increases the risk of serious personal injury or death.

**NOTE:** *The Supplemental Restraint System (SRS) must be fully operational and free of faults before releasing the vehicle to the customer.*

**NOTE:** *Most faults are due to connector and/or wiring concerns. Carry out a thorough inspection and verification before proceeding with the pinpoint test.*

**NOTE:** *Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).*

## D1 CHECK THE RCM CONNECTION

- Ignition OFF.
- Depower the SRS . Refer to [Section 501-20B](#).
- Disconnect: RCM C2041A .
- Disconnect: RCM C2041B .


- Inspect the RCM connector for damaged, pushed out or corroded pins.

**Are RCM C2041A pin 13 and RCM C2041B pins 9 and 10 OK?**

<b>Yes</b>	GO to <a href="#">D2</a> .
<b>No</b>	REPAIR the <u>RCM</u> connector pins as necessary. REPOWER the <u>SRS</u> . REFER to <a href="#">Section 501-20B</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.

**D2 CHECK THE RCM VOLTAGE SUPPLY CIRCUIT FOR AN OPEN**

- Repower the SRS . Refer to [Section 501-20B](#).
- Ignition ON.
- Measure the voltage between the RCM C2041A Pin 13, circuit CBP31 (BU/OG), harness side and ground.



N0117680

**Is the voltage greater than 10 volts?**

<b>Yes</b>	GO to <a href="#">D3</a> .
<b>No</b>	VERIFY the Smart Junction Box (SJB) fuse 31 (10A) is OK. If OK, REPAIR the circuit. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short. CLEAR the DTCs. REPEAT the network test with the scan tool.

**D3 CHECK THE RCM CASE GROUND**


- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the RCM case and a good chassis ground.

**Is the resistance less than 5 ohms?**

<b>Yes</b>	GO to <a href="#">D4</a> .
<b>No</b>	REPAIR the <u>RCM</u> case ground as necessary. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.


**D4 CHECK THE HS-CAN CIRCUITS BETWEEN THE RCM AND THE DLC FOR AN OPEN**

- Measure the resistance between the RCM C2041B Pin 10, circuit VDB04 (WH/BU), harness side and the Data Link Connector (DLC) [C251](#) Pin 6, circuit VDB04 (WH/BU), harness side.



N0090002

- Measure the resistance between the RCM C2041B Pin 9, circuit VDB05 (WH), harness side and the DLC C251 Pin 14, circuit VDB05 (WH), harness side.



**Are the resistances less than 5 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">D5</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

**D5 CHECK FOR CORRECT RCM OPERATION**

- Disconnect all the RCM connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the RCM connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>RCM</u> . REFER to <a href="#">Section 501-20B</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

**Pinpoint Test E: The Occupant Classification System Module (OCSM) Does Not Respond To The Scan Tool**

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [46](#) , Supplemental Restraint System for schematic and connector information.

**Normal Operation**

The Occupant Classification System Module (OCSM) communicates with the scan tool through the High Speed Controller Area Network (HS-CAN) .

**This pinpoint test is intended to diagnose the following:**

- Fuse
- Wiring, terminals or connectors
- OCSM

**PINPOINT TEST E : THE OCSM DOES NOT RESPOND TO THE SCAN TOOL**

**⚠️ WARNING:** Never disassemble or tamper with seat belt deployable components, including pretensioners, load limiters and inflators. Never back probe deployable device electrical connectors. Tampering or back probing may cause

an accidental deployment and result in personal injury or death.

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.


**NOTE:** The Supplemental Restraint System (SRS) must be fully operational and free of faults before releasing the vehicle to the customer.

**NOTE:** Most faults are due to connector and/or wiring concerns. Carry out a thorough inspection and verification before proceeding with the pinpoint test.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

### E1 CHECK THE OCSM VOLTAGE SUPPLY CIRCUIT FOR AN OPEN

- Ignition OFF.
- Depower the SRS . Refer to [Section 501-20B](#).
- Disconnect: OCSM C3043 .
- Deactivate the SRS . Refer to [Section 501-20B](#).
- Repower the SRS . Refer to [Section 501-20B](#).
- Ignition ON.
- Measure the voltage between the OCSM C3043 Pin 1, circuit CBP46 (WH/BU), harness side and ground.




Is the voltage greater than 10 volts?

<b>Yes</b>	GO to <a href="#">E2</a> .
<b>No</b>	VERIFY the Smart Junction Box (SJB) fuse 46 (7.5A) is OK. If OK, REPAIR the circuit. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short. REACTIVATE the <u>SRS</u> . REFER to <a href="#">Section 501-20B</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.

### E2 CHECK THE OCSM GROUND CIRCUIT FOR AN OPEN

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the OCSM C3043 Pin 14, circuit GD138 (BK/WH), harness side and ground.




Is the resistance less than 5 ohms?

<b>Yes</b>	GO to <a href="#">E3</a> .
<b>No</b>	REPAIR the circuit. REACTIVATE the <u>SRS</u> . CONNECT the negative battery cable. REFER to <a href="#">Section 501-20B</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.


### E3 CHECK THE HS-CAN CIRCUITS BETWEEN THE OCSM AND THE DLC FOR AN OPEN

- Measure the resistance between the OCSM C3043 Pin 18, circuit VDB04 (WH/BU), harness side and the Data Link Connector (DLC) C251 Pin 6, circuit VDB04 (WH/BU), harness side.



N0026670

- Measure the resistance between the OCSM C3043 Pin 9, circuit VDB05 (WH), harness side and the DLC C251 Pin 14, circuit VDB05 (WH), harness side.



N0026671

**Are the resistances less than 5 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">E4</a> .
<b>No</b>	REPAIR the circuit. REACTIVATE the <u>SRS</u> . CONNECT the negative battery cable. REFER to <a href="#">Section 501-20B</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.

### E4 CHECK FOR CORRECT OCSM OPERATION

- Disconnect the OCSM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the OCSM connector and make sure it seats correctly.
- Verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>OCSM</u> . REFER to <a href="#">Section 501-20B</a> . REACTIVATE the <u>SRS</u> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. REACTIVATE the <u>SRS</u> . REFER to <a href="#">Section 501-20B</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.

### Pinpoint Test F: The Smart Junction Box (SJB) Does Not Respond To The Scan Tool

Refer to Wiring Diagrams Cell [13](#) , Power Distribution/SJB for schematic and connector information.

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

**Normal Operation**

The Smart Junction Box (SJB) communicates with the scan tool through the Medium Speed Controller Area Network (MS-CAN) .

**This pinpoint test is intended to diagnose the following:**

- Fuse
- Wiring, terminals or connectors
- SJB


**PINPOINT TEST F : THE SJB DOES NOT RESPOND TO THE SCAN TOOL**

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

**F1 CHECK THE SJB VOLTAGE SUPPLY CIRCUIT FOR AN OPEN**

- Ignition ON.
  - **NOTE:** Measurements are taken with the fuses installed.
- Measure the voltage between the SJB fuse 5 (10A) and ground.




N0060055

**Is the voltage greater than 10 volts?**

<b>Yes</b>	GO to <a href="#">F2</a> .
<b>No</b>	VERIFY the <u>SJB</u> fuse 5 (10A) is OK. If OK, REPAIR the circuit. CLEAR the DTCs. REPEAT the network test with the scan tool. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short.

**F2 CHECK THE SJB GROUND CIRCUIT FOR AN OPEN**

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Disconnect: SJB C2280D .
- Measure the resistance between the SJB C2280D Pin 8, circuit GD139 (BK/YE), harness side and ground; and between the SJB C2280D Pin 12, circuit GD139 (BK/YE), harness side and ground.




Is the resistance less than 5 ohms?


<b>Yes</b>	GO to <a href="#">F3</a> .
<b>No</b>	REPAIR the circuit. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

### F3 CHECK THE MS-CAN CIRCUITS BETWEEN THE SJB AND THE DLC FOR AN OPEN

- Disconnect: [SJB C2280B](#) .
- Measure the resistance between the [SJB C2280B](#) Pin 37, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side.



- Measure the resistance between the [SJB C2280B](#) Pin 38, circuit VDB07 (VT/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.



Are the resistances less than 5 ohms?

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">F4</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

### F4 CHECK FOR CORRECT SJB OPERATION

- Disconnect all the [SJB](#) connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the [SJB](#) connectors and make sure they seat correctly.



- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>SJB</u> . REFER to <a href="#">Section 419-10</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

**Pinpoint Test G: The Body Control Module B (BCM-B) Does Not Respond To The Scan Tool**

Refer to Wiring Diagrams Cell [89](#) , Interior Lamps for schematic and connector information.

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

**Normal Operation**

The Body Control Module B (BCM-B) communicates with the scan tool through the Medium Speed Controller Area Network (MS-CAN) .

**This pinpoint test is intended to diagnose the following:**

- Fuse
- Wiring, terminals or connectors
- BCM-B


**PINPOINT TEST G : THE BCM-B DOES NOT RESPOND TO THE SCAN TOOL**

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

**G1 CHECK THE BCM-B VOLTAGE SUPPLY CIRCUITS FOR AN OPEN**

- Ignition OFF.
- Disconnect: BCM-B C4368A .
- Ignition ON.
- Measure the voltage between the BCM-B C4368A Pin 1, circuit SBB18 (YE/RD), harness side and ground; and between the BCM-B C4368A Pin 7, circuit CBP35 (YE/GY), harness side and ground.



N0099865


**Are the voltages greater than 10 volts?**

<b>Yes</b>	GO to <a href="#">G2</a> .
<b>No</b>	VERIFY the Battery Junction Box (BJB) fuse 18 (20A) or Smart Junction Box (SJB) fuse 35 (10A) is OK. If OK, REPAIR the circuit in question. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short. CLEAR the DTCs. REPEAT the network test with the scan tool.

**G2 CHECK THE BCM-B GROUND CIRCUIT FOR AN OPEN**

- Ignition OFF.

- Disconnect: Negative Battery Cable .
- Measure the resistance between the [BCM-B C4368A](#) Pin 13, circuit GD110 (BK/WH), harness side and ground.




N0099866

**Is the resistance less than 5 ohms?**

<b>Yes</b>	GO to <a href="#">G3</a> .
<b>No</b>	REPAIR the circuit. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.


### G3 CHECK THE MS-CAN CIRCUITS BETWEEN THE BCM-B AND THE DLC FOR AN OPEN

- Measure the resistance between the [BCM-B C4368A](#) Pin 11, circuit VDB06 (GY/OG), harness side and the Data Link Connector (DLC) [C251](#) Pin 3, circuit VDB06 (GY/OG), harness side.



N0099867

- Measure the resistance between the [BCM-B C4368A](#) Pin 23, circuit VDB07 (VT/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.



N0099868

**Are the resistances less than 5 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">G4</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

### G4 CHECK FOR CORRECT BCM-B OPERATION

- Disconnect all the [BCM-B](#) connectors.
- Check for:
  - corrosion
  - damaged pins

- pushed-out pins
- Connect all the BCM-B connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new BCM-B . REFER to <a href="#">Section 419-10</a> . TEST the system for normal operation.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

**Pinpoint Test H: The HVAC Module Does Not Respond To The Scan Tool**

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [54](#) , Manual Climate Control for schematic and connector information.

Refer to Wiring Diagrams Cell [55](#) , Automatic Climate Control System for schematic and connector information.

**Normal Operation**

The HVAC module communicates with the scan tool through the Medium Speed Controller Area Network (MS-CAN) .

**This pinpoint test is intended to diagnose the following:**

- Fuse
- Wiring, terminals or connectors
- HVAC module


**PINPOINT TEST H : THE HVAC MODULE DOES NOT RESPOND TO THE SCAN TOOL**

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

**H1 CHECK THE HVAC VOLTAGE SUPPLY CIRCUITS FOR AN OPEN**

- Ignition OFF.
- Disconnect: HVAC Module [C294A](#) .
- Ignition ON.
- Measure the voltage between the HVAC module [C294A](#) Pin 1, circuit SBP15 (WH/RD), harness side and ground.




**Are the voltages greater than 10 volts?**

<b>Yes</b>	GO to <a href="#">H2</a> .
<b>No</b>	VERIFY the Smart Junction Box (SJB) fuse 15 (10A) is OK. If OK, REPAIR the circuit in question. CLEAR the DTCs. REPEAT the network test with the scan tool. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short.

## H2 CHECK THE HVAC GROUND CIRCUIT FOR AN OPEN

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the HVAC module [C294A](#) Pin 17, circuit GD116 (BK/VT), harness side and ground.




Is the resistance less than 5 ohms?


<b>Yes</b>	GO to <a href="#">H3</a> .
<b>No</b>	REPAIR the circuit. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

## H3 CHECK THE MS-CAN CIRCUITS BETWEEN THE HVAC MODULE AND THE DLC FOR AN OPEN

- Measure the resistance between the HVAC module [C294A](#) Pin 15, circuit VDB06 (GY/OG), harness side and the Data Link Connector (DLC) [C251](#) Pin 3, circuit VDB06 (GY/OG), harness side.



- Measure the resistance between the HVAC module [C294A](#) Pin 14, circuit VDB07 (VT/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.



Are the resistances less than 5 ohms?

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">H4</a> .
<b>No</b>	REPAIR the circuit as necessary. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

#### H4 CHECK FOR CORRECT HVAC MODULE OPERATION

- Disconnect all the HVAC module connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the HVAC module connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

##### Is the concern still present?

<b>Yes</b>	INSTALL a new HVAC module. REFER to <a href="#">Section 412-01</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

#### Pinpoint Test I: The Audio Front Control Module (ACM) Does Not Respond To The Scan Tool

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [130](#) , Audio System/Navigation for schematic and connector information.

#### Normal Operation

The Audio Front Control Module (ACM) communicates with the scan tool through the Medium Speed Controller Area Network (MS-CAN) .

#### This pinpoint test is intended to diagnose the following:

- Fuse
- Wiring, terminals or connectors
- ACM


#### PINPOINT TEST I : THE ACM DOES NOT RESPOND TO THE SCAN TOOL

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

#### I1 CHECK THE ACM VOLTAGE SUPPLY CIRCUITS FOR AN OPEN

- Ignition OFF.
- Disconnect: ACM C290D .
- Ignition ON.
- Measure the voltage between the ACM C290D Pin 1, circuit SBP39 (WH/RD), harness side and ground.



N0062412


#### Are the voltages greater than 10 volts?

<b>Yes</b>	GO to <a href="#">I2</a> .
------------	----------------------------

<b>No</b>	VERIFY the <u>SJB</u> fuse 39 (20A) is OK. If OK, REPAIR the circuit in question. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short. CLEAR the DTCs. REPEAT the network test with the scan tool.
-----------	--

## I2 CHECK THE ACM GROUND CIRCUIT FOR AN OPEN

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the ACM C290D Pin 13, circuit GD115 (BK/GY), harness side and ground.




A0057104

Is the resistance less than 5 ohms?

<b>Yes</b>	GO to <a href="#">I3</a> .
<b>No</b>	REPAIR the circuit. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.


## I3 CHECK THE MS-CAN CIRCUITS BETWEEN THE ACM AND THE DLC FOR AN OPEN

- Disconnect: ACM C290A .
- Measure the resistance between the ACM C290A Pin 15, circuit VDB06 (GY/OG), harness side and the Data Link Connector (DLC) C251 Pin 3, circuit VDB06 (GY/OG), harness side.



N0012514

- Measure the resistance between the ACM C290A Pin 16, circuit VDB07 (VT/OG), harness side and the DLC C251 Pin 11, circuit VDB07 (VT/OG), harness side.



N0012515

Are the resistances less than 5 ohms?

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">I4</a> .
------------	--

<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.
-----------	---

#### I4 CHECK FOR CORRECT ACM OPERATION

- Disconnect all the ACM connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the ACM connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

#### Is the concern still present?

<b>Yes</b>	INSTALL a new <u>ACM</u> . REFER to <a href="#">Section 415-00</a> . TEST the system for normal operation.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

#### Pinpoint Test J: The Front Controls Interface Module (FCIM) Does Not Respond To The Scan Tool

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [130](#) , Audio System/Navigation for schematic and connector information.

#### Normal Operation

The Front Controls Interface Module (FCIM) communicates with the scan tool through the Medium Speed Controller Area Network (MS-CAN) .

#### This pinpoint test is intended to diagnose the following:

- Fuse
- Wiring, terminals or connectors
- FCIM


#### PINPOINT TEST J : THE FCIM DOES NOT RESPOND TO THE SCAN TOOL

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

#### J1 CHECK THE FCIM VOLTAGE SUPPLY CIRCUIT FOR AN OPEN

- Ignition OFF.
- Disconnect: FCIM C2402 .
- Ignition ON.
- Measure the voltage between the FCIM C2402 Pin 1, circuit SBP14 (BN/RD), harness side and ground.




N0099873

### Is the voltage greater than 10 volts?

<b>Yes</b>	GO to <a href="#">J2</a> .
<b>No</b>	VERIFY the Smart Junction Box (SJB) fuse 14 (10A) is OK. If OK, REPAIR the circuit in question. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short. CLEAR the DTCs. REPEAT the network test with the scan tool.

### J2 CHECK THE FCIM GROUND CIRCUIT FOR AN OPEN

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the [FCIM C2402](#) Pin 4, circuit GD115 (BK/GY), harness side and ground.




N0099874

### Is the resistance less than 5 ohms?

<b>Yes</b>	GO to <a href="#">J3</a> .
<b>No</b>	REPAIR the circuit. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.


### J3 CHECK THE MS-CAN CIRCUITS BETWEEN THE FCIM AND THE DLC FOR AN OPEN

- Measure the resistance between the [FCIM C2402](#) Pin 2, circuit VDB06 (GY/OG), harness side and the Data Link Connector (DLC) [C251](#) Pin 3, circuit VDB06 (GY/OG), harness side.



N0099875

- Measure the resistance between the [FCIM C2402](#) Pin 3, circuit VDB07 (VT/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.



N0099876

### Are the resistances less than 5 ohms?



<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">J4</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

#### J4 CHECK FOR CORRECT FCIM OPERATION

- Disconnect the FCIM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the FCIM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

#### Is the concern still present?

<b>Yes</b>	INSTALL a new <u>FCIM</u> . REFER to <a href="#">Section 415-00</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

#### Pinpoint Test K: The Front Display Interface Module (FDIM) Does Not Respond To The Scan Tool (Without Navigation)

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [130](#) , Audio System/Navigation for schematic and connector information.

#### Normal Operation

The Front Display Interface Module (FDIM) (without navigation) communicates with the scan tool through the Medium Speed Controller Area Network (MS-CAN) .

#### This pinpoint test is intended to diagnose the following:

- Fuse
- Wiring, terminals or connectors
- FDIM


#### PINPOINT TEST K : THE FDIM DOES NOT RESPOND TO THE SCAN TOOL (WITHOUT NAVIGATION)

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

#### K1 CHECK THE FDIM VOLTAGE SUPPLY CIRCUIT FOR AN OPEN

- Ignition OFF.
- Disconnect: FDIM C2123 .
- Ignition ON.
- Measure the voltage between the FDIM C2123 Pin 12, circuit SBP14 (BN/RD), harness side and ground.




N0062413

Is the voltage greater than 10 volts?

<b>Yes</b>	GO to <a href="#">K2</a> .
<b>No</b>	VERIFY the Smart Junction Box (SJB) fuse 14 (10A) is OK. If OK, REPAIR the circuit. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short. CLEAR the DTCs. REPEAT the network test with the scan tool.

### K2 CHECK THE FDIM GROUND CIRCUIT FOR AN OPEN

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the [FDIM C2123](#) Pin 8, circuit GD116 (BK/VT), harness side and ground.




N0077731

Is the resistance less than 5 ohms?

<b>Yes</b>	GO to <a href="#">K3</a> .
<b>No</b>	REPAIR the circuit. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.


### K3 CHECK THE MS-CAN CIRCUITS BETWEEN THE FDIM AND THE DLC FOR AN OPEN

- Measure the resistance between the [FDIM C2123](#) Pin 4, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side.



N0077618

- Measure the resistance between the [FDIM C2123](#) Pin 5, circuit VDB07 (VT/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.



N0077619

**Are the resistances less than 5 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">K4</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

#### **K4 CHECK FOR CORRECT FDIM OPERATION**

- Disconnect the FDIM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the FDIM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>FDIM</u> . REFER to <a href="#">Section 415-00</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

#### **Pinpoint Test L: The Global Positioning System Module (GPSM) Does Not Respond To The Scan Tool**

Refer to Wiring Diagrams Cell [14](#) , Lodule Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [130](#) , Audio System/Navigation for schematic and connector information.

#### **Normal Operation**

The Global Positioning System Module (GPSM) communicates with the scan tool through the Medium Speed Controller Area Network (MS-CAN) .

**This pinpoint test is intended to diagnose the following:**

- Fuse
- Wiring, terminals or connectors
- GPSM


#### **PINPOINT TEST L : THE GPSM DOES NOT RESPOND TO THE SCAN TOOL**

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

#### **L1 CHECK THE GPSM VOLTAGE SUPPLY CIRCUIT FOR AN OPEN**

- Ignition OFF.
- Disconnect: [GPSM C2398](#) .
- Ignition ON.
- Measure the voltage between the [GPSM C2398](#) Pin 1, circuit SBP14 (BN/RD), harness side and ground.




N0094349

**Is the voltage greater than 10 volts?**

<b>Yes</b>	GO to <a href="#">L2</a> .
<b>No</b>	VERIFY the Smart Junction Box (SJB) fuse 14 (10A) is OK. If OK, REPAIR the circuit in question. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short. CLEAR the DTCs. REPEAT the network test with the scan tool.

## L2 CHECK THE GPSM GROUND CIRCUIT FOR AN OPEN

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the [GPSM C2398](#) Pin 6, circuit GD115 (BK/GY), harness side and ground.




N0094350

**Is the resistance less than 5 ohms?**


<b>Yes</b>	GO to <a href="#">L3</a> .
<b>No</b>	REPAIR the circuit. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

## L3 CHECK THE MS-CAN CIRCUITS BETWEEN THE GPSM AND THE DLC FOR AN OPEN

- Measure the resistance between the [GPSM C2398](#) Pin 2, circuit VDB06 (GY/OG), harness side and the Data Link Connector (DLC) [C251](#) Pin 3, circuit VDB06 (GY/OG), harness side.



- Measure the resistance between the GPSM C2398 Pin 3, circuit VDB07 (VT/OG), harness side and the DLC C251 Pin 11, circuit VDB07 (VT/OG), harness side.



**Are the resistances less than 5 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">L4</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

**L4 CHECK FOR CORRECT GPSM OPERATION**

- Disconnect the GPSM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the GPSM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>GPSM</u> . REFER to <a href="#">Section 415-00</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

**Pinpoint Test M: The Accessory Protocol Interface Module (APIM) Does Not Respond To The Scan Tool**

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [130](#) , Audio System/Navigation for schematic and connector information.

**Normal Operation**

The Accessory Protocol Interface Module (APIM) communicates with the scan tool and other modules through the Medium Speed Controller Area Network (MS-CAN) and also communicates with other modules on the High Speed Controller Area Network (HS-CAN) .

This pinpoint test is intended to diagnose the following:

- Fuse
- Wiring, terminals or connectors
- APIM


**PINPOINT TEST M : THE APIM DOES NOT RESPOND TO THE SCAN TOOL**

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

**M1 CHECK THE APIM VOLTAGE SUPPLY CIRCUIT FOR AN OPEN**

- Disconnect: APIM C2383 .
- Ignition ON.
- Measure the voltage between the APIM C2383 Pin 1, circuit SBP03 (BU/RD), harness side and ground.




Is the voltage greater than 10 volts?

<b>Yes</b>	GO to <a href="#">M2</a> .
<b>No</b>	VERIFY the Smart Junction Box (SJB) fuse 3 (15A) is OK. If OK, REPAIR the circuit. CLEAR the DTCs. REPEAT the network test with the scan tool. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short.

**M2 CHECK THE APIM GROUND CIRCUIT FOR AN OPEN**

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the APIM C2383 Pin 37, circuit GD115 (BK/GY), harness side and ground; and between the APIM C2383 Pin 38, circuit GD115 (BK/GY), harness side and ground.




Are the resistances less than 5 ohms?

<b>Yes</b>	GO to <a href="#">M3</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.


**M3 CHECK THE HS-CAN CIRCUITS BETWEEN THE APIM AND THE DLC FOR AN OPEN**

- Measure the resistance between the APIM C2383 Pin 53, circuit VDB04 (WH/BU), harness side and the Data Link Connector (DLC) C251 Pin 6, circuit VDB04 (WH/BU), harness side.



N0077603

- Measure the resistance between the APIM C2383 Pin 54, circuit VDB05 (WH), harness side and the DLC C251 Pin 14, circuit VDB05 (WH), harness side.




N0077604

**Are the resistances less than 5 ohms?**

<b>Yes</b>	GO to <a href="#">M4</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.


#### **M4 CHECK THE MS-CAN CIRCUITS BETWEEN THE APIM AND THE DLC FOR AN OPEN**

- Measure the resistance between the APIM C2383 Pin 16, circuit VDB06 (GY/OG), harness side and the DLC C251 Pin 3, circuit VDB06 (GY/OG), harness side.



N0077605

- Measure the resistance between the APIM C2383 Pin 17, circuit VDB07 (VT/OG), harness side and the DLC C251 Pin 11, circuit VDB07 (VT/OG), harness side.



N0077606


### Are the resistances less than 5 ohms?

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">M5</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

### M5 CHECK FOR CORRECT APIM OPERATION

- Disconnect all the APIM connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the APIM connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	 <b>VIN required to access Guided Routine (APIM)</b>
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

### Pinpoint Test N: The Power Steering Control Module (PSCM) Does Not Respond To The Scan Tool

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [43](#) , Power Steering Controls for schematic and connector information.

### Normal Operation

The Power Steering Control Module (PSCM) communicates with the scan tool and other modules through the High Speed Controller Area Network (HS-CAN) .

### This pinpoint test is intended to diagnose the following:

- Fuse
- Wiring, terminals or connectors
- PSCM

### PINPOINT TEST N : THE PSCM DOES NOT RESPOND TO THE SCAN TOOL


**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

### N1 CHECK THE PSCM VOLTAGE SUPPLY CIRCUIT FOR AN OPEN

- Disconnect: PSCM C1463A .
- Ignition ON.
- Measure the voltage between the PSCM C1463A Pin 1, circuit CBB45 (YE), harness side and ground.






N0113933

Is the voltage greater than 10 volts?

<b>Yes</b>	GO to <a href="#">N2</a> .
<b>No</b>	VERIFY the <a href="#">BJB</a> fuse 45 (5A) is OK. If OK, REPAIR the circuit. CLEAR the DTCs. REPEAT the network test with the scan tool. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short.

### N2 CHECK THE PSCM GROUND CIRCUIT FOR AN OPEN

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the [PSCM C1463B](#) Pin 1, circuit GD125 (BK), harness side and ground




N0113935

Are the resistances less than 5 ohms?

<b>Yes</b>	GO to <a href="#">N3</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.


### N3 CHECK THE HS-CAN CIRCUITS BETWEEN THE PSCM AND THE DLC FOR AN OPEN

- Measure the resistance between the [PSCM C1463A](#) Pin 2, circuit VDB04 (WH/BU), harness side and the Data Link Connector (DLC) [C251](#) Pin 6, circuit VDB04 (WH/BU), harness side.



N0113936

- Measure the resistance between the [PSCM C1463A](#) Pin 3, circuit VDB05 (WH), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.



N0113937

**Are the resistances less than 5 ohms?**

<b>Yes</b>	GO to <a href="#">N4</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

#### **N4 CHECK FOR CORRECT PSCM OPERATION**

- Disconnect all the PSCM connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the PSCM connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>PSCM</u> . REFER to Steering Gear in <a href="#">Section 211-02</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

#### **Pinpoint Test O: The Parking Aid Module (PAM) Does Not Respond To The Scan Tool**

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [131](#) , Parking Aid for schematic and connector information.

#### **Normal Operation**

The Parking Aid Module (PAM) communicates with the scan tool and other modules through the High Speed Controller Area Network (HS-CAN) .

**This pinpoint test is intended to diagnose the following:**

- Fuse
- Wiring, terminals or connectors
- PAM


#### **PINPOINT TEST O : THE PAM DOES NOT RESPOND TO THE SCAN TOOL**

**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

#### **O1 CHECK THE PAM VOLTAGE SUPPLY CIRCUIT FOR AN OPEN**

- Disconnect: [PAM C4014](#) .
- Ignition ON.
- Measure the voltage between the [PAM C4014](#) Pin 1, circuit CBP32 (GN/VT), harness side and ground.




A0072266

**Is the voltage greater than 10 volts?**

<b>Yes</b>	GO to <a href="#">O2</a> .
<b>No</b>	VERIFY the Smart Junction Box (SJB) fuse 32 (10A) is OK. If OK, REPAIR the circuit. CLEAR the DTCs. REPEAT the network test with the scan tool. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short.

### O2 CHECK THE PAM GROUND CIRCUIT FOR AN OPEN

- Ignition OFF.
- Disconnect: Negative Battery Cable .
- Measure the resistance between the [PAM C4014](#) Pin 4, circuit GD110 (BK/WH), harness side and ground




A0072267

**Are the resistances less than 5 ohms?**

<b>Yes</b>	GO to <a href="#">O3</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.


### O3 CHECK THE HS-CAN CIRCUITS BETWEEN THE PAM AND THE DLC FOR AN OPEN

- Measure the resistance between the [PAM C4014](#) Pin 3, circuit VDB04 (WH/BU), harness side and the Data Link Connector (DLC) [C251](#) Pin 6, circuit VDB04 (WH/BU), harness side.



N0114774

- Measure the resistance between the PAM C4014 Pin 11, circuit VDB05 (WH), harness side and the DLC C251 Pin 14, circuit VDB05 (WH), harness side.



N0114775

**Are the resistances less than 5 ohms?**

<b>Yes</b>	GO to <a href="#">O4</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

**O4 CHECK FOR CORRECT PAM OPERATION**

- Disconnect the PAM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the PAM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>PAM</u> . REFER to <a href="#">Section 413-13</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CLEAR the DTCs. REPEAT the network test with the scan tool.

**Pinpoint Test P: No Medium Speed Controller Area Network (MS-CAN) Communication, All Modules Are Not Responding**

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

**Normal Operation**

The Medium Speed Controller Area Network (MS-CAN) uses an unshielded twisted pair cable, circuits VDB06 (MS-CAN -) and VDB07 (MS-CAN +).

**NOTE:** *The Instrument Panel Cluster (IPC) , while on the MS-CAN , communicates with the scan tool only on the High Speed Controller Area Network (HS-CAN) .*

**This pinpoint test is intended to diagnose the following:**

- Wiring, terminals or connectors
- Audio Front Control Module (ACM)
- Accessory Protocol Interface Module (APIM) (if equipped)
- Body Control Module B (BCM-B)
- Front Controls Interface Module (FCIM)
- Front Display Interface Module (FDIM) (without navigation)
- Global Positioning System Module (GPSM)
- HVAC module

- Instrument Panel Cluster (IPC)
- Smart Junction Box (SJB)

### PINPOINT TEST P : NO MS-CAN COMMUNICATION, ALL MODULES ARE NOT RESPONDING


**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Most faults are due to connector and/or wiring concerns. Carry out a thorough inspection and verification before proceeding with the Pinpoint Test.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

#### P1 CHECK THE DLC PINS FOR DAMAGE

- Ignition OFF.
- Disconnect the scan tool cable from the Data Link Connector (DLC) .
- Inspect DLC pins 3 and 11 for damage.




N0053178

Are DLC pins 3 and 11 OK?

<b>Yes</b>	GO to <a href="#">P2</a> .
<b>No</b>	REPAIR the <u>DLC</u> as necessary. CLEAR the DTCs. REPEAT the network test with the scan tool.

#### P2 CHECK THE MS-CAN TERMINATION RESISTANCE

- Disconnect: Negative Battery Cable .
- Measure the resistance between the DLC C251 Pin 3, circuit VDB06 (GY/OG), harness side and the DLC C251 Pin 11, circuit VDB07 (VT/OG), harness side.




N0050701

Is the resistance between 54 and 66 ohms?

<b>Yes</b>	GO to <a href="#">P3</a> .
<b>No</b>	GO to <a href="#">P5</a> .

#### P3 CHECK THE MS-CAN (+) AND MS-CAN (-) CIRCUITS FOR A SHORT TO GROUND

- Measure the resistance between the DLC C251 Pin 3, circuit VDB06 (GY/OG), harness side and ground; and between the DLC C251 Pin 11, circuit VDB07 (VT/OG), harness side and ground.




N0008947

**Are the resistances greater than 1,000 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">P4</a> .
<b>No</b>	GO to <a href="#">P12</a> .

**P4 CHECK THE MS-CAN (+) AND MS-CAN (-) CIRCUITS FOR A SHORT TO VOLTAGE**

- Ignition ON.
- Measure the voltage between the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side and ground; and between the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side and ground.




N0050702

**Is the voltage greater than 6 volts?**

<b>Yes</b>	REPAIR the circuit. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	GO to <a href="#">P13</a> .

**P5 CHECK THE MS-CAN TERMINATION RESISTOR**

- Measure the resistance between the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.




N0050701

**Is the resistance between 108 and 132 ohms?**

<b>Yes</b>	GO to <a href="#">P6</a> .
<b>No</b>	GO to <a href="#">P9</a> .

## P6 CHECK THE MS-CAN TERMINATION RESISTOR WITH THE SJB DISCONNECTED

- Disconnect: Smart Junction Box (SJB) [C2280B](#) .
- Measure the resistance between the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.




N0050701

Is the resistance between 108 and 132 ohms?

<b>Yes</b>	GO to <a href="#">P7</a> .
<b>No</b>	GO to <a href="#">P8</a> .


## P7 CHECK THE MS-CAN CIRCUITS BETWEEN THE SJB AND THE DLC FOR AN OPEN

- Measure the resistance between the [SJB C2280B](#) Pin 37, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side.



N0064664

- Measure the resistance between the [SJB C2280B](#) Pin 38, circuit VDB07 (VT/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.



N0064665


Are the resistances less than 5 ohms?

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">P22</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

## P8 CHECK THE MS-CAN CIRCUITS BETWEEN THE IPC AND THE DLC FOR AN OPEN


- Disconnect: [IPC C220](#) .

- Measure the resistance between the [IPC C220](#) Pin 26, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side.



N0099863

- Measure the resistance between the [IPC C220](#) Pin 25, circuit VDB07 (VT/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.




N0099864

**Are the resistances less than 5 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">P30</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

**P9 CHECK THE MS-CAN (+) AND MS-CAN (-) CIRCUITS FOR A SHORT TOGETHER**

- Measure the resistance between the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.



N0050701


**Is the resistance less than 5 ohms?**

<b>Yes</b>	GO to <a href="#">P11</a> .
<b>No</b>	GO to <a href="#">P10</a> .

**P10 CHECK THE MS-CAN CIRCUITS FOR AN OPEN AT THE DLC**

- Measure the resistance between the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side.






N0050701

**Is the resistance greater than 10,000 ohms?**

<b>Yes</b>	REPAIR the <a href="#">DLC</a> or REPAIR the circuit in question. CLEAR the DTCs. REPEAT the Network Test with the scan tool.
<b>No</b>	A capacitor internal to a module may still be draining, causing irregular resistance readings. WAIT 5 minutes. REPEAT the pinpoint test.

**P11 CHECK THE MS-CAN (+) AND MS-CAN (-) CIRCUITS FOR A SHORT TOGETHER**

- While measuring the resistance between the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side and the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side, disconnect the following modules one at a time until the resistance is greater than 5 ohms.
  - [APIM C2383](#) (if equipped)
  - [ACM C290A](#)
  - [BCM-B C4368A](#)
  - [FCIM C2402](#) (if equipped)
  - [FDIM C2123](#) (without navigation)
  - [GPSM C2398](#) (if equipped)
  - HVAC module [C294A](#)
  - [IPC C220](#)
  - [SJB C2280B](#)




N0050701

**Did the resistance change to greater than 5 ohms with one of the modules disconnected?**

<b>Yes</b>	CONNECT the negative battery cable. For the <a href="#">APIM</a> , GO to <a href="#">P29</a> . For the <a href="#">ACM</a> , GO to <a href="#">P28</a> . For the <a href="#">BCM-B</a> , GO to <a href="#">P23</a> . For the <a href="#">FCIM</a> , GO to <a href="#">P24</a> . For the <a href="#">FDIM</a> , GO to <a href="#">P27</a> . For the <a href="#">GPSM</a> , GO to <a href="#">P25</a> . For the HVAC module, GO to <a href="#">P26</a> . For the <a href="#">IPC</a> , GO to <a href="#">P30</a> . For the <a href="#">SJB</a> , GO to <a href="#">P22</a> .
<b>No</b>	REPAIR circuits VDB06 (GY/OG) and VDB07 (VT/OG) for a short together. CONNECT all modules. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the Network Test with the scan tool.

## P12 CHECK THE MS-CAN (+) AND MS-CAN (-) CIRCUITS FOR A SHORT TO GROUND WITH THE MODULES DISCONNECTED

- Measure the resistance between the [DLC C251](#) Pin 3, circuit VDB06 (GY/OG), harness side and ground; and between the [DLC C251](#) Pin 11, circuit VDB07 (VT/OG), harness side and ground. Check for the short to ground on both circuits after disconnecting each module. Disconnect the following modules one at a time until the resistance to ground is greater than 1,000 ohms.
  - [APIM C2383](#) (if equipped)
  - [ACM C290A](#)
  - [BCM-B C4368A](#)
  - [FCIM C2402](#) (if equipped)
  - [FDIM C2123](#) (without navigation)
  - [GPSM C2398](#) (if equipped)
  - HVAC module [C294A](#)
  - [IPC C220](#)
  - [SJB C2280B](#)



Did the resistance change to greater than 1,000 ohms with one of the modules disconnected?

<b>Yes</b>	CONNECT the negative battery cable. For the <a href="#">APIM</a> , GO to <a href="#">P29</a> . For the <a href="#">ACM</a> , GO to <a href="#">P28</a> . For the <a href="#">BCM-B</a> , GO to <a href="#">P23</a> . For the <a href="#">FCIM</a> , GO to <a href="#">P24</a> . For the <a href="#">FDIM</a> , GO to <a href="#">P27</a> . For the <a href="#">GPSM</a> , GO to <a href="#">P25</a> . For the HVAC module, GO to <a href="#">P26</a> . For the <a href="#">IPC</a> , GO to <a href="#">P30</a> . For the <a href="#">SJB</a> , GO to <a href="#">P22</a> .
<b>No</b>	REPAIR the circuit in question for a short to ground. CLEAR the DTCs. REPEAT the Network Test with the scan tool.

## P13 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE ACM DISABLED

**NOTE:** When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.

- Disconnect: [SJB](#) Fuse 39 (20A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

Do all other modules pass the network test?

<b>Yes</b>	INSTALL the removed fuse. <a href="#">GO to Pinpoint Test I.</a>
<b>No</b>	INSTALL the removed fuse. GO to <a href="#">P14</a> .

## P14 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE SJB DISABLED

**NOTE:** When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.

- Disconnect: [SJB](#) Fuse 5 (10A) .

- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuse. <a href="#">GO to Pinpoint Test F.</a>
<b>No</b>	INSTALL the removed fuse. GO to <a href="#">P15.</a>

**P15 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE BCM-B DISABLED**

**NOTE:** *When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.*

- Disconnect: [BJB](#) Fuse 18 (10A) and [SJB](#) Fuse 35 (10A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuses. <a href="#">GO to Pinpoint Test G.</a>
<b>No</b>	INSTALL the removed fuses. GO to <a href="#">P16.</a>

**P16 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE HVAC MODULE DISABLED**

**NOTE:** *When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.*

- Disconnect: [SJB](#) Fuse 15 (10A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuse. <a href="#">GO to Pinpoint Test H.</a>
<b>No</b>	INSTALL the removed fuse. GO to <a href="#">P17.</a>

**P17 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE FCIM , FDIM AND GPSM DISABLED**

**NOTE:** *When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.*

- Disconnect: [SJB](#) Fuse 14 (10A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuse. GO to <a href="#">P18.</a>
<b>No</b>	INSTALL the removed fuse. If the vehicle is equipped with SYNC®, GO to <a href="#">P20.</a> If the vehicle is not equipped with SYNC®, GO to <a href="#">P21.</a>

**P18 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE FCIM DISABLED**

**NOTE:** *When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.*

- Disconnect: [FCIM C2402](#) .
- Enter the following diagnostic mode on the scan tool: Network Test .

- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	CONNECT the <u>FCIM</u> . <a href="#">GO to Pinpoint Test J.</a>
<b>No</b>	If the vehicle is equipped with an <u>FDIM</u> (without navigation) only, <a href="#">GO to Pinpoint Test K.</a> If the vehicle is equipped with a <u>GPSM</u> only, <a href="#">GO to Pinpoint Test L.</a> If the vehicle is equipped with both an <u>FDIM</u> (without navigation) and a <u>GPSM</u> , GO to <a href="#">P19.</a>

**P19 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE FDIM DISCONNECTED**

**NOTE:** *When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.*

- Disconnect: FDIM C2123 .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	CONNECT the <u>FDIM</u> . <a href="#">GO to Pinpoint Test K.</a>
<b>No</b>	CONNECT the <u>FDIM</u> . <a href="#">GO to Pinpoint Test L.</a>

**P20 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE APIM DISABLED**

**NOTE:** *When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.*

- Disconnect: SJB Fuse 3 (15A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuse. <a href="#">GO to Pinpoint Test M.</a>
<b>No</b>	INSTALL the removed fuse. GO to <a href="#">P21.</a>

**P21 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE IPC DISABLED**

**NOTE:** *When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.*

- Disconnect: SJB Fuses 26 (10A) and 36 (5A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuses. <a href="#">GO to Pinpoint Test C.</a>
<b>No</b>	CONNECT all modules. The <u>MS-CAN</u> tests within specification. Verify the correct operation of the scan tool on a known good vehicle.

**P22 CHECK FOR CORRECT SJB OPERATION**

- Disconnect all the SJB connectors.
- Check for:
  - corrosion
  - damaged pins

- pushed-out pins
- Connect all the SJB connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>SJB</u> . REFER to <a href="#">Section 419-10</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

**P23 CHECK FOR CORRECT BCM-B OPERATION**

- Disconnect all the BCM-B connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the BCM-B connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>BCM-B</u> . REFER to <a href="#">Section 419-10</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

**P24 CHECK FOR CORRECT FCIM OPERATION**

- Disconnect the FCIM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the FCIM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>FCIM</u> . REFER to <a href="#">Section 415-00</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

**P25 CHECK FOR CORRECT GPSM OPERATION**

- Disconnect the GPSM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the GPSM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>GPSM</u> . REFER to <a href="#">Section 415-00</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
------------	--

<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
-----------	---

## P26 CHECK FOR CORRECT HVAC MODULE OPERATION

- Disconnect all the HVAC module connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the HVAC module connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	INSTALL a new HVAC module. REFER to <a href="#">Section 412-01</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

## P27 CHECK FOR CORRECT FDIM OPERATION

- Disconnect the FDIM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the FDIM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	INSTALL a new <u>FDIM</u> . REFER to <a href="#">Section 415-00</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

## P28 CHECK FOR CORRECT ACM OPERATION

- Disconnect all the ACM connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the ACM connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	INSTALL a new <u>ACM</u> . REFER to <a href="#">Section 415-00</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.


## P29 CHECK FOR CORRECT APIM OPERATION

- Disconnect the APIM connector.
- Check for:

- corrosion
- damaged pins
- pushed-out pins

- Connect the APIM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	 <b>VIN required to access Guided Routine (APIM)</b>
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

**P30 CHECK FOR CORRECT IPC OPERATION**

- Disconnect the IPC connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the IPC connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new <u>IPC</u> . REFER to <a href="#">Section 413-01</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

**Pinpoint Test Q: No High Speed Controller Area Network (HS-CAN) Communication, All Modules Are Not Responding**

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

Refer to Wiring Diagrams Cell [24](#) , 5.0L for schematic and connector information.

Refer to Wiring Diagrams Cell [25](#) , 5.4L for schematic and connector information.

Refer to Wiring Diagrams Cell [26](#) , 3.7L for schematic and connector information.

**Normal Operation**

The High Speed Controller Area Network (HS-CAN) uses an unshielded twisted pair cable, circuits VDB04 (HS-CAN +) and VDB05 (HS-CAN -).

**NOTE:** *The APIM , while on the HS-CAN , communicates with the scan tool only on the Medium Speed Controller Area Network (MS-CAN) .*

**This pinpoint test is intended to diagnose the following:**

- Fuse
- Wiring, terminals or connectors
- ABS module
- Accessory Protocol Interface Module (APIM) (if equipped)
- Engine Temperature Gauge (if equipped)
- Instrument Panel Cluster (IPC)

- Occupant Classification System Module (OCSM)
- Parking Aid Module (PAM)
- PCM
- Power Steering Control Module (PSCM)
- Restraints Control Module (RCM)

**PINPOINT TEST Q : NO HS-CAN COMMUNICATION, ALL MODULES ARE NOT RESPONDING**


**NOTICE:** Use the correct probe adapter(s) when making measurements. Failure to use the correct probe adapter(s) may damage the connector.

**NOTE:** Most faults are due to connector and/or wiring concerns. Carry out a thorough inspection and verification before proceeding with the pinpoint test.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

**Q1 CHECK THE DLC PINS FOR DAMAGE**

- Ignition OFF.
- Inspect DLC pins 6 and 14 for damage.




A0093867

Are DLC pins 6 and 14 OK?

<b>Yes</b>	GO to <a href="#">Q2</a> .
<b>No</b>	REPAIR the <u>DLC</u> as necessary. CLEAR the DTCs. REPEAT the network test with the scan tool.

**Q2 CHECK THE HS-CAN TERMINATION RESISTANCE**

- Disconnect: Negative Battery Cable .
- Measure the resistance between the DLC C251 Pin 6, circuit VDB04 (WH/BU), harness side and the DLC C251 Pin 14, circuit VDB05 (WH), harness side.



N0026427


Is the resistance between 54 and 66 ohms?

<b>Yes</b>	GO to <a href="#">Q3</a> .
<b>No</b>	GO to <a href="#">Q5</a> .

**Q3 CHECK THE HS-CAN (+) AND HS-CAN (-) CIRCUITS FOR A SHORT TO GROUND**

- Measure the resistance between the DLC C251 Pin 6, circuit VDB04 (WH/BU), harness side and ground; and between the DLC C251 Pin 14, circuit VDB05 (WH), harness side and ground.






N0002963

Are the resistances greater than 1,000 ohms?

Yes	CONNECT the negative battery cable. GO to <a href="#">Q4</a> .
No	GO to <a href="#">Q12</a> .

#### Q4 CHECK THE HS-CAN (+) AND HS-CAN (-) CIRCUITS FOR A SHORT TO VOLTAGE

- Ignition ON.
- Measure the voltage between the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side and ground; and between the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side and ground.




N0002964

Is the voltage greater than 6 volts?

Yes	REPAIR the circuit. CLEAR the DTCs. REPEAT the network test with the scan tool.
No	GO to <a href="#">Q13</a> .

#### Q5 CHECK THE HS-CAN TERMINATION RESISTOR

- Measure the resistance between the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.




N0026427

Is the resistance between 108 and 132 ohms?

Yes	GO to <a href="#">Q6</a> .
No	GO to <a href="#">Q9</a> .

### Q6 CHECK THE HS-CAN TERMINATION RESISTOR WITH THE PCM DISCONNECTED

- Disconnect: PCM [C175B](#) or [C1381B](#) .
- Measure the resistance between the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.




Is the resistance between 108 and 132 ohms?


<b>Yes</b>	GO to <a href="#">Q7</a> .
<b>No</b>	GO to <a href="#">Q8</a> .

### Q7 CHECK THE HS-CAN CIRCUITS BETWEEN THE PCM AND THE DLC FOR AN OPEN

- Measure the resistance between the PCM [C175B](#) Pin 59 or [C1381B](#) Pin 59, circuit VDB04 (WH/BU), harness side and the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side.



- Measure the resistance between the PCM [C175B](#) Pin 58 or [C1381B](#) Pin 58, circuit VDB05 (WH), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.




Are the resistances less than 5 ohms?

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">Q21</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

### Q8 CHECK THE HS-CAN CIRCUITS BETWEEN THE IPC AND THE DLC FOR AN OPEN


- Disconnect: [IPC C220](#) .

- Measure the resistance between the [IPC C220](#) Pin 13, circuit VDB04 (WH/BU), harness side and the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side.



N0099861

- Measure the resistance between the [IPC C220](#) Pin 12, circuit VDB05 (WH), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.




N0099862

**Are the resistances less than 5 ohms?**

<b>Yes</b>	CONNECT the negative battery cable. GO to <a href="#">Q26</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.

**Q9 CHECK THE HS-CAN (+) AND HS-CAN (-) CIRCUITS FOR A SHORT TOGETHER**

- Measure the resistance between the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.




N0026427

**Is the resistance less than 5 ohms?**

<b>Yes</b>	GO to <a href="#">Q11</a> .
<b>No</b>	GO to <a href="#">Q10</a> .

**Q10 CHECK THE HS-CAN CIRCUITS FOR AN OPEN AT THE DLC**

- Measure the resistance between the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side and the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side.




N0026427

Is the resistance greater than 10,000 ohms?

<b>Yes</b>	REPAIR the <u>DLC</u> or REPAIR the circuit in question. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	A capacitor internal to a module may still be draining causing irregular resistance readings. WAIT 5 minutes. REPEAT the pinpoint test.

### Q11 CHECK THE HS-CAN (+) AND HS-CAN (-) CIRCUITS FOR A SHORT TOGETHER

- While measuring the resistance between the DLC C251 Pin 6, circuit VDB04 (WH/BU), harness side and the DLC C251 Pin 14, circuit VDB05 (WH), harness side, disconnect the following modules one at a time until the resistance is greater than 5 ohms.
  - APIM C2383 (if equipped)
  - ABS module C135
  - Engine temperature gauge C2460
  - IPC C220 (if equipped)
  - OCSM C3043
  - PAM C4014 (if equipped)
  - PSCM C1463B (if equipped)
  - PCM C175B or C1381B
  - RCM C2041B




N0026427

Did the resistance change to greater than 5 ohms with one of the modules disconnected?

<b>Yes</b>	CONNECT the negative battery cable. For the <u>APIM</u> , GO to <u>Q25</u> . For the ABS module, GO to <u>Q22</u> . For the engine temperature gauge, GO to <u>Q29</u> . For the <u>IPC</u> , GO to <u>Q26</u> . For the <u>OCSM</u> , GO to <u>Q24</u> . For the <u>PAM</u> , GO to <u>Q28</u> . For the <u>PCM</u> , GO to <u>Q21</u> . For the <u>PSCM</u> , GO to <u>Q27</u> . For the <u>RCM</u> , GO to <u>Q23</u> .
<b>No</b>	REPAIR circuits VDB04 (WH/BU) and VDB05 (WH) for being shorted together. CLEAR the DTCs. REPEAT the Network Test with the scan tool.

### Q12 CHECK THE HS-CAN (+) AND HS-CAN (-) CIRCUITS FOR A SHORT TO GROUND WITH THE MODULES DISCONNECTED

- While measuring the resistance between the [DLC C251](#) Pin 6, circuit VDB04 (WH/BU), harness side and ground; and between the [DLC C251](#) Pin 14, circuit VDB05 (WH), harness side and ground, check for the short to ground on both circuits after disconnecting each module. Disconnect the following modules one at a time until the resistance to ground is greater than 1,000 ohms.
  - [APIM C2383](#) (if equipped)
  - ABS module [C135](#)
  - Engine temperature gauge [C2460](#)
  - [IPC C220](#) (if equipped)
  - [OCSM C3043](#)
  - [PAM C4014](#) (if equipped)
  - [PSCM C1463B](#) (if equipped)
  - [PCM C175B](#) or [C1381B](#)
  - [RCM C2041B](#)



N0002963

**Did the resistance change to greater than 1,000 ohms with one of the modules disconnected?**

<b>Yes</b>	CONNECT the negative battery cable. For the <a href="#">APIM</a> , GO to <a href="#">Q25</a> . For the ABS module, GO to <a href="#">Q22</a> . For the engine temperature gauge, GO to <a href="#">Q29</a> . For the <a href="#">IPC</a> , GO to <a href="#">Q26</a> . For the <a href="#">OCSM</a> , GO to <a href="#">Q24</a> . For the <a href="#">PAM</a> , GO to <a href="#">Q28</a> . For the <a href="#">PCM</a> , GO to <a href="#">Q21</a> . For the <a href="#">PSCM</a> , GO to <a href="#">Q27</a> . For the <a href="#">RCM</a> , GO to <a href="#">Q23</a> .
<b>No</b>	REPAIR the circuit in question. CONNECT all modules. CONNECT the negative battery cable. CLEAR the DTCs. REPEAT the Network Test with the scan tool.

### Q13 CHECK FOR RESTORED COMMUNICATION WITH THE PCM DISABLED

**NOTE:** An [IDS](#) session must be established prior to disabling the PCM in this test step. If the PCM has failed communication during multiple attempts to identify the vehicle, first identify the vehicle manually by entering a PCM part number, calibration number or tear tag when prompted by [IDS](#) .

**NOTE:** When a vehicle is manually identified by a PCM part number, calibration number or tear tag, the [IDS](#) will not automatically run a network test. The network test must be manually selected and run.

**NOTE:** When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.

- Disconnect: Battery Junction Box (BJB) Fuses 23 (10A), 45 (5A) and 47 (15A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuses. <a href="#">GO to Pinpoint Test A</a> .
<b>No</b>	INSTALL the removed fuses. GO to <a href="#">Q14</a> .

### Q14 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE ABS MODULE DISABLED

**NOTE:** When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.

- Disconnect: BJB Fuse 34 (5A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuse. <a href="#">GO to Pinpoint Test B.</a>
<b>No</b>	INSTALL the removed fuse. GO to <a href="#">Q15</a> .

#### **Q15 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE IPC DISABLED**

**NOTE:** When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.

- Disconnect: SJB Fuses 26 (10A) and 36 (5A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuses. <a href="#">GO to Pinpoint Test C.</a>
<b>No</b>	INSTALL the removed fuses. GO to <a href="#">Q16</a> .

#### **Q16 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE RCM DISABLED**

**NOTE:** When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.

- Disconnect: SJB Fuse 31 (10A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuse. <a href="#">GO to Pinpoint Test D.</a>
<b>No</b>	INSTALL the removed fuse. If equipped with rear park assist GO to <a href="#">Q17</a> . If not equipped with rear park assist GO to <a href="#">Q18</a> .

#### **Q17 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE PAM DISABLED**

**NOTE:** When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.

- Disconnect: SJB Fuse 32 (10A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuse. <a href="#">GO to Pinpoint Test O.</a>
<b>No</b>	INSTALL the removed fuse. The <u>HS-CAN</u> tests within specification. Verify the correct operation of the scan tool on a known good vehicle.

#### **Q18 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE OCSM DISABLED**

**NOTE:** When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.

- Disconnect: SJB Fuse 46 (7.5A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuse. <a href="#">GO to Pinpoint Test E.</a>
<b>No</b>	INSTALL the removed fuse. If equipped with SYNC®, GO to <a href="#">Q19</a> . If not equipped with SYNC®, GO to <a href="#">Q20</a> .

#### **Q19 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE APIM DISABLED**

**NOTE:** When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.

- Disconnect: SJB Fuse 3 (15A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuse. <a href="#">GO to Pinpoint Test M.</a>
<b>No</b>	INSTALL the removed fuse. GO to <a href="#">Q20</a> .

#### **Q20 CHECK FOR RESTORED NETWORK COMMUNICATION WITH THE PSCM DISABLED**

**NOTE:** When re-running the network test, the network test application must be closed first or the screen display reverts back to the prior run network test results.

- Disconnect: BJB Fuse 45 (5A) .
- Enter the following diagnostic mode on the scan tool: Network Test .
- Repeat the network test.

**Do all other modules pass the network test?**

<b>Yes</b>	INSTALL the removed fuse. <a href="#">GO to Pinpoint Test N.</a>
<b>No</b>	CONNECT all modules. The <u>HS-CAN</u> tests within specification. Verify the correct operation of the scan tool on a known good vehicle.

#### **Q21 CHECK FOR CORRECT PCM OPERATION**

- Disconnect all the PCM connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the PCM connectors and make sure they seat correctly.
- Operate the system and verify the concern is still present.

**Is the concern still present?**

<b>Yes</b>	INSTALL a new PCM. REFER to <a href="#">Section 303-14</a> . CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	REPAIR the circuit. CLEAR the DTCs. REPEAT the network test with the scan tool.

## Q22 CHECK FOR CORRECT ABS MODULE OPERATION

- Disconnect the ABS module connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the ABS module connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	INSTALL a new ABS module. REFER to <a href="#">Section 206-09</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

## Q23 CHECK FOR CORRECT RCM OPERATION

- Disconnect all the RCM connectors.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect all the RCM connectors and make sure they seat correctly.
- Verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	INSTALL a new <u>RCM</u> . REFER to <a href="#">Section 501-20B</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

## Q24 CHECK FOR CORRECT OCSM OPERATION

- Disconnect the OCSM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the OCSM connector and make sure it seats correctly.
- Verify the concern is still present.

### Is the concern still present?


<b>Yes</b>	INSTALL a new <u>OCSM</u> . REFER to <a href="#">Section 501-20B</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

## Q25 CHECK FOR CORRECT APIM OPERATION

- Disconnect the APIM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the APIM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.



### Is the concern still present?

<b>Yes</b>	 <b>VIN required to access Guided Routine (APIM)</b>
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

### Q26 CHECK FOR CORRECT IPC OPERATION

- Disconnect the IPC connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the IPC connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	INSTALL a new <u>IPC</u> . REFER to <a href="#">Section 413-01</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

### Q27 CHECK FOR CORRECT PSCM OPERATION

- Disconnect the PSCM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the PSCM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	INSTALL a new <u>PSCM</u> . REFER to Steering Gear in <a href="#">Section 211-02</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

### Q28 CHECK FOR CORRECT PAM OPERATION

- Disconnect the PAM connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the PAM connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	INSTALL a new <u>PAM</u> . REFER to <a href="#">Section 413-13</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
------------	---

<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
-----------	---

## Q29 CHECK FOR CORRECT ENGINE TEMPERATURE GAUGE OPERATION

- Disconnect the engine temperature gauge connector.
- Check for:
  - corrosion
  - damaged pins
  - pushed-out pins
- Connect the engine temperature gauge connector and make sure it seats correctly.
- Operate the system and verify the concern is still present.

### Is the concern still present?

<b>Yes</b>	INSTALL a new engine temperature gauge. REFER to <a href="#">Section 413-01</a> . CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.
<b>No</b>	The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector. CONNECT all modules. CLEAR the DTCs. REPEAT the network test with the scan tool.

## Pinpoint Test R: No Power To The Scan Tool

Refer to Wiring Diagrams Cell [14](#) , Module Communications Network for schematic and connector information.

### Normal Operation

The scan tool is connected to the Data Link Connector (DLC) to communicate with the High Speed Controller Area Network (HS-CAN) and Medium Speed Controller Area Network (MS-CAN) .

A loss of ground or poor ground at the DLC may result in HS-CAN or MS-CAN faults while the scan tool is connected. This may cause multiple malfunction indicators to be on with the scan tool connected to the DLC .

### This pinpoint test is intended to diagnose the following:

- Fuse
- Wiring, terminals or connectors
- Scan tool
- DLC


## PINPOINT TEST R : NO POWER TO THE SCAN TOOL

**NOTE:** Most faults are due to connector and/or wiring concerns. Carry out a thorough inspection and verification before proceeding with the pinpoint test.

**NOTE:** Failure to disconnect the battery when instructed results in false resistance readings. Refer to [Section 414-01](#).

### R1 CHECK THE DLC PINS FOR DAMAGE

- Disconnect the scan tool cable from the DLC .
- Inspect DLC pins 4, 5 and 16 for damage.




Are **DLC** pins 4, 5 and 16 OK?

<b>Yes</b>	GO to <a href="#">R2</a> .
<b>No</b>	REPAIR the <b>DLC</b> as necessary. CLEAR the DTCs. REPEAT the network test with the scan tool.

**R2 CHECK THE DLC VOLTAGE SUPPLY CIRCUIT FOR AN OPEN**

- Measure the voltage between the **DLC** [C251](#) Pin 16, circuit SBP20 (GN/RD), harness side and ground.




Is the voltage greater than 10 volts?

<b>Yes</b>	GO to <a href="#">R3</a> .
<b>No</b>	VERIFY the Smart Junction Box (SJB) fuse 20 (15A) is OK. If OK, REPAIR the circuit. If not OK, REFER to the Wiring Diagrams manual to identify the possible causes of the circuit short. REPEAT the network test with the scan tool.

**R3 CHECK THE DLC GROUND CIRCUITS FOR AN OPEN**

- Disconnect: Negative Battery Cable .
- Measure the resistance between the **DLC** [C251](#) Pin 4, circuit GD114 (BK/BU), harness side and ground; and between the **DLC** [C251](#) Pin 5, circuit GD119 (BK/BU), harness side and ground.



Are the resistances less than 5 ohms?

<b>Yes</b>	REPAIR the scan tool. CONNECT the negative battery cable. REPEAT the network test with the scan tool.
<b>No</b>	REPAIR the circuit in question. CONNECT the negative battery cable. REPEAT the network test with the scan tool.

