Audio System

Error Message	Potential Effects	Recommended Action
SiriusXM Updating	Audio may mute.	Allow SiriusXM some time to complete updating.
Loading	Audio may mute. Content may be temporarily unavail- able while loading.	No action necessary. If loading time is longer than usual, See Satellite Radio Settings (page 393).
SiriusXM Loading	Audio may mute. Content and controls may be temporarily unavailable.	No action necessary. Allow SiriusXM some time to finish loading.

Center Display Overview

CENTER DISPLAY PRECAUTIONS

warning: Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.

CENTER DISPLAY LIMITATIONS

Speed-restricted Features

For your safety, features that are not critical while driving are not available when the vehicle is moving at or above 5 mph (8 km/h).

STATUS BAR

The bar is on top of the display and indicates the status of your vehicle's features.

Audio System



Audio system muted.

Connected Device



Cell phone microphone muted.



Phone call in progress.



Media player connected using **Bluetooth**®.



Cell phone network signal strength.



Cell phone roaming.



Text message received.



Unread email message.



Automatic crash notification system off.



Cell phone battery status.

Vehicle Data



Wi-Fi available.



Wi-Fi connected.



Vehicle data sharing on.



Vehicle data sharing off.



Vehicle location sharing on.



Vehicle data and vehicle location sharing on.

Center Display Overview

Vehicle Software Update

See **Software Update Indicators** (page 428).

Wireless Accessory Charger



Wireless accessory charger active.

HOME SCREEN

Features, such as navigation, audio and phone, are located in the main portion of the display. The icons located on the side of the display allow you to access other vehicle features and settings.



Press to adjust system settings.



Press to view features.

Note: The icon may be different depending on your vehicle.



Press to search for and use compatible apps on your iOS or Android device.

FAVORITE



Press the button on the instrument panel to turn a feature on or off.

Assigning a Feature

If there is no feature assigned:

- Press the button on the instrument panel.
- 2. Follow the prompts on the touchscreen.

To change the assigned feature:

- Press Features on the touchscreen.
- 2. Press Edit Favorite.

Note: If you assign an exhaust mode to the favorite button, pressing the button activates the exhaust mode, and pressing it again restores the previous exhaust mode.

INFORMATION ON DEMAND SCREEN

The information on demand screen displays cards on the side of the display and allows you to see information from different features.

You can swipe up or down to view a different card.

Note: On some screens, you can swipe a card toward the center of the screen to move the content into the main screen.

CENTER DISPLAY SETTINGS

Adjusting the Display Brightness

- 1. Press **Settings** on the touchscreen.
- 2. Press **Center Display**.
- 3. Press **Brightness**.
- 4. Drag the slider left or right.

Valet Mode

Valet mode allows you to lock the system. No information is accessible until the system is unlocked with the correct PIN.

When you select valet mode, a pop up appears informing you that a four digit PIN must be entered to enable and disable valet mode. You can use any PIN you choose, but you must use the same PIN to disable valet mode. The system asks you to input the code.

Center Display Overview

Note: If the system is locked and you cannot remember the PIN, please contact the customer relationship center.

To enable valet mode, enter your chosen PIN. The system then asks to confirm your PIN by reentering it. The system then locks.

To unlock the system, enter the same PIN. The system reconnects to your phone and all of your options are available again.

REBOOTING THE CENTER DISPLAY

You can reboot the center display using the controls on the steering wheel.

1. Simultaneously press and hold the seek forward and audio system power button for 10 seconds.

MY MUSTANG OVERVIEW



Press the button on the instrument panel.



- A Track apps.
- B Auxiliary gauges.
- C Custom mode.
- D My color.
- E Cluster theme.
- F Exhaust mode. See **Selecting a Drive Mode** (page 226).

TRACK APPS

TRACK APPS PRECAUTIONS

WARNING: *Track Apps™* is for track use only. Remember that even advanced technology cannot defy the laws of physics. It is always possible to lose control of a vehicle due to inappropriate driver input for the conditions. Aggressive driving on any road condition can cause you to lose

control of your vehicle increasing the risk of personal injury or property damage.


Note: Track apps are for track use only. Do not use them under any other driving conditions.


Note: The pre-collision assist system turns off when using Track apps or when you switch off your stability control system.

TRACK APPS OVERVIEW

From the My Mustang menu, press **Track Apps**.







- A Acceleration timer.
- B Brake performance.
- C Lap timer.
- D Launch settings.

- E Performance shift indicator.
- F Drift brake.
- G Line lock.
- H Launch control.
- I Rev match.

ACCELERATION TIMER

Displays your vehicle's rate of acceleration for a given speed or distance range.

Note: Test events vary depending on the measurement unit conventions selected.

Using Acceleration Timer

- 1. From the Track Apps menu, press **Acceleration Timer**.
- 2. Select a drive type.
- 3. Select a start type.
- 4. Press **Start**.

Note: The start button is not available until a drive type and start type are selected.

5. Press the OK button on the steering wheel to start the timer.

When finished, press OK for more options.

Results

To view your timer results:

1. From the acceleration timer menu, press **Results**.

To clear results without clearing all-time best:

- 1. Press Clear.
- 2. Press **Yes**.

To clear all results.

- 1. Press Clear All.
- 2. Press Yes.

BRAKE PERFORMANCE

Displays your vehicle's rate of deceleration for a given speed range.

Note: Test events vary depending on the measurement unit conventions selected.

Using Brake Performance

- 1. From the Track Apps menu, press **Brake Performance**.
- 2. Select a speed range.
- 3. Press **Start**.
- 4. Press the OK button on the steering wheel.

When finished, press OK for more options.

Results

To view your results:

 From the brake performance menu, press **Results**.

To clear results without clearing all-time best:

- 1. Press Clear.
- 2. Press **Yes**.

To clear all results.

- 1. Press Clear All.
- 2. Press Yes.

MANUAL LAP TIMER

Gives you the ability to record lap times at three separate tracks.

Note: Test events vary depending on the measurement unit conventions selected.

Using Lap Timer

- From the Track Apps menu, press Lap Timer.
- 2. Select a track.

Note: You can edit the track names.

- 3. Press Start.
- 4. Press the OK button on the steering wheel.

Note: You can interrupt a session at any time by holding the OK button on the steering wheel.

When finished, press OK for more options.

Results

To view your results:

1. From the lap timer menu, press **Results**.

To clear results without clearing all-time best:

- 1. Press Clear.
- 2. Press **Yes**.


To clear all results.

- 1. Press Clear All.
- 2. Press **Yes**.

PERFORMANCE SHIFT INDICATOR - MANUAL TRANSMISSION

The performance shift indicator allows you to set the point at which you want to be alerted to shift gears, through audible and visual alerts. You can choose different graphic themes that represent the engine's rotation.

From the Track Apps menu, press
 Performance Shift Indicator to reach the menu.



- 2. From the menu, you can:
- Set the light mode between off, tach, track and drag.
- Set a shift point within the allowable RPM range in increments of 100.
- Enable or disable the shift tone, based on the set shift point.

Note: To enable or disable the feature, you must choose a light mode.

LINE LOCK

Line lock maintains brake force at the front wheels, allowing the rear wheels to spin with minimal vehicle movement. It is intended to condition the rear tires to maximize traction prior to track use.

Note: Line lock is a feature intended for use at tracks only and should not be used on public roadways.

Note: Use of this feature could result in significantly increased rear tire wear.

There are three line lock stages:

- Initiated.
- Engaged.
- Off.

Initiating Line Lock

The initiation stage verifies that the vehicle is ready for line lock function, and confirms driver intent.

 From the track apps menu, press Line Lock.

The following conditions must be met to initialize line lock:

- The vehicle is on a level surface.
- The engine is running.
- The vehicle is traveling less than 25 mph (40 km/h).
- Selectable drive mode is not in wet mode (if equipped).
- There are no electronic stability control faults.
- A spare tire is not installed.
- The parking brake is not applied.
- Auto hold is turned off.
- Adaptive cruise control is not active.
- Both doors are closed.

If you want to cancel line lock once it is initialized, press the OK button on the steering wheel. Once initiated, line lock is prepared for activation and remains initiated up to 25 mph (40 km/h). If vehicle speed exceeds 25 mph (40 km/h), line lock automatically cancels.

Engaging Line Lock

Follow the prompts in the instrument cluster display to engage line lock after it is initialized. To engage, firmly apply the brakes. Then press the OK button. Once engaged, release the brake pedal. The front brakes remain applied and the rear brakes release. At this point, the engagement timer is initiated and shown on the instrument cluster display.

The following conditions must be met to engage line lock:

- The vehicle is on a level surface.
- The engine is running.
- The vehicle is stopped.
- The parking brake is not applied.
- Both doors are closed.
- The transmission is in a forward gear.
- There are no electronic stability control faults.
- The steering wheel is in the straight ahead position.
- A spare tire is not installed.
- Auto hold is turned off.
- Adaptive cruise control is not active.

Releasing Line Lock

While line lock is engaged, you can exit (release) the feature using the OK button. When you press the OK button, line lock releases immediately and normal vehicle function resumes. When line lock engages, a countdown timer shows the remaining time before line lock is released automatically. If you exceed the time limit, or another vehicle condition requires line lock to release, the system safely disengages and normal vehicle function resumes.

Note: If you apply the brake pedal or parking brake while line lock is engaged, line lock automatically cancels and normal brake function resumes.

REV MATCH - MANUAL TRANSMISSION

This feature provides a smoother driving experience, particularly during a downshift event. Rev Match commands a quick engine RPM match to the selected gear during a clutch pressed gear shift. You can switch this feature on and off through the touchscreen.

LAUNCH CONTROL - MANUAL TRANSMISSION

Temporarily holds the engine RPM at a set point and maximizes traction to the wheels for a more aggressive start.

Enabling or Disabling Launch Control

 From the Track Apps menu, press Launch Control.

To set the RPM hold point:

1. From the Track Apps menu, press **Launch Settings**.

Note: You can also enable or disable the feature from this screen.



2. Use the slider bar or arrows to set the RPM value.

Using Launch Control

- 1. Make sure launch control is enabled.
- 2. Bring your vehicle to a complete stop.
- 3. The indicator illuminates white in the instrument cluster when launch control is ready.
- 4. Fully press and hold the clutch pedal.

- 5. Shift the transmission into first gear.
- 6. Fully press the accelerator pedal and keep it pressed. Allow the tachometer to settle at the RPM that you selected and wait for the indicator to turn green.
- 7. Release the clutch pedal.

Improving Your Launch

If launch control is not available when you come to a stop:

- Wait for the engine to come to operating temperature. If the engine is too hot or cold, launch control is not available.
- Make sure the drive mode is not set to Slippery.

If the vehicle did not launch effectively:

- Adjust the RPM and practice releasing the clutch. It may take practice to get a feel for how quickly to release the clutch.
- Switch traction control on, this can reduce excessive wheel spin.

Keep in mind that weather, road surface, and tire conditions can also affect your launch.

Launch Control Indicators

With Traction Control Off



Not ready.



Ready to use.



Active and ready to launch.

With Traction Control On



Not ready.



Ready to use.



Active and ready to launch.

DRIFT BRAKE (If Equipped)



Allows you to lock up the rear tires to enable drift maneuvers.

Before drifting, make sure you are on a track, and have the necessary safety equipment including a certified helmet and approved neck restraint device. Work up to your limit while drifting, do not expect to be an expert right away.

Note: *Drift brake is for track use only. Do not use it under any other driving conditions.*

Note: Using this feature may result in significantly increased rear tire wear.

Switching Drift Brake On or Off

- 1. From the Track Apps menu, press **Drift Brake**.
- 2. Confirm the selection. This enables track mode.

Note: If track mode is already enabled, there is no confirmation message.

Note: Switching drift brake on automatically enables track mode. If you change to a different drive mode, drift brake disables.

3. Press **Drift Brake** again to switch it off.

Note: When you switch drift brake off, track mode remains on.

Note: When the feature is on, the brake handle applies braking to the rear wheels only and locks up the rear wheels. When the feature is off, the brake handle works like the foot brake and applies braking to all four wheels.

Note: The system may exit track mode if it reaches certain threshold limits. If this happens, Drive Mode Not Available or Service AdvanceTrac messages display in the instrument cluster display screen. You can reset the system by switching your vehicle off and back on, driving normally up to 15 minutes and reaching 45 mph (73 km/h). After the system is re-calibrated, drive modes will be available through the button on the steering wheel.

Drift Brake Driving Hints - Vehicles with: Automatic Transmission

Two important things to note when driving a vehicle with an automatic transmission:

- Keep the RPM high when drifting to prevent unintentional engine stall. The engine RPM drops rapidly when locking the rear wheels, so it is best to be on the throttle prior to and after pulling the handle to prevent stalling.
- Using the paddle shifters or manual shift mode enhances your ability to keep the vehicle in the power band. This way when you release the drift brake you can quickly get back on the throttle and maintain your drift.

As your drifting skills develop, it may be beneficial to turn off other vehicle control systems such as traction control and electronic stability control. See **Traction Control** (page 197). See **Stability Control** (page 198). Before returning to public roads, re-enable both systems.

Drift Brake Driving Hints-Vehicles with: Manual Transmission

Drifting in a manual transmission gives you more control over the chosen gear, which allows you to make sure you have correct application of power to maintain the drift.

Two things to note while drifting in a manual transmission vehicle:

- Make sure to disengage the clutch immediately prior to pulling the drift brake. This prevents fighting engine torque and prevents unintended stalls.
- After releasing the drift brake, rapidly engage the clutch and get back on the throttle to maintain your drift.

As your drifting skills develop, it may be beneficial to turn off other vehicle control systems such as traction control and electronic stability control. See **Traction Control** (page 197). See **Stability Control** (page 198). Before returning to public roads, re-enable both systems.

AUXILIARY GAUGES



Auxiliary gauges are available in the touchscreen.

From the My Mustang menu, press **Auxiliary Gauges**.



Press the button to switch between three or five-gauge view.



To edit the gauges:

1. **=**

Press the button.

2. Use the arrows on the screen to select the gauges you prefer.

Auxiliary gauges:

- Cylinder head temperature.
- Engine oil temperature.
- Transmission oil temperature.
- Axle temperature.
- Engine oil pressure.
- Inlet air temperature.
- Manifold charge temperature.
- Intercooler coolant temperature.
- Vacuum or vacuum/boost.
- Voltage.

Note: Depending on your vehicle configuration, not all gauges are available.

CUSTOM DRIVE MODE

Allows you to create your own drive mode experience. Choose a drive mode to use as a starting point and then mix and match settings to tailor the experience to your preferences. You can create up to six custom modes.



You can set one of the six custom modes as the active mode. The active mode appears

as an available mode when selecting a drive mode. See **Selecting a Drive Mode** (page 226).

Creating a Drive Mode



- A Profile selection.
- B Base drive mode.
- C Adjustable settings.
- 1. From the My Mustang menu, press **Custom Drive Mode**.
- 2. Press the profile button to select a profile to edit.

Note: Selecting a profile also sets it as the active mode.

- 3. Select the base drive mode you prefer.
- 4. Press each option and select the setting you prefer.

CLUSTER THEME



You can change the style of the display behind the steering

- 1. From the My Mustang menu, press **Cluster Theme**.
- 2. Select a theme.

Note: If you choose **Match Drive Mode**, the instrument cluster style changes according to the drive mode you select.

MY COLOR



Allows you to customize the colors of the instrument cluster and touchscreen.

You can also adjust the ambient lighting. See **Ambient Lighting** (page 101).

- 1. From the My Mustang menu, press **MyColor**.
- 2. Adjust the primary and secondary colors to the setting you prefer.

EXHAUST MODE (IF EQUIPPED)

Allows you to change how loud your exhaust is. You can choose from one of four settings.

Quiet Mode



Lowers the noise of the exhaust.

Quiet Start

Minimizes exhaust noise when you start the vehicle. You can set a schedule for when you want quiet start to be on.

To access the quiet start menu:

- 1. Press **Settings** on the touchscreen.
- 2. Press **Vehicle**.
- 3. Press Quiet Start.

From the menu, you can do the following:

- Switch guiet start on or off.
- Set the schedule.

Normal Mode



Default factory setting.

Sport Mode



Raises the noise of the exhaust.

Track Mode



Loudest level of exhaust noise.

Note: The track exhaust mode setting is only for use at tracks and not for use on public roadways. Use of this setting results in increased exterior noise, which may not meet state and local laws and regulations. It is the obligation of the driver to operate the vehicle in a manner that complies with state and local requirements. Only use the track exhaust mode setting at a competition track or an off-road course where increased exterior vehicle noise is acceptable.

Voice Interaction

FORD ASSISTANT

USING FORD ASSISTANT

The digital assistant allows you to control vehicle features using conversational requests.

To begin a voice interaction using the wake word, say the selected wake word, then say your command.



Press the voice interaction button on the steering wheel. A tone sounds before you can say

your command.

Note: You may need to enable your vehicle's modem to use certain voice commands. See **Enabling and Disabling the Modem** (page 383).

Note: When you are not driving, additional commands are available by using popular chat applications. Use FordPass to setup a conversation with your Ford assistant.

Voice Command Examples

To see examples of what voice commands you can use with different features:



Press the button on the touchscreen.

- 1. Press **Ford Assistant**.
- 2. Press Voice Command Help.
- 3. Select a feature.

FORD ASSISTANT SETTINGS

To access the settings menu:



Press the button on the touchscreen.

Press Ford Assistant.

From the settings menu you can do the following:

- Switch listen for wake word on or off.
- Set the preferred wake word.
- Switch advance mode on or off.
- Switch phone confirmation on or off.
- Switch the commands list on or off.
- View the commands help menu.



Press the button next to a menu option for more information.

FORD ASSISTANT – FREQUENTLY ASKED QUESTIONS

Why does the system not understand what I am saying?

You are speaking too soon. When using the button of the steering wheel, wait for the tone before you speak.

Why does the system not understand the name of a track or artist?

- Bluetooth® does not support voice commands.Connect your device to a USB port.
- You are not saying the name exactly as it appears on your device. Say the name of the track or artist exactly as it appears on your device. Spell out any abbreviations in the name.
- The system does not recognize some special characters contained in the name of a song or artist, for example
 *, - or +. Rename the files on your device or use the touchscreen to select and play the track.

Voice Interaction

Why does the system not understand the name of a contact in the phonebook on my device and calls the wrong contact?

- You are not saying the name exactly as it appears on your device. Say the first and last name of the contact exactly as it appears on your device. Spell out any abbreviations in the name.
- The name contains special characters, for example *, - or +. Rename the contact on your device or use the touchscreen to select and call the contact.

Why does the system not understand foreign names of contacts in the phonebook on my device?

The system applies phonetic pronunciation rules of the selected language to the names of contacts in the phonebook on your device. Select the name of the contact on the touchscreen and use the Hear it option to get an idea of how the system expects you to pronounce it.

Why do the system voice prompts and the pronunciation of some words not seem accurate?

 The system uses text-to-speech technology and a synthetically generated voice rather than a pre-recorded human voice.

Alexa Built-In

WHAT IS ALEXA BUILT-IN

Allows you to use Alexa in your vehicle for auto-specific use cases on the road and gives you access to an ever-evolving number of skills that help to make your life more productive, entertaining, and connected while using your vehicle.

ALEXA BUILT-IN REQUIREMENTS

To use Alexa, all of the following must occur:

- Your vehicle modem is enabled.
- You are signed in to an existing Amazon account.
- Vehicle location services are enabled.
- Vehicle connectivity and vehicle data sharing is enabled.

SIGNING IN TO YOUR ACCOUNT



Press the button in the status bar and follow the on-screen prompts.

To sign in using the settings menu:

- 1. Press **Settings** on the touchscreen.
- 2. Press **Amazon Alexa**.
- 3. Press *Get Started*.
- 4. Sign in to your account by either scanning the QR code or entering the on-screen code into the Amazon website.
- 5. Once signed in, follow the on-screen prompts.
- 6. When complete, the vehicle informs you that Alexa is ready to be used in the vehicle.

Signing Out of Your Account

- 1. Press **Settings** on the touchscreen.
- 2. Press **Amazon Alexa**.
- 3. Press Sign Out.

USING ALEXA BUILT-IN

To use Alexa, say "Alexa" or press the voice interaction button on the steering wheel and then say "Alexa" to invoke Alexa to start listening.

Note: If the wake word is not enabled, you can only use the voice interaction button.

You can use Alexa for the following and more:

- Entertainment.
- Hands-free calling.
- Traffic and navigation.
- Vehicle controls.
- Smart home device control.
- Weather and news information.

ALEXA BUILT-IN SETTINGS

Enabling the Wake Word

- Press Settings on the touchscreen.
- 2. Press **Amazon Alexa**.
- 3. Switch *Listen for Wake Word* on or off.

Note: If the wake word is not enabled, you can only use the voice interaction button.

Contact List

Displays a list of connected phones and contact sharing status for each phone.

To change the contact sharing status:

- 1. Press **Settings** on the touchscreen.
- 2. Press **Amazon Alexa**.
- 3. Press Contact List.

Alexa Built-In

4. Enable or disable sharing for each phone.

Note: You can share contacts from more than one phone at a time.

Things to Try

Learn more about what you can do with Alexa by browsing the things to try.

- 1. Press **Settings** on the touchscreen.
- 2. Press **Amazon Alexa**.
- 3. Press *Things to Try*.

PHONE PRECAUTIONS

warning: Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.

CONNECTING YOUR PHONE

Go to the settings menu on your device and switch **Bluetooth**® on.



Press the phone option on the home screen.

1. Press **Add Phone**.

Note: A prompt alerts you to search for your vehicle on your cell phone.

2. Select your vehicle on your cell phone.

Note: A number appears on your cell phone and on the touchscreen.

3. Confirm the number on your cell phone matches the number on the touchscreen.

Note: The touchscreen indicates that you have successfully paired your cell phone.

4. Download the phonebook from your cell phone when you are prompted.

Note: If you pair more than one cell phone, use the phone settings on the center display to specify the primary phone. You can change this setting at any time.

PHONE MENU

This menu becomes available after pairing a phone.

Recent Call List

Display and select an entry from a list of previous calls.

Contacts

Display a smart search form to look up your contacts. Use the List button to alphabetically sort your contacts.

Favorites

Display the list of favorite contacts that are set up on your phone.

Messaging

Displays the list of text messages to read, listen to, or respond to.

Email

Displays the list of emails to read, listen to, or respond to.

Phone List

Display the list of paired or connected devices that you can select.

Note: Up to 12 devices can be stored.

Do Not Disturb

Reject incoming calls and switch ring tones and alerts off.

Phone Keypad

Directly dial a number.

Voice Control

Press the button and say a command to use the Google or Siri voice assistant available on your connected phone to access supported features.

Note: Some features under the phone menu may not be available if the feature is not supported through the phone.

MAKING AND RECEIVING A PHONE CALL

Making Calls

To call a number in your contacts, select:

Menu Item	Action and Description
Contacts	You can then select the name of the contact you want to call. Any numbers stored for that contact display along with any stored contact photos. You can then select the number that you want to call. The system begins the call.

To call a number from your recent calls, select:

Menu Item	Action and Description
Recent Call List	You can then select an entry that you want to call. The system begins the call.

To call a number from your favorites, select:

Menu Item	Action and Description
Favorites	You can then select an entry that you want to call. The system begins the call.

To call a number that is not stored in your phone, select:

Menu Item	Action and Description
Phone Keypad	Select the digits of the number you wish to call.
Call	The system begins the call.

Pressing the backspace button deletes the last digit you typed.

Receiving Calls

During an incoming call, an audible tone sounds. Caller information appears in the display if it is available.

To accept the call, select:

	Menu Item	
Accept		

Note: You can also accept the call by pressing the phone button on the steering wheel.

To reject the call, select:

	Menu Item
Reject	

Ignore the call by doing nothing. The system logs it as a missed call.

During a Phone Call

During a phone call, the contacts name and number display on the screen along with the call duration.

The phone status items are also visible:

- Signal Strength.
- Battery.

You can select any of the following during an active phone call:

Item	
End Call	Immediately end a phone call. You can also press the button on the steering wheel.
Keypad	Press this to access the phone keypad.

Item	
Mute	You can switch the microphone off so the caller does not hear you.
Privacy	Transfer the phone call audio to the cell phone or back to the touchscreen.

SENDING AND RECEIVING A TEXT MESSAGE

Menu Item	Description
Hear It	Hear the text message.
View	View the text message.
Call	Call the sender.
Reply	Reply to the text message with a standard text message.

SWITCHING TEXT MESSAGE NOTIFICATION ON AND OFF

The settings on your device must be enabled to receive text message notifications on the center display. Check your device settings to enable these features.

Bluetooth®

CONNECTING A BLUETOOTH® DEVICE

- 1. Make sure **Bluetooth**® is enabled on your device.
- 2. Press **Settings** on the touchscreen.
- 3. Press Connectivity.
- 4. Press **Bluetooth**.
- 5. Press **Add a Bluetooth Device**.

Note: A prompt alerts you to search for your vehicle on your device.

6. Select your vehicle on your device.

Note: A number appears on your device and on the touchscreen.

7. Confirm that the number on your device matches the number on the touchscreen.

Note: The touchscreen indicates that you have successfully paired your device.

The **Bluetooth**® word mark and logos are registered trademarks owned by **Bluetooth SIG, Inc.** and any use of such marks by Ford Motor Company is under license. Other trademarks and trade names are those of their respective owners.

PLAYING MEDIA USING BLUETOOTH®

warning: Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any

hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.

Connect your device.



Press the audio button on the home screen.



Press **Sources**.



Press the **Bluetooth®** option.



Press to play a track. Press again to pause the track.



Press to skip to the next track. Press and hold to fast forward through the track.



Press once to return to the beginning of a track. Repeatedly press to return to previous

tracks.

Press and hold to fast rewind through the track.

APP PRECAUTIONS

warning: Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.

APP REQUIREMENTS

When you start an app through the system for the first time, you could be asked to grant certain permissions. You can review and change the permissions that you have granted at any time when your vehicle is not moving. We recommend that you check your data plan before using your apps through the system. Using them could result in additional charges. We also recommend that you check the app provider's terms and conditions and privacy policy before using their app. Make sure that you have an active account for apps that you want to use through the system. Some apps will work with no setup. Others require you to configure some personal settings before you can use them.

ACCESSING APPS



Select the apps option on the home screen.

ENABLING APPS ON AN IOS DEVICE



Select the apps option on the home screen.

- 1. Select Mobile Apps Help.
- 2. Follow the instructions to pair and connect your device via *Bluetooth*® or with a USB cable.
- 3. Start the apps on your device that you want to use.
- 4. Select the app that you want to use on the touchscreen.

Note: Some apps may run through Apple CarPlay if it is enabled.

Note: Closing an app on your device closes it on the touchscreen.

Note: For troubleshooting assistance select Mobile Apps List under Mobile Apps Help.

ENABLING APPS ON AN ANDROID DEVICE



Select the apps option on the home screen.

- 1. Select Mobile Apps Help.
- Follow the instructions to pair and connect your device via *Bluetooth*® or with a USB cable.
- 3. Start the apps on your device that you want to use.
- 4. Select *Find Mobile Apps*.
- 5. Select the app that you want to use on the touchscreen.

Note: Some devices may lose the ability to play music over USB when Mobile Apps are enabled.

Note: Some apps may run through Android Auto if it is enabled.

Apps

Note: Closing an app on your device closes it on the touchscreen.

Note: For troubleshooting assistance select Mobile Apps List under Mobile Apps Help.

SWITCHING APPLE CARPLAY ON AND OFF

Enabling Apple CarPlay with USB

- 1. Connect your device to a USB port.
- 2. Follow the instructions on your device and the touchscreen.

Note: Selecting Enable Wireless CarPlay on your device prepares the device for wireless Apple CarPlay when you re-enter the vehicle.

Enabling Apple CarPlay with Wireless

- 1. Pair your device to **Bluetooth**®.
- 2. Follow the instructions on your device and the touchscreen.

Disabling Apple CarPlay



Select the settings option on the home screen.

- 1. Press Phone List.
- 2. Select your device from the list.
- 3. Press Disable.

Re-Enabling Apple CarPlay



Select the settings option on the home screen.

- 1. Press Phone List.
- 2. Select your device from the list.
- 3. Press Connect to Apple CarPlay.

SWITCHING ANDROID AUTO ON AND OFF

Enabling Android Auto with USB (If Equipped)

- 1. Connect your device to a USB port.
- 2. Follow the instructions on the touchscreen.

Note: Certain features of the system are not available when you are using Android Auto.

Enabling Android Auto with Wireless

- 1. Pair your device to **Bluetooth**®.
- 2. Follow the instructions on your device and the touchscreen.

Note: Certain Android devices do not support Android Auto Wireless. Check your Android OS version for compatibility.

Disabling Android Auto



Select the settings option on the home screen.

- 1. Press Phone List.
- 2. Select your device from the list.
- Press Disable.

Re-Enabling Android Auto



Select the settings option on the home screen.

- 1. Press Phone List.
- 2. Select your device from the list.
- 3. Press Connect to Android Auto.

Personal Profiles

HOW DO PERSONAL PROFILES WORK

This feature allows you to create multiple personal profiles enabling users to personalize vehicle's settings such as seats and mirrors, as well as non-positional settings like radio, navigation and driver assist. Positional settings are saved by holding a memory seat button. Non-positional settings are saved when you change a setting while a profile is active. You can create one profile for each preset memory seat button along with a guest profile.

Recalling and Changing a Profile

You can recall a profile using the touchscreen or the preset button you selected when you created your profile. You can also link a remote control and a mobile device to your profile, to recall the profile.

ENABLING OR DISABLING PERSONAL PROFILES

When you switch on the Personal Profiles feature:

- Unlocking a door with a remote control or mobile device that is not linked to a driver profile does not change the active profile, but remains in the last known profile. It does not change the positional settings.
- Pressing a memory seat button that is not linked to a driver profile or saved to a preset setting does not change the active profile, but remains in the last known profile. It does not change the positional settings.
- Pressing a memory seat button that is not linked to a driver profile but is saved to a preset setting does not change the active profile, but remains in the last known profile. It recalls the positional settings that you saved to that memory seat button.

When you switch off a Personal Profiles feature:

- Unlocking a door with a remote control or mobile device does not recall any non-positional settings but still recalls positional settings from the driver profile which the remote control or mobile device is linked to.
- Pressing a memory seat button that is not linked to a driver profile or saved to a preset setting does not change the positional or non-positional settings.
- Pressing a memory seat button that is linked to a driver profile or has saved to a preset setting recalls the positional settings that you saved to that memory seat button.

Personal Profiles

CREATING A PERSONAL PROFILE

Use the touchscreen to create a personal profile.

- 1. Switch the vehicle on and leave the vehicle in park (P).
- 2. Select the Personal Profiles button under Settings.
- 3. Follow the instructions on the display.

LINKING OR UNLINKING A PERSONAL PROFILE TO A REMOTE CONTROL

You can save Personal Profiles, including preset memory positions, for up to three remote controls by assigning a remote control to a personal profile using the touchscreen.

Use the touchscreen to link a remote control to a personal profile.

- 1. Switch the vehicle on and leave the vehicle in park (P).
- Select Personal Profiles under Settings.
- 3. Touch the arrow for the profile you want to link to a remote control.
- 4. Select remote control.
- 5. Follow the instructions on the display.

Note: If more than one linked remote control is in range, the memory function moves to the settings of the first key to initiate a memory recall.

Note: The guest profile consists of existing settings when there is no driver profile created. After you create a driver profile, the guest profile serves as an additional driver profile.

Note: You cannot link a remote control to a guest profile.

LINKING OR UNLINKING A PERSONAL PROFILE TO A DEVICE

Use the touchscreen to link a mobile device to a personal profile.

- 1. Switch the vehicle on and leave the vehicle in park (P).
- 2. Select the Personal Profiles button under Settings.
- 3. Touch the arrow for the profile you wish to link to a mobile device.
- 4. Select mobile device.
- 5. Follow the instructions on the display.

Note: To successfully link a mobile device, the mobile device must be in your vehicle, and must have previously been setup as a remote control for your vehicle.

Note: The guest profile consists of existing settings when there is no driver profile created. After you create a driver profile, the guest profile serves as an additional driver profile.

Note: You cannot link a personalized name to a guest profile.

Navigation (If Equipped)

CONNECTED NAVIGATION (IF

EQUIPPED)

Your vehicle may be equipped with connected navigation. Depending on your version, you are given a 90 day or 3 year trial. After the trial period, you need to sign up to continue the experience. For additional information, visit <u>ford.com/connectedservices</u>.

Note: If you do not sign up or renew your subscription, you can still use navigation through a connected device.

ACCESSING NAVIGATION



Press the button to access Navigation.

Note: As the driver, be aware of all local traffic regulations and road attributes, and operate your vehicle in a safe and legal manner.

NAVIGATION MAP UPDATES

To update your map data over Wi-Fi, your vehicle must be connected to a Wi-Fi access point. For USB updates and other details, contact dealers at 1-866-462-8837 in the United States and Canada, or 800-557-5539 in Mexico.

Note: If you find map data errors, you may report them by going to www.here.com/mapcreator.

ADJUSTING THE MAP

ZOOMING THE MAP IN AND OUT

You can use pinch gestures to zoom in and out. Place two fingers on the screen and move them apart to zoom in. Place two fingers on the screen and bring them together to zoom out.

CHANGING THE FORMAT OF THE



Press the Menu button.

- 1. Press the Map Orientation tile.
- 2. Select a map orientation.

LIVE TRAFFIC

WHAT IS LIVE TRAFFIC

You can observe real-time road congestion when live traffic is on.

SWITCHING LIVE TRAFFIC ON AND OFF



Press the Menu button.

- 1. Press the Traffic on Map tile.
- 2. Press Traffic on or Traffic Off.

SETTING A DESTINATION

SETTING A DESTINATION USING THE TEXT ENTRY SCREEN

1. Press the search bar at the top of the screen.

Navigation (If Equipped)

- 2. Enter your destination using the keyboard.
- 3. Press Search.
- 4. Select a destination from the list.
- 5. Press Start to begin navigation.

SETTING A DESTINATION USING THE MAP SCREEN

Press and hold on the map to place a pin at that location. Information about the location of the pin appears on the screen.



Press the button to begin navigation to the pin.

SETTING A DESTINATION USING A PREDICTIVE DESTINATION

Press the predicted destination card on the screen to navigate to it. These appear when the navigation system has learned your driving habits.

SETTING A DESTINATION USING A RECENT DESTINATION

- 1. Press the Recents tile.
- 2. Select a destination from the list.

SETTING A DESTINATION USING A SAVED DESTINATION

- 1. Press Saved Places.
- 2. Select a saved destination.

Note: Press the star icon next when viewing location details to save the location.

SETTING A DESTINATION USING A POINT OF INTEREST

Press a point of interest icon on the map. Information about the location of the point of interest appears on the screen.



Press the button to begin navigation to the point of interest.

WAYPOINTS

ADDING A WAYPOINT



Press the Add Waypoint button when in an active navigation session.

- 1. Select a category or enter your waypoint on the keyboard and press Search.
- 2. Select a waypoint from the list.
- 3. Press Add to Trip.

EDITING WAYPOINTS

- 1. Press the waypoint you would like to edit
- 2. Select an option to reorder or delete the waypoint.

ROUTE GUIDANCE

ADJUSTING THE GUIDANCE PROMPT VOLUME

Turn the volume control when a guidance prompt plays to adjust the volume.

CANCELING ROUTE GUIDANCE



Press the button to cancel route guidance to the selected location.

Vehicle Software Updates

These software updates introduce new features or provide updates to vehicle software systems. To receive updates, we recommend you switch Automatic Updates on, set a recurring update schedule and connect your vehicle to Wi-Fi. Updates could take longer when not connected to Wi-Fi or could not download at all. See **Connecting the Vehicle to a Wi-Fi Network** (page 383).

Your vehicle may be able to receive drivable software updates, non-drivable software updates or both. Drivable software updates happen during normal vehicle usage. If Automatic Updates is switched on, updates happen without any input from you. If Automatic Updates is switched off, a software update icon displays on the touchscreen and customer acceptance is required.

Non-drivable software updates require you to input a scheduled start time. You are notified on your touchscreen and connected device prior to a non-drivable update.

Most updates complete in less than 30 minutes, although some updates could take up to a few hours.

You are notified of the status of the software updates on the top left part of the touchscreen and on your connected device. See **Software Update Indicators** (page 428).

Vehicle Software Update Requirements

Non-drivable software updates do not install if any of the following occur:

- Your vehicle is running.
- Your vehicle is switched on.
- Your vehicle is not parked.
- The 12 V battery charge is too low.
- The hazard indicators are switched on.
- The alarm is sounding.

- The doors are open.
- The parking lamps are switched on.
- You are pressing the brake pedal.
- An emergency call is in process.
- Your vehicle is in limp home mode.

Vehicle Software Update Limitations

Once you begin a non-drivable software update, you cannot:

- Cancel the update.
- Enter your vehicle unless you have a key blade.
 - You can open the doors using the mechanical latch if child locks are not on.
- Use the remote control to lock, unlock or start your vehicle.
- Drive your vehicle.
- Charge your vehicle.
 - Charging resumes once the update completes.

SOFTWARE UPDATE SETTINGS

To access the Software Updates menu:

- 1. Press **Settings** on the touchscreen.
- 2. Press **Software Updates**.

You can do the following in the Software Updates menu:

- Switch Automatic Updates on and off.
- Schedule and install software updates.
- View software update details.



Press the button next to a menu option for more information.

Vehicle Software Updates

Switching Automatic Updates On and Off

Your vehicle may come with Automatic Updates switched on. Where Automatic Updates is set to 'On' in your vehicle, you agree that software updates may be automatically delivered without any further notice or additional consent from you.

Note: Software updates require approval to download or install with Automatic Updates switched off.

Scheduling and Installing Software Updates

Scheduling Software Updates

From the Software Updates menu:

- 1. Press **Schedule Updates**.
- 2. Select the days and time for updates.
- 3. Press Save.

The more days that updates are scheduled, the more frequently your vehicle installs new updates. We recommend selecting a time you normally do not need your vehicle.

Note: The schedule you set is recurring. If Automatic Updates is on, every time a non-drivable update is available, it installs on this schedule unless you change it. You are notified on your touchscreen and connected device prior to a non-drivable update, with an option to reschedule it.

Installing Software Updates

Using the Status Bar

- 1. Press a Software Update indicator on your touchscreen when it appears.
- 2. Follow the instructions on the touchscreen.

Using the Touchscreen

From the Software Updates menu:

- 1. Press *Update Details*.
- 2. Press *Update Now*.

Viewing Software Update Details

From the Software Updates menu:

1. Press *Update Details*.

SOFTWARE UPDATE INDICATORS

You can press the indicators in the status bar when they appear for more information.



Vehicle software update reminder, schedule required, confirmation of default schedule

required, or consent required.



Vehicle software update canceled, update not successful, or precondition not met.



Vehicle software update successful.

Vehicle System Reset

PERFORMING A SYSTEM RESET

Performing a system reset allows you to remove all personal information and restore settings to their factory defaults.

- 1. Press **Settings** on the touchscreen.
- 2. Press **General**.
- 3. Press **Reset**.
- 4. Press *Factory Reset*.
- 5. Follow the prompts on the screen to complete the reset.

Accessories

For a complete listing of the accessories that are available for your vehicle, please contact your authorized dealer or visit the online store web site:

Web Address (United States)

www.Accessories.Ford.com

Web Address (Canada)

www.Accessories.Ford.ca

We will repair or replace any properly authorized dealer-installed Ford Original Accessory found to be defective in factory-supplied materials or workmanship during the warranty period, as well as any component damaged by the defective accessories.

We will warrant your Ford Original Accessory through the warranty that provides the greatest benefit:

- 24 months, unlimited mileage.
- The remainder of your new vehicle limited warranty.

Contact an authorized dealer for details and a copy of the warranty.

Ford Licensed Accessories are the accessory manufacturer's designs. The manufacturer develops and therefore warrants Ford Licensed Accessories, and does not design or test these accessories to Ford Motor Company engineering requirements. Contact an authorized Ford dealer for the manufacturer's limited warranty details, and request a copy of the Ford Licensed Accessories product limited warranty from the accessory manufacturer.

For maximum vehicle performance, keep the following information in mind when adding accessories or equipment to your vehicle:

- When adding accessories, equipment, passengers and luggage to your vehicle, do not exceed the total weight capacity of the vehicle or of the front or rear axle (GVWR or GAWR as indicated on the Safety Compliance Certification label). Ask an authorized dealer for specific weight information.
- The Federal Communications
 Commission (FCC) and Canadian
 Radio Telecommunications
 Commission (CRTC) regulate the use
 of mobile communications systems
 that are equipped with radio
 transmitters, for example two-way
 radios, telephones and theft alarms.
 Any such equipment installed in your
 vehicle should comply with Federal
 Communications Commission (FCC)
 and Canadian Radio
 Telecommunications Commission
 (CRTC) regulations and should be
 installed only by an authorized dealer.
- An authorized dealer needs to install mobile communications systems. Improper installation may harm the operation of your vehicle, particularly if the manufacturer did not design the mobile communication system specifically for automotive use.
- If you or an authorized Ford dealer add any non-Ford electrical or electronic accessories or components to your vehicle, you may adversely affect battery performance and durability. In addition, you may also adversely affect the performance of other electrical systems in the vehicle.

Ford Protect

WHAT IS FORD PROTECT

Protect yourself from the rising cost of vehicle repairs with a Ford Protect extended service plan.

Ford Protect Extended Service Plans - United States Only

Ford Protect extended service plans mean peace of mind. Extended service plans are backed by Ford Motor Company, and provide more protection beyond the New Vehicle Limited Warranty coverage. When you visit your Ford Dealer, insist on the Ford Protect extended service plan.

Ford Protect Can Quickly Pay for Itself

One trip to the service center could easily exceed the price of your Ford Protect extended service plan. With the Ford Protect extended service plan, you minimize your risk for unexpected repair bills and rising repair costs.

Up to 1,000+ Covered Vehicle Components

There are four mechanical Ford Protect extended service plans with different levels of coverage. Ask your authorized dealer for details.

- 1. PremiumCARE Our most comprehensive coverage. With over 1,000 covered components, this plan is so complete it is probably easier to list what is not covered.
- 2. ExtraCARE Covers 113 components, and includes many high-tech items.
- 3. BaseCARE Covers 84 components.
- 4. PowertrainCARE Covers 29 critical components.

Ford Protect extended service plans are honored by all authorized Ford dealers in the United States, Canada and Mexico. That means you get:

- Reliable, quality service at any Ford or Lincoln dealership.
- Repairs performed by factory trained technicians, using genuine parts.

Rental Car Reimbursement

First Day Rental Benefit

If you bring your car into your dealer for service, we will give you a rental vehicle to use for the day.

Extended Rental Benefits

If your vehicle is kept overnight for covered repairs, you are eligible for rental car coverage, warranty repairs, and field service actions.

Roadside Assistance

Exclusive 24/7 roadside assistance, including:

- Towing, flat-tire change and battery jump starts.
- Lock-out assistance.
- Travel expense reimbursement for lodging, meals and rental car.
- Assistance for taxi, shuttle, rental car coverage or other transportation.

Transferable Coverage

If you sell your vehicle before your Ford Protect extended service plan coverage expires, you can transfer any remaining coverage to the new owner. This should give you and your potential buyer peace of mind.

Ford Protect

Less Cost to Properly Maintain Your Vehicle

The Ford Protect extended service plan also offers a Premium Maintenance Plan that covers all scheduled maintenance, and selected wear items. The coverage is prepaid, so you never have to worry about the cost of your vehicle's maintenance.

Covered maintenance includes:

- Windshield wiper blades.
- The clutch disc (if equipped).
- Brake pads and linings.
- Shock absorbers.
- Struts.
- Cabin air filter replacement every 20,000 mi (32,000 km).

Interest Free Finance Options

Just a 5% down payment provides you with an affordable, no interest, no fee payment program allowing you all the security and benefits Ford Protect extended service plan has to offer while paying over time. You are pre-approved with no credit check or hassles. To learn more, call our Ford Protect extended service plan specialists at 800-367-3377.

Ford Protect Extended Service Plan P.O. Box 321067 Detroit. MI 48232

Ford Protect Extended Service Plan (Canada Only)

You can get more protection for your vehicle by purchasing a Ford Protect extended service plan. Ford Protect extended service plan is the only service contract backed by Ford Motor Company of Canada, Limited. Depending on the plan you purchase, Ford Protect extended service plan provides benefits such as:

- Rental reimbursement.
- Coverage for certain maintenance and wear items.
- Protection against repair costs after your New Vehicle Limited Warranty Coverage expires.
- Roadside Assistance benefits.

There are several Ford Protect extended service plans available in various time, distance and deductible combinations. Each plan is tailored to fit your own driving needs, including reimbursement for towing and rental. When you purchase Ford Protect extended service plan, you receive added peace-of-mind protection throughout Canada, the United States and Mexico, provided by a network of participating authorized Ford Motor Company dealers.

Note: Repairs performed outside of Canada and the United States are not eligible for Ford Protect extended service plan coverage.

This information is subject to change. Visit your local Ford of Canada dealer or www.ford.ca to find the Ford Protect extended service plan that is right for you.

GENERAL MAINTENANCE INFORMATION

Why Maintain Your Vehicle?

Carefully following the maintenance schedule helps protect against major repair expenses resulting from neglect or inadequate maintenance and may help to increase the value of your vehicle when you sell or trade it. Keep all receipts for completed maintenance with your vehicle.

We have established regular maintenance intervals for your vehicle based upon rigorous testing. It is important that you have your vehicle serviced at the proper times. These intervals serve two purposes; one is to maintain the reliability of your vehicle and the second is to keep your cost of owning your vehicle down.

It is your responsibility to have all scheduled maintenance performed and to make sure that the materials used meet the specifications identified in this owner's manual. See **Capacities and Specifications** (page 363).

Failure to perform scheduled maintenance invalidates warranty coverage on parts affected by the lack of maintenance.

Why Maintain Your Vehicle at Your Dealership?

Factory-Trained Technicians

Service technicians participate in extensive factory-sponsored certification training to help them become experts on the operation of your vehicle. Ask your dealership about the training and certification their technicians have received.

Genuine Ford and Motorcraft® Replacement Parts

Dealerships stock Ford, Motorcraft and Ford-authorized branded re-manufactured replacement parts. These parts meet or exceed our specifications. Parts installed at your dealership carry a nationwide 24-month or unlimited mile (kilometer) parts and labor limited warranty.

If you do not use Ford authorized parts they may not meet our specifications and depending on the part, it could affect emissions compliance.

Convenience

Many dealerships have extended evening and Saturday hours to make your service visit more convenient and they offer one stop shopping. They can perform any services that are required on your vehicle, from general maintenance to collision repairs.

Note: Not all dealers have extended hours or body shops. Please contact your dealer for details.

Protecting Your Investment

Maintenance is an investment that pays dividends in the form of improved reliability, durability and resale value. To maintain the proper performance of your vehicle and its emission control systems, make sure you have scheduled maintenance performed at the designated intervals.

Your vehicle is equipped with an intelligent oil-life monitor that determines oil life based on engine operating conditions.

- Under normal operating conditions, a message appears in the instrument cluster display to indicate the regular oil change interval.
- Under severe operating conditions, the oil change interval may reduce, and the message interval may adjust.

High performance vehicles can be driven in such a way that may lead to higher oil consumption (this includes extended time at high engine speeds, high loads, engine braking, hard cornering maneuvers, and track use). Under these conditions, oil consumption of approximately 1 quart per 500 miles (1 liter per 800 km) is possible. As a result, the engine oil level needs to be checked at every refueling and adjusted to maintain proper level to avoid engine damage.

Note: Oil level should not exceed the maximum mark on the indicator. See **Checking the Engine Oil Level** (page 299).

Your vehicle can be driven in such a way that dilutes and increases the level of oil by short trips that do not allow the engine to get to operating temperature, extended idling, and low speed driving for long periods of time.

When the oil change message appears in the instrument cluster display, it is time for an oil change. Make sure you perform the oil change within two weeks or 500 mi (800 km) of the message appearing. Make sure you reset the Intelligent Oil-Life Monitor after each oil change.

If your instrument cluster display resets prematurely or becomes inoperative, you should perform the oil change interval at six months or 5,000 mi (8,000 km) from your last oil change. Never exceed one year or 10,000 mi (16,000 km) between oil change intervals.

Your vehicle is very sophisticated and built with multiple, complex, performance systems. Every manufacturer develops these systems using different specifications and performance features. That is why it is important to rely upon your dealership to properly diagnose and repair your vehicle.

Ford Motor Company has recommended maintenance intervals for various parts and component systems based upon engineering testing. Ford Motor Company relies upon this testing to determine the most appropriate mileage for replacement of oils and fluids to protect your vehicle at the lowest overall cost to you and recommends against maintenance schedules that deviate from the scheduled maintenance information.

We strongly recommend the use of only genuine Ford, Motorcraft or Ford-authorized re-manufactured replacement parts engineered for your vehicle.

Additives and Chemicals

This owner's manual and the Ford Workshop Manual list the recommended additives and chemicals for your vehicle. We do not recommend using chemicals or additives not approved by us as part of your vehicle's normal maintenance. Please consult your warranty information.

Oils, Fluids and Flushing

In many cases, fluid discoloration is a normal operating characteristic and, by itself, does not necessarily indicate a concern or that the fluid needs to be changed. However, a qualified expert, such as the factory-trained technicians at your dealership, should inspect discolored fluids that also show signs of overheating or foreign material contamination immediately.

Make sure to change your vehicle's oils and fluids at the specified intervals or in conjunction with a repair. Flushing is a viable way to change fluid for many vehicle sub-systems during scheduled maintenance. It is critical that systems are flushed only with new fluid that is the same as that required to fill and operate the

system or using a Ford-approved flushing chemical.

Owner Checks and Services

Make sure you perform the following basic maintenance checks and inspections every month or at six-month intervals.

Check every month

Engine oil level.

For severe use, high engine speed and engine loads, engine braking and track use, check engine oil level every fuel fill-up.

Function of all interior and exterior lights.

Tires, including spare, for wear and proper pressure.

Windshield washer fluid level.

Check every six months

Battery connections. Clean if necessary.

Body and door drain holes for obstructions. Clean if necessary.

Cooling system fluid level and coolant strength.

Door weatherstrips for wear. Lubricate if necessary.

Hinges, latches and outside locks for proper operation. Lubricate if necessary.

Parking brake for proper operation.

Seatbelts and seat latches for wear and function.

Safety warning lamps operation for brake, ABS, airbag and seatbelt.

Washer spray and wiper operation. Clean or replace blades as necessary.

Multi-Point Inspection

In order to keep your vehicle running right, it is important to have the systems on your vehicle checked regularly. This can help identify potential issues and prevent major

problems. We recommend having the following multi-point inspection performed at every scheduled maintenance interval to help make sure your vehicle keeps running great.

Multi-Point inspection	
Accessory drive belts.	Hazard warning system operation.
Battery performance.	Horn operation.
Engine air filter.	Radiator, cooler, heater and air conditioning hoses.
Exhaust system.	Suspension components for leaks or damage.
Exterior lamps operation.	Steering and linkage.
Fluid levels; fill if necessary.	Tires, including spare, for wear and proper pressure. ²
For oil and fluid leaks.	Windshield for cracks, chips or pits.
Half-shaft dust boots.	Washer spray and wiper operation.

¹ Brake, coolant recovery reservoir, automatic transmission and window washer.

Be sure to ask your dealership service advisor or technician about the multi-point vehicle inspection. It is a comprehensive way to perform a thorough inspection of your vehicle. Your checklist gives you immediate feedback on the overall condition of your vehicle.

NORMAL SCHEDULED MAINTENANCE

Intelligent Oil-Life Monitor™

Your vehicle has an Intelligent Oil-Life Monitor that determines when you should change the engine oil based on how you use your vehicle. By using several important factors in its calculations, the monitor helps reduce the cost of owning your vehicle and reduces environmental waste at the same time.

² If your vehicle is equipped with a temporary mobility kit, check the tire sealant expiration Use By date on the canister. Replace as needed.

This means you do not have to remember to change the oil on a mileage-based schedule. Your vehicle lets you know when an oil change is due by displaying a message in the information display.

The following table provides examples of vehicle use and its impact on oil change intervals. It is a guideline only. Actual oil change intervals depend on several factors and generally decrease with severity of use.

When to expect the message prompting you to change your oil	
Interval	Vehicle Use and Example
	Normal
7,000–10,000 mi (11,000–16,000 km)	Normal commuting with highway driving. No, or moderate, load or towing. Flat to moderately hilly roads. No extended idling.
	Severe
5,000–7,500 mi (8,000–12,000 km)	Moderate to heavy load or towing. Mountainous or off-road conditions. Extended idling. Extended hot or cold operation. High engine speeds and loads, engine braking and hard cornering.
3,000–5,000 mi (4,800–8,000 km)	Extreme
	Maximum load or towing. Extreme hot or cold operation.

Normal Maintenance Intervals

At every oil change interval as indicated by the information display
Change the engine oil and filter. ²
Rotate tires, inspect tire wear and measure the tread depth.
Perform a multi-point inspection, recommended.
Inspect the automatic transmission fluid level if your vehicle has a dipstick. Consult your dealer for requirements.
Inspect the brake pads, rotors, hoses and the parking brake.
Inspect the engine cooling system strength and hoses.

At every oil change interval as indicated by the information display

Inspect the exhaust system and heat shields.

Inspect rear axle and U-joints. Lubricate if your vehicle has grease fittings.

Inspect the half-shaft boots.

Inspect the steering linkage, ball joints, suspension, tie-rod ends, driveshaft and U-joints. Lubricate any areas with grease fittings.

Inspect the wheels and related components for abnormal noise, wear, looseness or drag.

²Reset the Intelligent Oil-Life Monitor after engine oil and filter changes.

Brake Fluid Maintenance	
Every three Years	Change the brake fluid. ²

¹ Perform this maintenance item every three years. Do not exceed the designated time for the interval.

²Brake fluid servicing requires special equipment available at your authorized dealer.

Other Maintenance Items 1	
Every 20,000 mi (32,000 km)	Replace the cabin air filter.
Every 30,000 mi (48,000 km)	Replace the engine air filter.
Every 100,000 mi (160,000 km)	Replace the spark plugs.
	Inspect the accessory drive belts. 2
Every 150,000 mi (240,000 km)	Change the automatic transmission fluid and filter.
	Change the manual transmission fluid.
	Replace the accessory drive belts.

¹ Do not exceed one year or 10,000 mi (16,000 km) between service intervals.

Other Maintenance Items	
	Change the rear axle fluid.
At 200,000 mi (320,000 km)	Change the engine coolant. 3

¹Perform these maintenance items within 3,000 mi (4,800 km) of the last engine oil and filter change. Do not exceed the designated distance for the interval.

Track Use Maintenance Intervals

Follow these maintenance intervals for when you use your vehicle on a track or in a high-speed event.

In addition to the recommendations below, we recommend following the procedures previously outlined in the Normal Maintenance Intervals section to help keep your vehicle running right, to identify potential issues, and to prevent major problems.

Interval	Vehicle Use and Example
One track weekend or approximately four hours of track use	Change the engine oil and filter.
Every 500 mi (800 km)	Change the rear axle fluid.

¹Change the fluid every 500 mi (800 km) or when a message appears in the information display stating that the axle fluid is overtemperature.

SPECIAL OPERATING CONDITIONS SCHEDULED MAINTENANCE

If you operate your vehicle primarily in any of the following conditions, you need to perform extra maintenance, as indicated. If you operate your vehicle occasionally under any of these conditions, it is not necessary to perform the extra maintenance. For specific recommendations, see your dealership service advisor or technician.

² After initial inspection, inspect every other oil change until replaced.

³Initial replacement at 10 years or 200,000 mi (320,000 km), then every 5 years or 100,000 mi (160,000 km).

Towing a Trailer or Using a Car-top Carrier	
As required	Change engine oil and filter as indicated by the instrument cluster display and perform services listed in the Normal Scheduled Maintenance chart.
Inspect frequently, service as required	Inspect rear axle and U-joints. Lubricate if equipped with grease fittings.
	See axle maintenance items under, Exceptions.
Every 60,000 mi	Change manual transmission fluid.
(96,000 km)	Replace spark plugs.

Extensive Idling or Low-speed Driving for Long Distances, as in Heavy Commercial Use (Such as Delivery, Taxi, Patrol Car or Livery) Short Trips that do not allow the engine to get to operating temperature causing fuel dilution and an increase of the engine oil level	
As required	Change engine oil and filter as indicated by the instrument cluster display and perform services listed in the Normal Scheduled Maintenance chart.
Inspect frequently, service as required	Replace cabin air filter.
Every 15,000 mi (24,000 km)	Inspect engine air filter. Replace as required.
Every 60,000 mi (96,000 km)	Replace spark plugs.

Operating in Dusty or Sandy Conditions Such as Unpaved or Dusty Roads	
Inspect frequently, service as required	Replace cabin air filter.
Every 15,000 mi (24,000 km)	Inspect engine air filter. Replace as required.
Every 5,000 mi (8,000 km)	Inspect the wheels and related components for abnormal noise, wear, looseness or drag.
	Rotate tires, inspect tires for wear and measure tread depth.

Operating in Dusty or Sandy Conditions Such as Unpaved or Dusty Roads	
Every 5,000 mi (8,000 km) or six months	Change engine oil and filter.
Every 50,000 mi (80,000 km)	Change manual transmission fluid.

Reset your Intelligent Oil-Life Monitor after each engine oil and filter change.

Exclusive Use of E85 - Flex Fuel Vehicles Only	
Every oil change interval	If ran exclusively on E85, fill the fuel tank full of regular unleaded fuel.

Exceptions

There are several exceptions to the Normal Schedule:

Axle Maintenance

Change the axle fluid anytime an axle is submerged in water.

If you receive an axle overtemperature warning message in the instrument cluster display and a wrench warning indicator appears, you should change the rear axle fluid at the next convenient time. The wrench warning indicator turns off when you switch off your vehicle.

Timing Chain

If you use your vehicle extensively at a racetrack or at high rpm, it is possible to exceed the service life of the engine timing chain. A wrench indicator light will illuminate when it is time for you to replace your chain. See an authorized dealer.

California Fuel Filter Replacement

If you register your vehicle in California, the California Air Resources Board has determined that the failure to perform this maintenance item does not nullify the emission warranty or limit recall liability before the completion of your vehicle's useful life. Ford Motor Company, however, urges you to have all recommended maintenance services performed at the specified intervals and to record all vehicle service.

Hot Climate Oil Change Intervals

Vehicles operating in the Middle East, North Africa, Sub-Saharan Africa or locations with similar climates using an American Petroleum Institute (API) Certified for Gasoline Engines (Certification mark) oil of SM or SN quality, the normal oil change interval is 3,000 mi (4,800 km).

If the available API SM or SN oils are not available, then the oil change interval is 1,800 mi (2,900 km).

Engine Air Filter and Cabin Air Filter Replacement

The life of the engine air filter and cabin air filter is dependent on exposure to dusty and dirty conditions. Vehicles operated in these conditions require frequent inspection and replacement of the engine air filter and cabin air filter.

THE BETTER BUSINESS BUREAU AUTO LINE PROGRAM

Your satisfaction is important to Ford Motor Company and to your dealer. If a warranty concern has not been resolved using the three-step procedure outlined earlier in this chapter in the Getting the Services you need section, you may be eligible to participate in the BBB AUTO LINE program.

The BBB AUTO LINE program consists of two parts — mediation and arbitration. During mediation, a representative of the BBB will contact both you and Ford Motor Company to explore options for settlement of the claim. If an agreement is not reached during mediation or you do not want to participate in mediation, and if your claim is eligible, you may participate in the arbitration process. An arbitration hearing will be scheduled so that you can present your case in an informal setting before an impartial person. The arbitrator considers the testimony provided and makes a decision after the hearing.

Disputes submitted to the BBB AUTO LINE program are usually decided within 40 days after you file your claim with the BBB. You are not bound by the decision, and may reject the decision and proceed to court where all findings of the BBB Auto Line dispute, and decision, are admissible in the court action. Should you choose to accept the BBB AUTO LINE decision, Ford is then bound by the decision, and must comply with the decision within 30 days of receipt of your acceptance letter.

BBB AUTO LINE Application: Using the information that follows, call or write to request a program application. You will be asked for your name and address, general information about your new vehicle, information about your warranty concerns, and any steps you have already taken to

try to resolve them. A Customer Claim Form will be mailed that needs to be completed, signed and returned to the BBB along with proof of ownership. Upon receipt, the BBB reviews the claim for eligibility under the Program Summary Guidelines.

You can get more information by calling BBB AUTO LINE at 1-800-955-5100, or writing to:

BBB AUTO LINE a Division of BBB National Programs, Inc. 1676 International Drive, Suite 550 McLean, VA 22102

BBB AUTO LINE applications can also be requested by calling the Ford Motor Company Customer Relationship Center at 1-800-392-3673.

For additional information, refer to the Better Business Bureau website.

Note: Ford Motor Company reserves the right to change eligibility limitations, modify procedures, or to discontinue this process at any time without notice and without obligation.

THE MEDIATION AND ARBITRATION PROGRAM

For vehicles delivered to authorized Canadian dealers. In those cases where you continue to feel that the efforts by Ford of Canada and the authorized dealer to resolve a factory-related vehicle service concern have been unsatisfactory, Ford of Canada participates in an impartial third party mediation/arbitration program administered by the Canadian Motor Vehicle Arbitration Plan (CAMVAP).

The CAMVAP program is a straightforward and relatively speedy alternative to resolve a disagreement when all other efforts to produce a settlement have failed. This procedure is without cost to you and is designed to eliminate the need for lengthy and expensive legal proceedings.

In the CAMVAP program, impartial third-party arbitrators conduct hearings at mutually convenient times and places in an informal environment. These impartial arbitrators review the positions of the parties, make decisions and, when appropriate, render awards to resolve disputes. CAMVAP decisions are fast, fair, and final as the arbitrator's award is binding on both you and Ford of Canada.

CAMVAP services are available in all Canadian territories and provinces. For more information, without charge or obligation, call your CAMVAP Provincial Administrator directly at 1-800-207-0685 or visit www.camvap.ca.

ORDERING A CANADIAN FRENCH OWNER'S MANUAL

You can obtain a French owner's manual from an authorized dealer or by contacting Helm, LLC at:

HELM, LLC 47911 Halyard Drive, Suite 200 Plymouth, Michigan 48170 Attention: Customer Service

Call toll free: 1-800-782-4356

Monday-Friday 8:00 a.m. - 6:00 p.m. EST

For additional information, visit www.helminc.com.

REPORTING SAFETY DEFECTS IN THE UNITED STATES

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration (NHTSA) in addition to notifying Ford Motor Company.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign. However, NHTSA cannot become involved in individual problems between you, your dealer, or Ford Motor Company.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to www.safercar.gov; or write to:

Administrator

1200 New Jersey Avenue, Southeast

Washington, D.C. 20590

You can also obtain other information about motor vehicle safety from www.safercar.gov.

REPORTING SAFETY DEFECTS IN CANADA

which could cause a crash or could cause injury or death, you should immediately inform Transport Canada and Ford of Canada.

If you believe that your vehicle has a defect

Transport Canada Contact Information		
Website (English)	http://tc.canada.ca/recalls	
Website (French)	http://tc.canada.ca/rappels	
Phone	1-800-333-0510	

Ford of Canada Contact Information			
Website	www.ford.ca		
Phone	1-800-565-3673		

THIRD PARTY SOFTWARE COPYRIGHT ACKNOWLEDGMENT


Your vehicle could have components that use open source software. For additional information, visit http://

corporate.ford.com/ford-open-source.html.

RADIO FREQUENCY CERTIFICATION LABELS

ANTENNAS

European Union EU



Ukraine



United Kingdom



BLIND SPOT INFORMATION SYSTEM SENSORS


Device	Supplier	Type Designation
SRR5 BLIS Corner Radar (RRU2)	Aptiv	2F5TR

Argentina



H-28070

Europe Union EU



Ghana

NCA APPROVED: 7E6-M0-XDF-TME

Jamaica

This product has been Type Approved by Jamaica: SMA - 2F5TR.

Paraguay



NR: 2022-04-I-0255

United Arab Emirates (U.A.E.)

TRA REGISTERED No:

ER10085/22

DEALER No:

DA37380/15

United Kingdom



United States and Canada

warning: Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

FCC ID: L2C2F5TR IC: 3432A-2F5TR

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

BLIND SPOT INFORMATION SYSTEM SENSORS

Argentina



Brazil



Djibouti

AGREE PAR LE MCPT (REPUBLIQUE DE DJIBOUTI) Numéro d'agrément : 195/MCPT/DDTIC Date d'agrément : 06/09/2021

Europe Union EU



Mauritania

AGREE PAR L'ANE MAURITANIE Numéro d'agrément : 0985/ARE/2021 Date d'agrément : 24/08/2021

Ghana

NCA APPROVED: SRO-1M-7E4-X0E

Mexico

IFETEL: RCPAPF520-0480

Morocco

AGREE PAR L'ANRT MAROC

Nu méro d'agré me nt : MR00030033ANRT2021

Date d'agrément : 16/09/2021

Jamaica

This product has been Type Approved by Jamaica: SMA – F5TR.

Paraguay




South Korea



Taiwan

2020-10-I-0753

Singapore



∭CCAI20LP1990T7

Thailand

(1)เครื่องโทรคมนาคมและอุปกรณ์นี้ มีความสอดคล้องตามข้อกาหนดของ กทช.

(2)เครื่องวิทยุคมนาคมน์มีระดับการแผ่คลื่นแม่เหล็กไฟท่ำสอดคล้องตามมาตรฐานความปลอดภัยต่อสุขภาพของมนุษย์จ ากการใช้เครื่องวิทยุคมนาคมที่คณะกรรมการกิจการโทรคมนาคมแห่งชาติประกาศกาหน

South Africa



Ukraine



United Arab Emirates (U.A.E.)

TRA
REGISTERED NO: ER80144/20
DEALER NO: DA83047/19

United States and Canada



WARNING: Changes or

modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

FCC ID: L2CF5TR IC: 3432A-F5TR

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Vietnam

United Kingdom



Ford Vietnam A00182015



BODY CONTROL MODULE

CNE COMISIÓN NACIONAL DE COMUNICACIONES

CNC ID: H-23804

Argentina

Jamaica

This product has been Type Approved by Jamaica: SMA - M3NA2C766336.

Brazil



Moldova



Ghana

NCA PRODUCT IDENTIFIER: ZRO-M8-7E3-281

Morocco

AGREE PAR L'ANRT MAROC

Numéro d'agrément: MR 20148 ANRT 2019

Date d'agrément: 19/06/2019

Paraguay



South Africa



2019-01-I-000076

Serbia



Ukraine



Singapore

Complies with IMDA Standards

DA 00461

United Arab Emirates (U.A.E.)

TRA REGISTERED No: ER68566/19

DEALER No: DA37380/15

United Kingdom



United States and Canada

 \triangle

WARNING: Changes or

modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

FCC ID: M3NA2C766336 IC: 7812A-A2C766336

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Vietnam

Ford Vietnam A00182015



Zambia



CRUISE CONTROL MODULE Argentina



Brazil



Djibouti

Ghana

AGREE PAR LE MCPT (REPUBLIQUE DE DJIBOUTI) Numéro d'agrément: 059/DDTIC/2020 Date d'agrément: 01/10/2020

NCA APPROVED: SRO-1M-7E4-X13

EAC Marking - Russia, Belarus, Kazakhstan


Independent State Of Samoa





Europe Union EU





Israel

- 1. מספר אישור התאמה מטעם משרד התקשורת: 51-82320
- .2 חל איסור לבצע פעולות במכשיר שיש בהן כדי לשנות את תכונותיו האלחוטיות של המכשיר, ובכלל זה שינויי תוכנה, החלפת אנטנה מקורית או הוספת אפשרות לחיבור לאנטנה חיצונית, בלא קבלת אישור משרד התקשורת, בשל החשש להפרעות אלחוטיות.

Jamaica

This product has been Type Approved by Jamaica: SMA – F3TR.

Mexico

IFT: RCPAPF320-0479

Moldova



Malaysia



HIDF16000009

Mauritania

AGREE PAR L'ANE MAURITANIE Numéro d'agrément : 0835/ARE/2020 Date d'agrément : 31/08/2020

Morocco

AGREE PAR L'ANRT MAROC

Numéro d'agrément: MR00030034ANRT2021

Date d'agrément: 16/09/2021

Pakistan



Paraguay



NR: 2020-10-I-0752

Sierra Leone



TAN: 2021-002-0028

Singapore

Complies with IMDA Standards

DA 00461

South Africa



South Korea



R-C-1Ap-F3TR

Taiwan

Unites Arab Emirates (U.A.E.)



TRA REGISTERED NO: ER80143/20 DEALER NO: DA83047/19

Thailand

(1) เครื่องโทรคมนาคมและอุปกรณ์นี้ มีความสอดคล้องตามข้อกาหนดของ กทช.

(2) เครื่องวิทยุคมนาคมนี้มีระดับการแผ่คลื่นแม่เหล็กไฟฟ้าสอดคล้องตามมาตรฐานความปลอดภัยต่อสุขภาพของมนุษย์จากการใช้เครื่องวิทยุคมนาคมพื้คณะกรรมการกิจการโพรคมนาคมแห่งชาติประกาศกาหน

United Kingdom



Ukraine



United States and Canada

WARNING: Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

FCC ID: L2CF3TR IC: 3432A-F3TR

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Zambia



- This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

KEYS AND REMOTE CONTROLS Argentina





GARAGE DOOR OPENER United States and Canada

warning: Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

FCC ID: NZLSAHL5E IC: 4112A-SAHL5E



CNC ID: H-16355



Djibouti

AGREE PAR LE MCPT (REPUBLIQUE DE DJIBOUTI) Numéro d'agrément : 287/MCPT/SC/16 Date d'agrément : 02/07/2016

Brazil



AGREE PAR LE MCPT (REPUBLIQUE DE DJIBOUTI) Numéro d'agrément : 289/MCPT/SC/116 Date d'agrément : 02/07/2016

Ghana



NCA APPROVED: 2R9-8M-7E0-x94

NCA APPROVED: 2R9-1H-7E0-01A

Jamaica

This product has been Type Approved by Jamaica: SMA – A2C97102000

Mauritania

This product has been Type Approved by Jamaica: SMA – A2C93142100

AGREE PAR L'ANE MAURITANIE Numéro d'agrément : 0324/ARE/2016 Date d'agrément : 07/03/2016

This product has been Type Approved by Jamaica: SMA – M3N-A2C931423

Malaysia



F17000176

AGREE PAR L'ANE MAURITANIE Numéro d'agrément : 0323/ARE/2016 Date d'agrément : 07/03/2016

Moldova



Morocco

AGREE PAR L'ANRT MAROC

Numéro d'agrément: MR 12432 ANRT 2016

Date d'agrément: 31/08/2016

Paraguay



NR: 2016-9-I-000222

NR: 2016**-**9-I-000220

NR: 2016-9-I-000223

AGREE PAR L'ANRT MAROC Numéro d'agrément : MR 12433 ANRT 2016 Date d'agrément : 31/08/2016

Serbia







Singapore

South Africa

Complies with IMDA Standards

DA 00461

South Korea



MSIP-CRM-TAL-A2C97102000

Taiwan









Ukraine



United Arab Emirates (U.A.E.)

TRA
REGISTERED No: ER47690/16
DEALER No: DA37380/15

TRA
REGISTERED No:
ER46754/16

DEALER No: DA37380/15


United States and Canada

WARNING: Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Vietnam



Zambia

China

CMIIT ID: 2016DJ0249

Djibouti



AGREE PAR LE MCPT (REPUBLIQUE DE DJIBOUTI) Numéro d'agrément: 247/MCPT/SC/16 Date d'agrément: 23/05/2016

E272192



AGREE PAR LE MCPT (REPUBLIQUE DE DJIBOUTI) Numéro d'agrément : 286/MCPT/SC/16

Date d'agrément: 02/07/16

RADIO TRANSCEIVER MODULE Argentina

Ghana



NCA APPROVED: NCA/TA/16/24

CNC ID: H-24069

Indonesia

SERTIFIKAT NOMOR: 44813/SDPPI/2016

PLG ID: 4940

Jamaica

This product has been Type Approved by Jamaica: SMA – FO3-AM433RX

This product has been Type Approved by Jamaica: SMA – F03-AM315RX

E272193

This product has been Type Approved by Jamaica: SMA - FO4-AM902TRB.

Mauritania

AGREE PAR L'ANE MAURITANIE Numéro d'agrément : 0233/ARE/2014 Date d'agrément : 14/11/2014

AGREE PAR L'ANE MAURITANIE Numéro d'agrément : 0325/ARE/2016 Date d'agrément : 07/03/2016

Moldova



Morocco

AGREE PAR L'ANRT MAROC Numéro d'agrément : MR 8921 ANRT 2014 Date d'agrément : 04/02/2014

AGREE PAR L'ANRT MAROC

Numéro d'agrément: MR 11489 ANRT 2016

Date d'agrément: 26/02/2016

Paraguay



NR: 2016-9-I-00244

Serbia



Pakistan



South Africa



South Korea



((() CCAB14LP5640T5

KCC-REM-DDG-FO3

Syria

SyTRA REGISTERED No: 1508/4NK

Ukraine



Taiwan

United Arab Emirates (U.A.E.)



TRA REGISTERED No. ER49062/16 DEALER No: DA37380/15

TRA REGISTERED No: ER46324/16

DEALER No: DA37380/15

Zambia



United States and Canada

warning: Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

FCC ID: LTQFO3AM315RX

FCC ID: L2C0062TR

IC: 3659A-FO3AM315RX IC: 3659A-FO4AM902TRX

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

SYNC

Argentina





CNC ID: C-24009

Brazil




AGREE PAR LE MCPT (REPUBLIQUE DE DJIBOUTI) Numéro d'agrément : 125/DDTIC/2019 Date d'agrément : 07/08/2019

Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.





08658-19-01505



Este equipamento não tem direito à proteção contra interferência prejudicial e não pode causar interferência em sistemas devidamente autorizados.

Ghana

Djibouti

AGREE PAR LE MCPT (REPUBLIQUE DE DJIBOUTI) Numéro d'agrément : 124/DDTIC/2019 Date d'agrément : 07/08/2019 NCA APPROVED: ZRO-1H-7E3-182

NCA APPROVED: ZRO-1H-7E3-180

Indonesia

Model: SYNC-G4 Sertifikat Nomor: 80700/SDPPI/2022 PLG ID: 13493



Model: SYNC-G4L Sertifikat Nomor: **81116**/SDPPI/2022 PLG ID: 13493



Jamaica

This product has been Type Approved by Jamaica: SMA – SYNC-G4.



Malaysia



SQASI/TA/19/4047 SQASI/TA/19/4046

Mauritania

AGREE PAR L'ANE MAURITANIE Numéro d'agrément : 0692/ARE/2018 Date d'agrément : 08/08/2019

AGREE PAR L'ANE MAURITANIE Numéro d'agrément : 0691/ARE/2018 Date d'agrément : 08/08/2019

AGREE PAR L'ANRT MAROC N° D'AGRÉMENT: MR 20606 ANRT 2019 07 AOUT 2019

Moldova



Morocco

AGREE PAR L'ANRT MAROC N° D'AGRÉMENT: MR 20608 ANRT 2019 07 AOUT 2019

Pakistan




Paraguay



2020-03-I-00192 2020-03-I-00193

Serbia





Singapore

Complies with IMDA Standards

DA 00461

South Korea





Taiwan

South Africa







TRA
REGISTERED No: ER74903/19
DEALER No: DA37380/15

Ukraine



United Arab Emirates (U.A.E.)

UAE - TRA
REGISTERED No:
ER74902/19
DEALER No:
DA37380/15

United Kingdom



United States and Canada

warning: Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

FCC ID: KMH-SYNCG4 FCC ID: KMH-SYNCG4L

IC: 1422A-SYNCG4 IC: 1422A-SYNCG4L

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Zambia





C-28150




Brazil






Europe Union EU



Mexico



United Arab Emirates (U.A.E.)

TRA

REGISTERED No:

ER87741/20

DEALER No:

DA83047/19

South Africa


Taiwan



United Kingdom



United States and Canada




We recommend that the distance between the antenna of the telematics control unit and the user be greater than 14 in (35 cm) when using the telematics control unit. **WARNING:** Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

FCC ID: KMH-14H074-NA1 IC: 1422A-14H074NA1

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Vietnam



TIRE PRESSURE MONITORING SYSTEM SENSORS

Argentina



Brazil



18962-22-08001

China

CMIITID:2014DJ1923

Democratic Republic of Congo

Agréé par l'ARPTC Nº d'homologation: HIR -0051/4/2014

Date d'homologation: 16/4/2014


Djibouti

European Union (EU)

AGREE PAR LE MCPT (REPUBLIQUE DE DJIBOUTI)

Numéro d'agrément : 198/MCPT/DDTCC

Date d'agrément : 7/9/2021



The RED 2014/53/EU (replacing R&TTE Directive 1999/5/EC on 13 June 2016) explicitly states that instructions for intentional radiators include reference to "(a) frequency band(s) in which the radio equipment operates; and (b) maximum radio-frequency power transmitted in the frequency band(s) in which the radio equipment operates," in addition to carrying over the general operational instruction and Declaration of Conformity inclusion requirements from the R&TTE Directive.

Hereby, Schrader Electronics Ltd. declares that the radio equipment type AG2SZ4 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

http://www.tpmseuroshop.com/documents/declaration_conformities

f=433.92MHz

P<10mW (e.i.r.p)

Schrader Electronics Ltd. 11 Technology Park, Belfast Road, Antrim BT41 1QS, Northern Ireland United Kingdom.

Ghana

NCA APPROVED: 3R88M14030

Independent State of Samoa



Israel

1. מספר אישור התאמה מטעם משרד התקשורת: 51-77913

חל איסור לבצע פעולות במכשיר שיש בהן כדי לשנות את תכונותיו האלחוטיות של המכשיר, ובכלל זה שינויי תוכנה, החלפת אנטנה מקורית או הוספת אפשרות לחיבור לאנטנה חיצונית, בלא קבלת אישור משרד התקשורת, בשל החשש להפרעות אלחוטיות.

Jamaica

This product has been Type Approved by Jamaica: SMA - AG2SZ4

Malaysia



HIDF16000009

Mauritania

AGREEPAR L'ANEMAURITANIE Numéro d'agrément: 0842/ARE/2020 Date d'agrément : 21/09/2020

Mexico

IFT: RLVSCMR15-1238

Moldova



Morocco

AGREE PAR L'ANRT MAROC Numéro d'agrément: MR9098 ANRT 2014 Date d'agrément: 14/03/2014

Nigeria

Connection and use of this communications equipment is permitted by the Nigerian Communications Commission

Oman

OMAN TRA TA-R/1752/14 D090258

Paraguay



NR: 2017-06-I-0000175

Pakistan



Russia




Sierra Leone



TAN: 2017-002-0035

Serbia



Singapore

Complies with IMDA Standards
DA 00461

South Africa



TA-2014/064

Approved

South Korea



MSIP-CRM-SRD-AG2SZ4

Taiwan



Thailand

(1) เครื่องโทรคมนาคมและอุปกรณ์นี้ มีความสอดคล้องตามข้อกาหนดของ กทช.

(2) ครื่องวิทยุคมนาคมนี้มีระดับการแผ่คลื่นแม่เหล็กไฟฟ้าสอดคล้องตามมาตรฐานความปลอดภัยต่อสุขภาพของมนุษย์จากการใช้เครื่องวิทยุคมนาคมพื้คณะกรรมการกิจการโพรคมนาคมแห่งชาติประกาศกาหน

Ukraine



United Arab Emirates

TRA REGISTERED No:

ER80634/20

DEALER No:

DA83047/19

United Kingdom



United States and Canada

warning: Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

FCC ID: MRXAG2SZ4 IC: 2546A-AG2SZ4

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Vietnam



TIRE PRESSURE MONITORING SYSTEM SENSORS

Argentina



Zambia



CNC ID: H-28035

Brazil



13309-22-08001

European Union EU



The RED 2014/53/EU (replacing R&TTE Directive 1999/5/EC on 13 June 2016) explicitly states that instructions for intentional radiators include reference to "(a) frequency band(s) in which the radio equipment operates; and (b) maximum radio-frequency power transmitted in the frequency band(s) in which the radio equipment operates," in addition to carrying over the general operational instruction and Declaration of Conformity inclusion requirements from the R&TTE Directive.

Hereby, Schrader Electronics Ltd. declares that the radio equipment type BG2BP4 is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:

http://www.tpmseuroshop.com/documents/declaration_conformities

f=433.92MHz

P<10mW (e.i.r.p)

Schrader Electronics Ltd. 11 Technology Park, Belfast Road, Antrim BT41 1QS, Northern Ireland United Kingdom.

Israel Jamaica

This product has been Type Approved by Jamaica: SMA - BG2BP4.

1. מספר אישור התאמה מטעם משרד התקשורת: 51-86230

 חל איסור לבצע פעולות במכשיר שיש ב^הן כדי לשנות את תכונותיו האלחוטיות של המכשיר, ובכלל זה שינויי תוכנה, החלפת אנטנה מקורית או הוספת אפשרות לחיבור לאנטנה חיצונית, בלא קבלת אישור משרד התקשורת, בשל החשש להפרעות אלחוטיות.

Malaysia



HIDF16000009

Mexico

IFT: RLVSCBG22-2502

Moldova



Morocco

AGREE PAR L'ANRT MAROC

Numéro d'agrément: MR00034968ANRT2022


Date d'agrément: 21/12/2022

Paraguay



NR: 2022-05-I-0000331

Serbia



Singapore

Complies with IMDA Standards
DA 00461

South Africa



South Korea



MSIP-R-C-SRD-BG2BP4

Taiwan



Thailand

(1)เครื่องโทรคมนาคมและอุปกรณ์นี้ มีความสอดคล้องตามข้อกาหนดของ กทช.

(2)เครื่องวิทยุคมนาคมนีมีระดับการแผ่คลื่นแม่เหล็กไฟฟ้าสอดคล้องตามมาตรฐานความปลอดภัยต่อสุขภาพของมนุษย์จ ากการใช้เครื่องวิทยุคมนาคมที่คณะกรรมการกิจการโพรคมนาคมแห่งชาติประกาศกาหน

Ukraine



Unites Arab Emirates (U.A.E.)

TRA REGISTERED No:

ER10488/22

DEALER No:

DA37380/15

United Kingdom



United States and Canada

warning: Changes or modifications not expressively approved by the party responsible for compliance could void the user's authority to operate the equipment. The term "IC:" before the radio certification number only signifies that Industry Canada technical specifications were met.

FCC ID: MRXBG2BP4 IC: 2546A-BG2BP4

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- This device must accept any interference received, including interference that may cause undesired operation.

WIRELESS ACCESSORY CHARGING MODULE

Argentina





CNCID: H-26492



Brazil

Ghana



NCA APPROVED: 7ES-7M-XB1-RDR


Democratic Republic of Congo

Indonesia

Agréé par l'ARPTC N° d'homologation : HER-0054/Juin/2021 Date d'homologation : 02/06/2021 Model: WCFDM00N2A1 Sertifikat Nomor: 80110/SDPPI/2022 PLG ID: 13493



European Union







Jamaica

Model: WCFDM00N2A5 Sertifikat Nomor: 80112/SDPPI/2022 PLG ID: 13493



This product has been Type Approved by Jamaica: SMA - WCFDM00N2A.

Malaysia



Israel

- מספר אישור התאמה מטעם משרד התקשורת: 51-80014
 חל איסור לבצע פעולות במבשיר שיש בהן בדי לשנות את תכונותיו האלחוטיות של המבשיר, ובכלל זה שינויי תוכנה, החלפת אנטנה מקורית או הוספת אפשרות לחיבור לאנטנה חיצונית, בלא קבלת אישור משרד התקשורת, בשל החשע להפרעות אלחוטיות
- RGEZ/35A/0521/S(21-2033) RGEZ/35A/0521/S(21-2032) RGEZ/35A/0521/S(21-2031)
- Mauritania

מספר אישור התאמה מטעם משרד התקשורת: 51-80015
 חל איסור לבצע פעולות במכשיר שיש בהן בדי לשנות את תכונותיו האלחוטיות של המכשיר, ובכלל זה שינויי תוכנה, החלפת אנטנה מקורית או הוספת אפשרות לחיבור לאנטנה חיצונית, בלא קבלת אישור משרד התקשורת, בשל החשש להפרעות אלחוטיות

AGREE PAR L'ANE MAURITANIE Numéro d'agrément : 0935/ARE/2021

Date d'agrément: 23/03/2021

 מספר אישור התאמה מטעם משרד התקשורת: 51-80013
 חל איסור לבצע פעולות במבשיר שיש בהן כדי לשנות את תכונותיו האלחוטיות של המבשיר, ובכלל זה שינויי תוכנה, החלפת אנטנה מקורית או הוספת אפשרות לחיבור לאנטנה חיצונית, בלא קבלת אישור משרד

התקשורת, בשל החשש להפרעות אלחוטיות

Morocco

AGREE PAR L'ANE MAURITANIE

Numéro d'agrément: 0934/ARE/2021

Date d'agrément: 23/03/2021

AGREE PAR L'ANRT MAROC

Numéro d'agrément: MR 00027924ANRT 2021

Date d'agrément: 25/03/2021

AGREE PAR L'ANE MAURITANIE

Numéro d'agrément: 0933/ARE/2021

Date d'agrément: 23/03/2021

AGREE PAR L'ANRT MAROC

Numéro d'agrément : MR 00027925ANRT 2021

Date d'agrément : 25/03/2021

Moldova



AGREE PAR L'ANRT MAROC

Nu méro d'agré ment: MR 00027923ANRT 2021

Date d'agrément: 25/03/2021

Paraguay



NR: 2021-04-I-0202

NR: 2021-04-I-0203

NR: 2021-04-I-0204

Russia



Serbia



Sierra Leone



Singapore

Complies with IMDA Standards


DA 00461

South Africa



South Korea






R-R-LGE-WCFDM00N2A1

Taiwan





品名(Product name): 無線充電座

型號 (Type Designation): WCFDM00N2A1, WCFDM00N2A3, WCFDM00N2A5 產地 (Origin): 馬來西亞

額定電壓(Input rating): 12V

製造日期 (Approval date): 2021.04.21

R43208 RoHs

申請廠商名稱(Approval name): 福特六和汽車股份有限公司申請廠商地址(Approval address): 桃園市中壢區中華路一段705號

Ukraine



United Kingdom



United Arab Emirates (U.A.E.)

TRA REGISTERED No:

ER98638/21

DEALER No:

DA37380/15

TRA REGISTERED No:

ER00421/21

DEALER No:

DA37380/15

TRA REGISTERED No:

ER00422/21

DEALER No:

DA37380/15

United States and Canada

FCC ID: BEJWCFDM00N2A IC: 2703H-WCFDM00N2A

This equipment generates, uses, and can radiate radio frequency energy and may cause harmful interference to radio communications. There is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, please consult the dealer.

This product is not end-user serviceable.

RF Radiation Exposure Statement: This equipment complies with FCC RF Radiation exposure limits set forth for an uncontrolled environment. This device and its antenna must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

This device complies with Part 15 of the FCC Rules and with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and
- 2. This device must accept any interference received, including interference that may cause undesired operation.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:

- 1. L'appareil ne doit pas produire debrouillage;
- L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Zambia



PERCHLORATE

Certain components in your vehicle such as airbag modules, seatbelt pretensioners and remote control batteries may contain perchlorate material. Special handling may apply for service or vehicle end of life disposal.

For more information visit: www.dtsc.ca.gov/hazardouswaste/perchlorate.

REPLACEMENT PARTS RECOMMENDATION

We have built your vehicle to the highest standards using quality parts. We recommend that you demand the use of genuine Ford and Motorcraft parts whenever your vehicle requires scheduled maintenance or repair. You can clearly identify genuine Ford and Motorcraft parts by looking for the Ford, FoMoCo or Motorcraft branding on the parts or their packaging.

Scheduled Maintenance and Mechanical Repairs

One of the best ways for you to make sure that your vehicle provides years of service is to have it maintained in line with our recommendations using parts that conform to the specifications detailed in this Owner's Manual.

Genuine Ford and Motorcraft parts meet or exceed these specifications.

Collision Repairs

We hope that you never experience a collision, but accidents happen sometimes.

Genuine Ford replacement collision parts meet our stringent requirements for fit, finish, structural integrity, corrosion protection and dent resistance. During vehicle development we validate that these parts deliver the intended level of protection as a whole system. A great way to know for sure you are getting this level of protection is to use genuine Ford replacement collision parts.

Warranty on Replacement Parts

Genuine Ford and Motorcraft replacement parts are the only replacement parts that benefit from a Ford Warranty.

The Ford Warranty may not cover damage caused to your vehicle as a result of failed non-Ford parts.

For additional information, refer to the terms and conditions of the Ford Warranty.

MOBILE COMMUNICATIONS EQUIPMENT

warning: Driving while distracted can result in loss of vehicle control, crash and injury. We strongly recommend that you use extreme caution when using any device that may take your focus off the road. Your primary responsibility is the safe operation of your vehicle. We recommend against the use of any hand-held device while driving and encourage the use of voice-operated systems when possible. Make sure you are aware of all applicable local laws that may affect the use of electronic devices while driving.

Using mobile communications equipment is becoming increasingly important in the conduct of business and personal affairs. However, you must not compromise your own or others' safety when using such equipment. Mobile communications can enhance personal safety and security when appropriately used, particularly in emergency situations. Safety must be paramount when using mobile communications equipment to avoid negating these benefits. Mobile communication equipment includes, but is not limited to, cellular phones, pagers, portable email devices, text messaging devices and portable two-way radios.

FEDERAL HIGHWAY ADMINISTRATION REGULATION

Regulations such as those issued by the Federal Highway Administration or issued pursuant to the Occupational Safety and Health Act (OSHA), and state and local laws and regulations may require additional equipment for the way you intend to use your vehicle. It is the responsibility of the registered owner to determine the applicability of such laws and regulations to your intended use for the vehicle, and to arrange for the installation of required equipment. The dealer has information about the availability of equipment which can be ordered for your vehicle.

END USER LICENSE AGREEMENT

VEHICLE SOFTWARE END USER LICENSE AGREEMENT (EULA)

- You ("You" or "Your" as applicable) have acquired a vehicle having several devices, including SYNC ® and various control modules, ("DEVICES") that include software licensed or owned by Ford Motor Company and its affiliates ("FORD MOTOR COMPANY"). Those software products of FORD MOTOR COMPANY origin, as well as associated media, printed materials, and "online" or electronic documentation ("SOFTWARE") are protected by international intellectual property laws and treaties. The SOFTWARE is licensed, not sold. All rights reserved.
- The SOFTWARE may interface with and/or communicate with, or may be later upgraded to interface with and/or communicate with additional software and/or systems provided by FORD MOTOR COMPANY.

IF YOU DO NOT AGREE TO THIS END USER LICENSE AGREEMENT ("EULA") DO NOT USE THE DEVICES OR COPY THE SOFTWARE. ANY USE OF THE SOFTWARE, INCLUDING BUT NOT LIMITED TO USE ON THE DEVICES, WILL CONSTITUTE YOUR AGREEMENT TO THIS EULA (OR RATIFICATION OF ANY PREVIOUS CONSENT).

GRANT OF SOFTWARE LICENSE: This EULA grants you the following license:

 You may use the SOFTWARE as installed on the DEVICES and as otherwise interfacing with systems and/or services provide by or through FORD MOTOR COMPANY or its third party software and service providers.

Description of Other Rights and Limitations.

- Speech Recognition: If the SOFTWARE includes speech recognition component(s), you should understand that speech recognition is an inherently statistical process and that recognition errors are inherent in the process. Neither FORD MOTOR COMPANY nor its suppliers shall be liable for any damages arising out of errors in the speech recognition process. It is your responsibility to monitor any speech recognition functions included in the system.
- Limitations on Reverse Engineering, **Decompilation and Disassembly:** You may not reverse engineer, decompile, translate, disassemble or attempt to discover any source code or underlying ideas or algorithms of the SOFTWARE nor permit others to reverse engineer, decompile or disassemble the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation or to the extent as may be permitted by the licensing terms governing use of any open source components included with the SOFTWARE.
- Limitations on Distributing, Copying, Modifying and Creating Derivative Works: You may not distribute, copy, make modifications to or create derivative works based on the SOFTWARE, except and only to the extent that such activity is expressly permitted by applicable law notwithstanding this limitation or to the extent as may be permitted by the licensing terms governing use of any open source components included with the SOFTWARE.

- Single EULA: The end user documentation for the DEVICES and related systems and services may contain multiple EULAs, such as multiple translations and/or multiple media versions (e.g., in the user documentation and in the software). Even if you receive multiple EULAs, you are licensed to use only one (1) copy of the SOFTWARE.
- permanently transfer: You may permanently transfer your rights under this EULA only as part of a sale or transfer of the DEVICES, provided you retain no copies, you transfer all of the SOFTWARE (including all component parts, the media and printed materials, any upgrades, and, if applicable, the Certificate(s) of Authenticity), and the recipient agrees to the terms of this EULA. If the SOFTWARE is an upgrade, any transfer must include all prior versions of the SOFTWARE.
- Termination: Without prejudice to any other rights, FORD MOTOR COMPANY may terminate this EULA if you fail to comply with the terms and conditions of this EULA.
- **Internet-Based Services Components:** The SOFTWARE may contain components that enable and facilitate the use of certain Internet-based services. You acknowledge and agree that FORD MOTOR COMPANY, third party software and service suppliers, its affiliates and/or its designated agent may automatically check the version of the SOFTWARE and/or its components that you are utilizing and may provide upgrades or supplements to the SOFTWARE that may be automatically downloaded to your DEVICES.
- Additional Software/Services: The SOFTWARE may permit FORD MOTOR COMPANY, third party software and service suppliers, its affiliates and/or its designated agent to provide or make available to you SOFTWARE updates, supplements, add-on components, or Internet-based services components of the SOFTWARE after the date you obtain your initial copy of the SOFTWARE ("Supplemental Components".) SOFTWARE updates may cause you to incur additional charges from your wireless service provider. If FORD MOTOR COMPANY or third party software and services suppliers provide or make available to you Supplemental Components and no other EULA terms are provided along with the Supplemental Components, then the terms of this **EULA shall apply. FORD MOTOR** COMPANY, its affiliates and/or its designated agent reserve the right to discontinue without liability any Internet-based services provided to you or made available to you through the use of the SOFTWARE.

- **Links to Third Party Sites:** The SOFTWARE may provide you with the ability to link to third party sites. The third party sites are not under the control of FORD MOTOR COMPANY, its affiliates and/or its designated agent. Neither FORD MOTOR COMPANY nor its affiliates nor its designated agent are responsible for (I) the contents of any third party sites, any links contained in third party sites, or any changes or updates to third party sites, or (ii) webcasting or any other form of transmission received from any third party sites. If the SOFTWARE provides links to third party sites, those links are provided to you only as a convenience, and the inclusion of any link does not imply an endorsement of the third party site by FORD MOTOR COMPANY, its affiliates and/or its designated agent.
- Obligation to Drive Responsibly:
 You recognize your obligation to drive
 responsibly and keep attention on the
 road. You will read and abide with the
 DEVICES operating instructions
 particularly as they pertain to safety
 and you agree to assume any risk
 associated with the use of the
 DEVICES.

UPGRADES AND RECOVERY MEDIA:

If the SOFTWARE is provided by FORD MOTOR COMPANY separate from the DEVICES on media such as a ROM chip, CD ROM disk(s) or via web download or other means, and is labeled "For Upgrade Purposes Only" or "For Recovery Purposes Only" you may install one (1) copy of such SOFTWARE onto the DEVICES as a replacement copy for the existing SOFTWARE, and use it in accordance with this EULA, including any additional EULA terms accompanying the upgrade SOFTWARE.

INTELLECTUAL PROPERTY RIGHTS:

All title and intellectual property rights in and to the SOFTWARE (including but not limited to any images, photographs, animations, video, audio, music, text and "applets" incorporated into the SOFTWARE), the accompanying printed materials, and any copies of the SOFTWARE, are owned by FORD MOTOR COMPANY, or its affiliates or suppliers. The SOFTWARE is licensed, not sold. You may not copy the printed materials accompanying the SOFTWARE. All title and intellectual property rights in and to the content which may be accessed through use of the SOFTWARE is the property of the respective content owner and may be protected by applicable copyright or other intellectual property laws and treaties. This EULA grants you no rights to use such content outside its intended use. All rights not specifically granted under this EULA are reserved by FORD MOTOR COMPANY, its affiliates, and third party software and service providers and suppliers. Use of any on-line services which may be accessed through the SOFTWARE may be governed by the respective terms of use relating to such services. If this SOFTWARE contains documentation that is provided only in electronic form, you may print one copy of such electronic documentation.

EXPORT RESTRICTIONS: You

acknowledge that the SOFTWARE is subject to U.S. and European Union export jurisdiction. You agree to comply with all applicable international and national laws that apply to the SOFTWARE, including the U.S. Export Administration Regulations, as well as end-user, end-use and destination restrictions issued by U.S. and other governments.

TRADEMARKS: This EULA does not grant you any rights in connection with any trademarks or service marks of FORD MOTOR COMPANY, its affiliates, and third party software and service providers.

PRODUCT SUPPORT: Please refer to FORD MOTOR COMPANY instructions provided in the documentation for the DEVICES product support, such as the vehicle owner guide.

Should you have any questions concerning this EULA, or if you desire to contact FORD MOTOR COMPANY for any other reason, please refer to the address provided in the documentation for the DEVICES.

No Liability for Certain Damages:

EXCEPT AS PROHIBITED BY LAW, FORD MOTOR COMPANY, ANY THIRD PARTY SOFTWARE OR SERVICES SUPPLIERS, AND THEIR AFFILIATES SHALL HAVE NO LIABILITY FOR ANY INDIRECT, SPECIAL, CONSEQUENTIAL OR INCIDENTAL DAMAGES ARISING FROM OR IN CONNECTION WITH THE USE OR PERFORMANCE OF THE SOFTWARE. THIS LIMITATION SHALL APPLY EVEN IF ANY REMEDY FAILS OF ITS ESSENTIAL PURPOSE. THERE ARE NO WARRANTIES OTHER THAN THOSE THAT MAY BE EXPRESSLY PROVIDED FOR YOUR NEW VEHICLE.

SYNC® Automotive Important Safety Information Read and follow instructions:

 Before using your SYNC® system, read and follow all instructions and safety information provided in this end user manual ("Owner Guide".) Not following precautions found in the Owner Guide can lead to an accident or other serious injuries. General Operation

- Voice Command Control: Certain functions within the SYNC® system may be accomplished using voice commands. Using voice commands while driving helps you to operate the system without removing your hands from the wheel or eyes from the road.
- Prolonged Views of Screen: Do not access any function requiring a prolonged view of the screen while you are driving. Pull over in a safe and legal manner before attempting to access a function of the system requiring prolonged attention.
- Volume Setting: Do not raise the volume excessively. Keep the volume at a level where you can still hear outside traffic and emergency signals while driving. Driving while unable to hear these sounds could cause an accident.
- Navigation Features: Any navigation features included in the system are intended to provide turn by turn instructions to get you to a desired destination. Please make certain all persons using this system carefully read and follow instructions and safety information fully.
- Distraction Hazard: Any navigation features may require manual (non-verbal) setup. Attempting to perform such set-up or insert data while driving can distract your attention and could cause an accident or other serious injury. Stop the vehicle in a safe and legal manner before attempting these operations.
- Let Your Judgment Prevail: Any navigation features are provided only as an aid. Make your driving decisions based on your observations of local conditions and existing traffic regulations. Any such feature is not a

- substitute for your personal judgment. Any route suggestions made by this system should never replace any local traffic regulations or your personal judgment or knowledge of safe driving practices.
- Route Safety: Do not follow the route suggestions if doing so would result in an unsafe or illegal maneuver, if you would be placed in an unsafe situation, or if you would be directed into an area that you consider unsafe. The driver is ultimately responsible for the safe operation of the vehicle and therefore, must evaluate whether it is safe to follow the suggested directions.
- Potential Map Inaccuracy: Maps used by this system may be inaccurate because of changes in roads, traffic controls or driving conditions. Always use good judgment and common sense when following the suggested routes.
- emergency Services: Do not rely on any navigation features included in the system to route you to emergency services. Ask local authorities or an emergency services operator for these locations. Not all emergency services such as police, fire stations, hospitals and clinics are likely to be contained in the map database for such navigation features.

- Your Responsibilities and Assumptions of Risk
- You agree to each of the following:(a) Any use of the SOFTWARE while driving an automobile or other vehicle in violation of applicable law or otherwise driving in an unsafe manner presents a significant risk of distracted driving and should not be attempted under any circumstances; (b) Use of the SOFTWARE at excessive volume poses a significant risk of hearing damage and should not be attempted under any circumstances;(c) The SOFTWARE may not be compatible with new or different versions of an operating system, third party software, or third party services, and the SOFTWARE may potentially cause a critical failure of an operating system, third party software, or third party service.(d) Any third party service accessed by or third party software used with the SOFTWARE (I) may charge an additional fee for access, (ii) may not work correctly, on an uninterrupted basis, or error free, (iii) may change streaming formats or discontinue operation, (iv) may contain adult, profane or offensive content; and (v) may contain inaccurate, false or misleading traffic, weather, financial or safety information or other content; and (e) Use of the SOFTWARE may cause you to incur additional charges from your wireless service provider (WSP) and any data or minute calculators that may be included in the software program are for reference only, are not warranted in any way and should not be relied upon in anyway.
- When using the SOFTWARE, you agree to be responsible for and assume the entire risk to the items set forth in Section (a) – (e) above.

Disclaimer of Warranty

YOU EXPRESSLY ACKNOWLEDGE AND AGREE THAT USE OF THE DEVICES AND SOFTWARE IS AT YOUR SOLE RISK AND THAT THE ENTIRE RISK AS TO SATISFACTORY QUALITY, PERFORMANCE, COMPATIBILITY. ACCURACY AND EFFORT IS WITH YOU. TO THE MAXIMUM EXTENT PERMITTED BY APPLICABLE LAW. THE SOFTWARE AND ANY THIRD PARTY SOFTWARE OR THIRD-PARTY SERVICES ARE PROVIDED "AS IS" AND "AS AVAILABLE", WITH ALL FAULTS AND WITHOUT WARRANTY OF ANY KIND, AND FORD MOTOR COMPANY HEREBY DISCLAIMS ALL WARRANTIES AND CONDITIONS WITH RESPECT TO THE SOFTWARE, THIRD PARTY SOFTWARE, AND THIRD-PARTY SERVICES, EITHER EXPRESS, IMPLIED OR STATUTORY, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES AND/OR CONDITIONS OF MERCHANTABILITY, OF SATISFACTORY **QUALITY, OF FITNESS FOR AN** ARTICULAR PURPOSE, OF ACCURACY, OF OUIET ENJOYMENT, AND NON-INFRINGEMENT OF THIRD-PARTY RIGHTS. FORD MOTOR COMPANY DOES NOT WARRANT (a) AGAINST INTERFERENCE WITH YOUR ENJOYMENT OF THE SOFTWARE, THIRD PARTY SOFTWARE, OR THIRD-PARTY SERVICES, (b) THAT THE SOFTWARE, THIRD PARTY SOFTWARE, OR THIRD-PARTY SERVICES WILL MEET YOUR REQUIREMENTS, (c) THAT THE OPERATION OF THE SOFTWARE, THIRD PARTY SOFTWARE, OR THIRD-PARTY SERVICES WILL BE UNINTERRUPTED OR ERROR-FREE, (d) OR THAT DEFECTS IN THE SOFTWARE. THIRD PARTY SOFTWARE, OR THIRD-PARTY SERVICES WILL BE CORRECTED. NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY FORD MOTOR COMPANY OR ITS AUTHORIZED REPRESENTATIVE SHALL

CREATE A WARRANTY. SHOULD THE SOFTWARE, THIRD PARTY SOFTWARE. OR THIRD-PARTY SERVICES PROVE DEFECTIVE, YOU ASSUME THE ENTIRE COST OF ALL NECESSARY SERVICING. REPAIR OR CORRECTION. SOME JURISDICTIONS DO NOT ALLOW THE DISCLAIMER OF IMPLIED WARRANTIES OR LIMITATIONS ON APPLICABLE STATUTORY RIGHTS OF A CONSUMER, SO THE ABOVE DISCLAIMER MAY NOT FULLY APPLY TO YOU. THE SOLE WARRANTY PROVIDED BY FORD MOTOR COMPANY SHALL BE FOUND IN THE WARRANTY INFORMATION INCLUDING WITH YOUR OWNER GUIDE. TO THE EXTENT THAT THERE IS ANY CONFLICT BETWEEN THE TERMS OF THIS SECTION AND THE WARRANTY BOOKLET. THE WARRANTY BOOKLET SHALL CONTROL.

Applicable Law, Venue, Jurisdiction

The laws of the State of Michigan govern this EULA and Your use of the SOFTWARE. Your use of the SOFTWARE may also be subject to other local, state, national, or international laws. Any litigation arising out of or related to this EULA shall be brought and maintained exclusively in a court of the State of Michigan located in Wavne County or in the United States District Court for the Eastern District of Michigan. You hereby consent to submit to the personal jurisdiction of a court in the State of Michigan located in Wayne County and the United States District Court for the Eastern District of Michigan for any dispute arising out of or relating to this EULA.

Binding Arbitration and Class Action Waiver

- (a) Application. This Section applies to any dispute EXCEPT IT DOES NOT INCLUDE A DISPUTE RELATING TO COPYRIGHT INFRINGEMENT, OR TO THE ENFORCEMENT OR VALIDITY OF YOUR. FORD MOTOR COMPANY, OR ANY OF FORD MOTOR COMPANY'S LICENSORS' INTELLECTUAL PROPERTY RIGHTS. Dispute means any dispute, action, or other controversy between You and FORD MOTOR COMPANY, other than the exceptions listed above, concerning the SOFTWARE (including its price) or this EULA, whether in contract, warranty, tort, statute, regulation, ordinance, or any other legal or equitable basis.
- **(b) Notice of Dispute.** In the event of a Dispute, You or FORD MOTOR COMPANY must give the other a "Notice of Dispute", which is a written statement of the name, address, and contact information of the party giving it, the facts giving rise to the dispute, and the relief requested. You and FORD MOTOR COMPANY will attempt to resolve any dispute through informal negotiation within 60 days from the date the Notice of Dispute is sent. After 60 days, You or FORD MOTOR COMPANY may commence arbitration.
- (c) Small claims court. You may also litigate any dispute in small claims court in your county of residence or FORD MOTOR COMPANY'S principal place of business, if the dispute meets all requirements to be heard in the small claims court. You may litigate in small claims court whether or not You negotiated informally first.
- (d) Binding arbitration. If You and FORD MOTOR COMPANY, do not resolve any dispute by informal negotiation or in small claims court, any other effort to resolve the dispute will be conducted exclusively by binding arbitration. You are giving up

- the right to litigate (or participate in as a party or class member) all disputes in court before a judge or jury. Instead, all disputes will be resolved before a neutral arbitrator, whose decision will be final except for a limited right of appeal under the Federal Arbitration Act. Any court with jurisdiction over the parties may enforce the arbitrator's award.
- (e) Class action waiver. Any proceedings to resolve or litigate any dispute in any forum will be conducted solely on an individual basis. Neither you nor FORD MOTOR COMPANY, will seek to have any dispute heard as a class action, as a private attorney general action, or in any other proceeding in which any party acts or proposes to act in a representative capacity. No arbitration or proceeding will be combined with another without the prior written consent of all parties to all affected arbitrations or proceedings.
- (f) Arbitration procedure. Any arbitration will be conducted by the American Arbitration Association (the "AAA"), under its Commercial Arbitration Rules. If You are an individual and use the SOFTWARE for personal or vehicle use, or if the value of the dispute is \$75.000 or less whether or not You are an individual or how You use the SOFTWARE, the AAA Supplementary Procedures for Consumer-Related Disputes will also apply. To commence arbitration, submit a Commercial Arbitration Rules Demand for Arbitration form to the AAA. You may request a telephonic or in-person hearing by following the AAA rules. In a dispute involving \$10,000 or less, any hearing will be telephonic unless the arbitrator finds good cause to hold an in-person hearing instead. For more information, see adr.org or call 1-800-778-7879. You agree to commence arbitration only in your county of residence or FORD MOTOR COMPANY'S principal place of business. The arbitrator

may award the same damages to you individually as a court could. The arbitrator may award declaratory or injunctive relief only to you individually, and only to the extent required to satisfy your individual claim.

(g) Arbitration fees and incentives.

- I. Disputes involving \$75,000 or less. FORD MOTOR COMPANY will promptly reimburse your filing fees and pay the AAA's and arbitrator's fees and expenses. If you reject FORD MOTOR COMPANY'S last written settlement offer made before the arbitrator was appointed ("last written offer"), your dispute goes all the way to an arbitrator's decision (called an "award"), and the arbitrator awards you more than the last written offer. FORD MOTOR COMPANY will give you three incentives: (1) pay the greater of the award or \$1,000; (2) pay twice your reasonable attorney's fees, if any; and (3) reimburse any expenses (including expert witness fees and costs) that your attorney reasonably accrues for investigating, preparing, and pursuing your claim in arbitration. The arbitrator will determine the amounts.
- ii. Disputes involving more than \$75,000. The AAA rules will govern payment of filing fees and the AAA's and arbitrator's fees and expenses.
- iii. Disputes involving any amount. In any arbitration you commence, FORD MOTOR COMPANY will seek its AAA or arbitrator's fees and expenses, or Your filing fees it reimbursed, only if the arbitrator finds the arbitration frivolous or brought for an improper purpose. In any arbitration FORD MOTOR COMPANY commences, it will pay all

filing, AAA, and arbitrator's fees and expenses. It will not seek its attorney's fees or expenses from you in any arbitration. Fees and expenses are not counted in determining how much a dispute involves.

- (h) Claims or disputes must be filed within one year. To the extent permitted by law, any claim or dispute under this EULA to which this Section applies must be filed within one year in small claims court (Section c) or in arbitration (Section d). The one-year period begins when the claim or dispute first could be filed. If such a claim or dispute is not filed within one year, it is permanently barred.
- (I) Severability. If the class action waiver (Section e) is found to be illegal or unenforceable as to all or some parts of a dispute, then that portion of Section e will not apply to those parts. Instead, those parts will be severed and proceed in a court of law, with the remaining parts proceeding in arbitration. If any other provision of that portion Section e is found to be illegal or unenforceable, that provision will be severed with the remainder of Section e remaining in full force and effect.

Telenav Software End User License Agreement

Please read these terms and conditions carefully before you use the TeleNav Software. Your use of the TeleNav Software indicates that you accept these terms and conditions. If you do not accept these terms and conditions, do not break the seal of the package, launch, or otherwise use the TeleNav Software. TeleNav may revise this Agreement and the privacy policy at any time, with or without notice to you. You agree to visit http://www.telenav.com from time to time to review the then current version of this Agreement and of the privacy policy.

1. Safe and Lawful Use

You acknowledge that devoting attention to the TeleNav Software may pose a risk of injury or death to you and others in situations that otherwise require your undivided attention, and you therefore agree to comply with the following when using the TeleNav Software:

- (a) observe all traffic laws and otherwise drive safely;
- (b) use your own personal judgment while driving. If you feel that a route suggested by the TeleNav Software instructs you to perform an unsafe or illegal maneuver, places you in an unsafe situation, or directs you into an area that you consider to be unsafe, do not follow such instructions;
- (c) do not input destinations, or otherwise manipulate the TeleNav Software, unless your vehicle is stationary and parked;
- (d) do not use the TeleNav Software for any illegal, unauthorized, unintended, unsafe, hazardous, or unlawful purposes, or in any manner inconsistent with this Agreement;
- (e) arrange all GPS and wireless devices and cables necessary for use of the TeleNav Software in a secure manner in your vehicle so that they will not interfere with your driving and will not prevent the operation of any safety device (such as an airbag).

You agree to indemnify and hold TeleNav harmless against all claims resulting from any dangerous or otherwise inappropriate use of the TeleNav Software in any moving vehicle, including as a result of your failure to comply with the directions above.

2. Account Information

You agree: (a) when registering the TeleNav Software, to provide TeleNav with true, accurate, current, and complete information about yourself, and (b) to inform TeleNav promptly of any changes to such information, and to keep it true, accurate, current and complete.

3. Software License

Subject to your compliance with the terms of this Agreement, TeleNav hereby grants to you a personal, non-exclusive, non-transferable license (except as expressly permitted below in connection with your permanent transfer of the TeleNav Software license), without the right to sublicense, to use the TeleNav Software (in object code form only) in order to access and use the TeleNav Software. This license shall terminate upon any termination or expiration of this Agreement. You agree that you will use the TeleNav Software only for your personal business or leisure purposes. and not to provide commercial navigation services to other parties.

3.1 License Limitations

- (a) reverse engineer, decompile, disassemble, translate, modify, alter or otherwise change the TeleNav Software or any part thereof; (b) attempt to derive the source code, audio library or structure of the TeleNav Software without the prior express written consent of TeleNav;
 - (c) remove from the TeleNav Software, or alter, any of TeleNav's or its suppliers' trademarks, trade names, logos, patent or copyright notices, or other notices or markings; (d)

distribute, sublicense or otherwise transfer the TeleNav Software to others, except as part of your permanent transfer of the TeleNav Software; or **(e)** use the TeleNav Software in any manner that

I. infringes the intellectual property or proprietary rights, rights of publicity or privacy or other rights of any party,

ii. violates any law, statute, ordinance or regulation, including but not limited to laws and regulations related to spamming, privacy, consumer and child protection, obscenity or defamation, or

iii. is harmful, threatening, abusive, harassing, tortuous, defamatory, vulgar, obscene, libelous, or otherwise objectionable; and (f) lease, rent out, or otherwise permit unauthorized access by third parties to the TeleNav Software without advanced written permission of TeleNav.

4. Disclaimers

To the fullest extent permissible pursuant to applicable law, in no event will TeleNay, its licensors and suppliers, or agents or employees of any of the foregoing, be liable for any decision made or action taken by you or anyone else in reliance on the information provided by the TeleNav Software. TeleNav also does not warrant the accuracy of the map or other data used for the TeleNav Software. Such data may not always reflect reality due to, among other things, road closures, construction, weather, new roads and other changing conditions. You are responsible for the entire risk arising out of your use of the TeleNav Software. For example but without limitation, you agree not to rely on the TeleNav Software for critical navigation in areas where the well-being or survival of you or others

- is dependent on the accuracy of navigation, as the maps or functionality of the TeleNav Software are not intended to support such high risk applications, especially in more remote geographical areas.
- TELENAV EXPRESSLY DISCLAIMS
 AND EXCLUDES ALL WARRANTIES IN
 CONNECTION WITH THE TELENAV
 SOFTWARE, WHETHER STATUTORY,
 EXPRESS OR IMPLIED, INCLUDING ALL
 WARRANTIES WHICH MAY ARISE
 FROM COURSE OF DEALING, CUSTOM
 OR TRADE AND INCLUDING, BUT NOT
 LIMITED TO, THE IMPLIED
 WARRANTIES OF MERCHANTABILITY,
 FITNESS FOR A PARTICULAR
 PURPOSE AND NON-INFRINGEMENT
 OF THIRD PARTY RIGHTS WITH
 RESPECT TO THE TELENAV
 SOFTWARE.
- Certain jurisdictions do not permit the disclaimer of certain warranties, so this limitation may not apply to you.

5. Limitation of Liability

TO THE EXTENT PERMITTED UNDER APPLICABLE LAW. UNDER NO CIRCUMSTANCES SHALL TELENAV OR ITS LICENSORS AND SUPPLIERS BE LIABLE TO YOU OR TO ANY THIRD PARTY FOR ANY INDIRECT, INCIDENTAL, CONSEQUENTIAL, SPECIAL OR EXEMPLARY DAMAGES (INCLUDING IN EACH CASE, BUT NOT LIMITED TO, DAMAGES FOR THE INABILITY TO USE THE EQUIPMENT OR ACCESS DATA, LOSS OF DATA, LOSS OF BUSINESS, LOSS OF PROFITS, BUSINESS INTERRUPTION OR THE LIKE) ARISING OUT OF THE USE OF OR INABILITY TO USE THE TELENAV SOFTWARE, EVEN IF TELENAV HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. NOTWITHSTANDING ANY DAMAGES THAT YOU MIGHT INCUR FOR ANY

REASON WHATSOEVER (INCLUDING, WITHOUT LIMITATION, ALL DAMAGES REFERENCED HEREIN AND ALL DIRECT OR GENERAL DAMAGES IN CONTRACT, TORT (INCLUDING NEGLIGENCE) OR OTHERWISE), THE ENTIRE LIABILITY OF TELENAV AND OF ALL OF TELENAV'S SUPPLIERS SHALL BE LIMITED TO THE AMOUNT ACTUALLY PAID BY YOU FOR THE TELENAV SOFTWARE. SOME STATES AND/OR JURISDICTIONS DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS OR EXCLUSIONS MAY NOT APPLY TO YOU.

6. Arbitration and Governing Law

You agree that any dispute, claim or controversy arising out of or relating to this Agreement or the TeleNav Software shall be settled by independent arbitration involving a neutral arbitrator and administered by the American Arbitration Association in the County of Santa Clara, California. The arbitrator shall apply the Commercial Arbitration Rules of the American Arbitration Association, and the judgment upon the award rendered by the arbitrator may be entered by any court having jurisdiction. Note that there is no judge or jury in an arbitration proceeding and the decision of the arbitrator shall be binding upon both parties. You expressly agree to waive your right to a jury trial. This Agreement and performance hereunder will be governed by and construed in accordance with the laws of the State of California, without giving effect to its conflict of law provisions. To the extent judicial action is necessary in connection with the binding arbitration, both TeleNav and you agree to submit to the exclusive jurisdiction of the courts of the County of Santa Clara, California. The United Nations Convention on Contracts for the International Sale of Goods shall not apply.

7. Assignment

You may not resell, assign, or transfer this Agreement or any of your rights or obligations, except in totality, in connection with your permanent transfer of the TeleNav Software, and expressly conditioned upon the new user of the TeleNav Software agreeing to be bound by the terms and conditions of this Agreement. Any such sale, assignment or transfer that is not expressly permitted under this paragraph will result in immediate termination of this Agreement, without liability to TeleNay, in which case you and all other parties shall immediately cease all use of the TeleNav Software. Notwithstanding the foregoing, TeleNav may assign this Agreement to any other party at any time without notice, provided the assignee remains bound by this Agreement.

8. Miscellaneous

8.1

This Agreement constitutes the entire agreement between TeleNav and you with respect to the subject matter hereof.

8.2

Except for the limited licenses expressly granted in this Agreement, TeleNav retains all right, title and interest in and to the TeleNav Software, including without limitation all related intellectual property rights. No licenses or other rights which are not expressly granted in this Agreement are intended to, or shall be, granted or

conferred by implication, statute, inducement, estoppel or otherwise, and TeleNav and its suppliers and licensors hereby reserve all of their respective rights other than the licenses explicitly granted in this Agreement.

8.3

By using the TeleNav Software, you consent to receive from TeleNav all communications, including notices, agreements, legally required disclosures or other information in connection with the TeleNav Software (collectively, "Notices") electronically. TeleNav may provide such Notices by posting them on TeleNav's Website or by downloading such Notices to your wireless device. If you desire to withdraw your consent to receive Notices electronically, you must discontinue your use of the TeleNav Software.

8.4

TeleNav's or your failure to require performance of any provision shall not affect that party's right to require performance at any time thereafter, nor shall a waiver of any breach or default of this Agreement constitute a waiver of any subsequent breach or default or a waiver of the provision itself.

8.5

If any provision herein is held unenforceable, then such provision will be modified to reflect the intention of the parties, and the remaining provisions of this Agreement will remain in full force and effect.

8.6

The headings in this Agreement are for convenience of reference only, will not be deemed to be a part of this Agreement, and will not be referred to in connection with the construction or interpretation of this Agreement. As used in this Agreement, the words "include" and "including" and variations thereof, will not be deemed to be terms of limitation, but rather will be deemed to be followed by the words "without limitation".

9. Other Vendors Terms and Conditions

The Telenav Software utilizes map and other data licensed to Telenav by third party vendors for the benefit of you and other end users. This Agreement includes end-user terms applicable to these companies (included at the end of this Agreement), and thus your use of the Telenav Software is also subject to such terms. You agree to comply with the following additional terms and conditions, which are applicable to Telenav's third party vendor licensors.

9.1 End User Terms Required by HERE North America, LLC

The data ("Data") is provided for your personal, internal use only and not for resale. It is protected by copyright, and is subject to the following terms and conditions which are agreed to by you, on the one hand, and Telenav ("Telenav") and its licensors (including their licensors and suppliers) on the other hand.

© 2013 HERE. All rights reserved.

The Data for areas of Canada includes information taken with permission from Canadian authorities, including: © Her Majesty the Queen in Right of Canada, © Queen's Printer for Ontario, © Canada Post Corporation, GeoBase®, © Department of Natural Resources Canada.

HERE holds a non-exclusive license from the United States Postal Service® to publish and sell ZIP+4® information.

©United States Postal Service® 2014. Prices are not established, controlled or approved by the United States Postal Service®. The following trademarks and registrations are owned by the USPS: United States Postal Service, USPS, and ZIP+4

The Data for Mexico includes certain data from Instituto Nacional de Estadística y Geografía.

9.2 End User Terms Required by NAV2 (Shanghai) Co., Ltd

The data ("Data") is provided for your personal, internal use only and not for resale. It is protected by copyright, and is subject to the following terms and conditions which are agreed to by you, on the one hand, and NAV2 (Shanghai) Co., Ltd ("NAV2") and its licensors (including their licensors and suppliers) on the other hand. 20xx. All rights reserved

Terms and Conditions

Permitted Use. You agree to use this Data together with the Telenav Software solely for the internal business and personal purposes for which you were licensed, and not for service bureau, time-sharing or other similar purposes. Accordingly, but subject to the restrictions set forth in the following paragraphs, you agree not to otherwise reproduce, copy, modify, decompile, disassemble, create any derivative works of, or reverse engineer any portion of this Data, and may not transfer or distribute it in any form, for any purpose, except to the extent permitted by mandatory laws.

Restrictions. Except where you have been specifically licensed to do so by Telenay, and without limiting the preceding paragraph, you may not use this Data (a) with any products, systems, or applications installed or otherwise connected to or in communication with vehicles, capable of vehicle navigation, positioning, dispatch, real time route guidance, fleet management or similar applications; or (b) with or in communication with any positioning devices or any mobile or wireless-connected electronic or computer devices, including without limitation cellular phones, palmtop and handheld computers, pagers, and personal digital assistants or PDAs.

Warning. The Data may contain inaccurate or incomplete information due to the passage of time, changing circumstances, sources used and the nature of collecting comprehensive geographic data, any of which may lead to incorrect results.

No Warranty. This Data is provided to you "as is," and you agree to use it at your own risk. Telenav and its licensors (and their licensors and suppliers) make no guarantees, representations or warranties of any kind, express or implied, arising by law or otherwise, including but not limited to, content, quality, accuracy, completeness, effectiveness, reliability, fitness for a particular purpose, usefulness, use or results to be obtained from this Data, or that the Data or server will be uninterrupted or error-free.

Disclaimer of Warranty: TELENAV AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) DISCLAIM ANY WARRANTIES, EXPRESS OR IMPLIED, OF QUALITY, PERFORMANCE, MERCHANTABILITY, FITNESS FOR A

PARTICULAR PURPOSE OR NON-INFRINGEMENT. Some States, Territories and Countries do not allow certain warranty exclusions, so to that extent the above exclusion may not apply to you.

Disclaimer of Liability: TELENAV AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) SHALL NOT BE LIABLE TO YOU: IN RESPECT OF ANY CLAIM, DEMAND OR ACTION, IRRESPECTIVE OF THE NATURE OF THE CAUSE OF THE CLAIM, DEMAND OR ACTION ALLEGING ANY LOSS, INJURY OR DAMAGES. DIRECT OR INDIRECT. WHICH MAY RESULT FROM THE USE OR POSSESSION OF THE INFORMATION; OR FOR ANY LOSS OF PROFIT, REVENUE. CONTRACTS OR SAVINGS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF OR INABILITY TO USE THIS INFORMATION. ANY DEFECT IN THE INFORMATION, OR THE BREACH OF THESE TERMS OR CONDITIONS, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY, EVEN IF TELENAV OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. Some States, Territories and Countries do not allow certain liability exclusions or damages limitations, so to that extent the above may not apply to you.

Export Control. You shall not export from anywhere any part of the Data or any direct product thereof except in compliance with, and with all licenses and approvals required under, applicable export laws, rules and regulations, including but not limited to the laws, rules and regulations administered by the Office of Foreign Assets Control of the U.S. Department of Commerce and the Bureau of Industry and Security of the U.S. Department of Commerce. To the extent that any such

export laws, rules or regulations prohibit HERE from complying with any of its obligations hereunder to deliver or distribute Data, such failure shall be excused and shall not constitute a breach of this Agreement.

Entire Agreement. These terms and conditions constitute the entire agreement between Telenav (and its licensors, including their licensors and suppliers) and you pertaining to the subject matter hereof, and supersedes in their entirety any and all written or oral agreements previously existing between us with respect to such subject matter.

Governing Law. The above terms and conditions shall be governed by the laws of the State of Illinois [insert "Netherlands" where European HERE Data is used], without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. You agree to submit to the jurisdiction of the State of Illinois [insert "The Netherlands" where European HERE Data is used] for any and all disputes, claims and actions arising from or in connection with the Data provided to you hereunder.

Government End Users. If the Data is being acquired by or on behalf of the United States government or any other entity seeking or applying rights similar to those customarily claimed by the United States government, this Data is a "commercial item" as that term is defined at 48 C.F.R. ("FAR") 2.101, is licensed in accordance with these End-User Terms, and each copy of Data delivered or otherwise furnished shall be marked and embedded as appropriate with the following "Notice of Use," and shall be treated in accordance with such Notice:

NOTICE OF USE

CONTRACTOR (MANUFACTURER/ SUPPLIER) NAME: HERE

CONTRACTOR (MANUFACTURER/ SUPPLIER) ADDRESS: c/o Nokia, 425 West Randolph Street, Chicago, Illinois 60606

This Data is a commercial item as defined in FAR 2.101 and is subject to these End-User Terms under which this Data was provided.

 \odot 1987 – 2014 HERE – All rights reserved.

If the Contracting Officer, federal government agency, or any federal official refuses to use the legend provided herein, the Contracting Officer, federal government agency, or any federal official must notify HERE prior to seeking additional or alternative rights in the Data.

I. US/Canada Territory

A. United States Data. The End-User Terms for any Application containing Data for the United States shall contain the following notices:

"HERE holds a non-exclusive license from the United States Postal Service® to publish and sell ZIP+4® information."

"©United States Postal Service® 20XX. Prices are not established, controlled or approved by the United States Postal Service®. The following trademarks and registrations are owned by the USPS: United States Postal Service, USPS, and ZIP+4."

- B. Canada Data. The following provisions apply to the Data for Canada, which may include or reflect data from third party licensors ("Third Party Data"), including Her Majesty the Queen in Right of Canada ("Her Majesty"), Canada Post Corporation ("Canada Post") and the Department of Natural Resources of Canada ("NRCan"):
 - 1. Disclaimer and Limitation: Client agrees that its use of the Third Party Data is subject to the following provisions:
 - a. Disclaimer: The Third Party Data is licensed on an "as is" basis. The licensors of such data, including Her Majesty, Canada Post and NRCan, make no guarantees, representations or warranties respecting such data, either express or implied, arising by law or otherwise, including but not limited to, effectiveness, completeness, accuracy or fitness for a particular purpose.
 - b. Limitation on Liability: The Third Party Data licensors, including Her Majesty, Canada Post and NRCan, shall not be liable: (i) in respect of any claim, demand or action, irrespective of the nature of the cause of the claim, demand or action alleging any loss, injury or damages, direct or indirect, which may result from the use or possession of such Data; or (ii) in any way for loss of revenues or contracts, or any other consequential loss of any kind resulting from any defect in the Data.

- 2. Copyright Notice: In connection with each copy of all or any portion of the Data for the Territory of Canada, Client shall affix in a conspicuous manner the following copyright notice on at least one of: (i) the label for the storage media of the copy; (ii) the packaging for the copy; or (iii) other materials packaged with the copy, such as user manuals or end user license agreements: "This data includes information taken with permission from Canadian authorities, including © Her Majesty the Queen in Right of Canada, © Queen's Printer for Ontario, © Canada Post Corporation, GeoBase®, © The Department of Natural Resources Canada. All rights reserved."
- 3. End-User Terms: Except as otherwise agreed by the parties, in connection with the provision of any portion of the Data for the Territory of Canada to End-Users as may be authorized under the Agreement, Client shall provide such End-Users, in a reasonably conspicuous manner, with terms (set forth with other end user terms required to be provided under the Agreement, or as otherwise may be provided, by Client) which shall include the following provisions on behalf of the Third Party Data licensors, including Her Majesty, Canada Post and NRCan:

The Data may include or reflect data of licensors, including Her Majesty the Queen in the Right of Canada ("Her Majesty"), Canada Post Corporation ("Canada Post") and the Department of Natural Resources Canada ("NRCan"). Such data is licensed on an "as is" basis. The licensors, including Her Majesty, Canada Post and NRCan, make no guarantees, representations or warranties respecting such data,

either express or implied, arising by law or otherwise, including but not limited to, effectiveness, completeness, accuracy or fitness for a particular purpose. The licensors, including Her Majesty, Canada Post and NRCan, shall not be liable in respect of any claim, demand or action, irrespective of the nature of the cause of the claim, demand or action alleging any loss, injury or damages, direct or indirect, which may result from the use or possession of the data or the Data. The licensors, including Her Majesty, Canada Post and NRCan, shall not be liable in any way for loss of revenues or contracts, or any other consequential loss of any kind resulting from any defect in the data or the Data.

End User shall indemnify and save harmless the licensors, including Her Majesty, Canada Post and NRCan, and their officers, employees and agents from and against any claim, demand or action, irrespective of the nature of the cause of the claim, demand or action, alleging loss, costs, expenses, damages or injuries (including injuries resulting in death) arising out of the use or possession of the data or the Data.

4. Additional Provisions: The terms contained in this Section are in addition to all of the rights and obligations of the parties under the Agreement. To the extent that any of the provisions of this Section are inconsistent with, or conflict with, any other provisions of the Agreement, the provisions of this Section shall prevail.

II. Mexico. The following provision applies to the Data for Mexico, which includes certain data from the Instituto Nacional de Estadística y Geografía ("INEGI"):

A. Any and all copies of the Data and/or packaging containing Data for Mexico shall contain the following notice: "Fuente: INEGI (Instituto Nacional de Estadística y Geografía)"

III. Latin America Territory

A. Third Party Notices. Any and all copies of the Data and/or packaging relating thereto shall include the respective Third Party Notices set forth below and used as described below corresponding to the Territory (or portion thereof) included in such copy:

Territory Notice

Argen- IGN "INSTITUTO

tina GEOGRAFICO NACIONAL

ARGENTINO"

Ecuador "INSTITUTO GEOGRAFICO

MILITAR DEL ECUADOR AUTORIZACION Nº IGM-2011-01- PCO-01 DEL 25 DE

ENERO DE 2011"

"source: © IGN 2009 - BD

TOPO®"

Guadeloupe, French Guiana and

Marti- "Fuente: INEGI (Instituto nique Nacional de Estadística y

Mexico Geografía)"

IV. Middle East Territory

A. Third Party Notices. Any and all copies of the Data and/or packaging relating thereto shall include the respective Third Party Notices set forth below and used as described below corresponding to the Territory (or portion thereof) included in such copy:

Country Notice

Jordan

"© Royal Jordanian Geographic Centre". The foregoing notice requirement for Jordan Data is a material term of the Agreement. If Client or any of its permitted sublicensees (if any) fail to meet such requirement, HERE shall have the right to terminate Client's license with respect to the Jordan Data.

B. Jordan Data. Client and its permitted sublicensees (if any) are restricted from licensing and/or otherwise distributing HERE's database for the country of Jordan ("Jordan Data") for use in Enterprise Applications to (i) non-Jordanian entities for use of the Jordan Data solely in Jordan or (ii) Jordan-based customers. In addition, Client, its permitted sublicensees (if any) and End-Users are restricted from using the Jordan Data in Enterprise Applications if such party is (i) a non-Jordanian entity using the Jordan Data solely in Jordan or (ii) a Jordan-based customer. For purposes of the foregoing, "Enterprise Applications" shall mean Geomarketing applications, GIS applications, mobile business asset management applications, call center applications, telematics applications, public organization Internet applications or for providing geocoding services.

V. Europe Territory

A. Use of Certain Traffic Codes in Europe

1. General Restrictions Applicable to Traffic Codes. Client acknowledges and agrees that in certain countries of the Europe Territory, Client will need to obtain rights directly from third party RDS-TMC code providers to receive and use the Traffic Codes in the Data and to deliver to End-Users Transactions in any way derived from or based on such Traffic Codes. For such countries, HERE shall deliver the Data incorporating Traffic Codes to Client only after receiving certification from Client of its having obtained such rights.

2. Display of Third Party Rights Legends for Belgium. Client shall, for each Transaction that uses Traffic Codes for Belgium, provide the following notice to the End-User: "Traffic Codes for Belgium are provided by the Ministerie van de Vlaamse Gemeenschap and the Ministèrie de l'Equipement et des Transports."

B. Paper Maps. With respect to any license granted to Client relating to making, selling or distributing paper maps (i.e., a map fixed on a paper or paper-like medium): (a) such license with respect to Data for the Territory of Great Britain is conditioned on Client's entering into and complying with a separate written agreement with the Ordnance Survey ("OS") to create and sell paper maps, Client's paying to the OS any and all applicable paper map royalties, and Client's complying with the OS copyright notice requirements; (b) such license for selling or otherwise distributing for charge with respect to Data for the Territory of Czech Republic

is conditioned on Client's obtaining prior written consent from Kartografie a.s.; (c) such license for selling or distributing with respect to Data for the Territory of Switzerland is conditioned on Client's obtaining a permit from Bundesamt für Landestopografie of Switzerland; (d) Client is restricted from using Data for the Territory of France to create paper maps with a scale between 1:5,000 and 1:250,000; and (e) Client is restricted from using any Data to create, sell or distribute paper maps that are the same or substantially similar, in terms of data content and specific use of color, symbols and scale, to paper maps published by the European national mapping agencies, including without limitation, Landervermessungämter of Germany, Topografische Dienst of the Netherlands, Nationaal Geografisch Instituut of Belgium, Bundesamt für Landestopografie of Switzerland, Bundesamt für Eich-und Vermessungswesen of Austria, and the National Land Survey of Sweden.

C. OS Enforcement. Without limiting Section IV(B) above, with respect to Data for the Territory of Great Britain, Client acknowledges and agrees that the Ordnance Survey ("OS") may bring a direct action against Client to enforce compliance with the OS copyright notice (see Section IV(D) below) and paper map requirements (see Section IV(B) above) contained in this Agreement.

D. Third Party Notices. Any and all copies of the Data and/or packaging relating thereto shall include the respective Third Party Notices set forth below and used as described below corresponding to the Territory (or portion thereof) included in such copy:

Country(ies) Notice

Austria "© Bundesamt für Eich-

und Vermessungswesen"

Croatia Cyprus, Estonia,

Latvia, Lithuania, Moldova, Poland, Slovenia and/or Ukraine

"© EuroGeographics"

France "source: © IGN 2009 – BD

TOPO®"

Germany "Die Grundlagendaten

wurden mit Genehmigung der zuständigen Behörden

entnommen"

Great Britain "Contains Ordnance

Survey data © Crown copyright and database right 2010 Contains Royal Mail data © Royal Mail copyright and database

right 2010"

Greece "Copyright Geomatics

Ltd."

Hungary "Copyright © 2003; Top-

Map Ltd."

Italy "La Banca Dati Italiana è

stata prodotta usando quale riferimento anche cartografia numerica ed al tratto prodotta e fornita dalla Regione Toscana."

Norway "Copyright © 2000;

Norwegian Mapping

Authority"

Portugal "Source: IgeoE – Portugal"

Spain "Información geográfica

propiedad del CNIG"

Sweden "Based upon electronic

data © National Land Survey Sweden"

Switzerland "Topografische

Grundlage: © Bundesamt für Landestopographie.

E. Respective Country Distribution. Client acknowledges that HERE has not received approvals to distribute map data for the following countries in such respective countries: Albania, Belarus, Kyrgyzstan, Moldova and Uzbekistan. HERE may update such list from time to time. The license rights granted to Client under this TL with respect to the Data for such countries are contingent upon Client's compliance with all applicable laws and regulations, including, without limitation, any required licenses or approvals to distribute the Application incorporating such Data in such respective countries.

VI. Australia Territory

A. Third Party Notices. Any and all copies of the Data and/or packaging relating thereto shall include the respective Third Party Notices set forth below and used as described below corresponding to the Territory (or portion thereof)

included in such copy:

Copyright. Based on data provided under license from PSMA Australia Limited (www.psma.com.au).

Product incorporates data which is © 20XX Telstra Corporation Limited, GM Holden Limited, Intelematics Australia Pty Ltd and Continental Pty Ltd.

B. Third Party Notices for Australia. In addition to the foregoing, the End-User Terms for any Application containing RDS-TMC Traffic Codes for Australia shall contain the following notice: "Product incorporates traffic location codes which is © 20XX Telstra Corporation Limited and its licensors."

AT&T Vehicle Network Carrier Telematics Disclosure

END USER FOR PURPOSES OF THIS SECTION MEANS YOU AND YOUR HEIRS. EXECUTORS. LEGAL PERSONAL REPRESENTATITVES AND PERMITED ASSIGNS. FOR PURPOSES OF THIS SECTION "UNDERLYING WIRELESS SERVICE CARRIER" INCLUDES ITS AFFILIATES AND CONTRACTORS AND THEIR RESPECTIVE OFFICERS. DIRECTORS, EMPLOYEES, SUCCESSORS AND ASSIGNS. END USER HAS NO CONTRACTUAL RELATIONSHIP WITH THE UNDERLYING WIRELESS SERVICE CARRIER AND END USER IS NOT A THIRD PARTY BENEFICIARY OF ANY AGREEMENT BETWEEN FORD AND UNDERLYING CARRIER. END USER UNDERSTANDS AND AGREES THAT THE UNDERLYING CARRIER HAS NO LEGAL, EQUITABLE, OR OTHER LIABILITY OF ANY KIND TO END USER. IN ANY EVENT. REGARDLESS OF THE FORM OF THE ACTION, WHETHER FOR BREACH OF CONTRACT, WARRANTY, NEGLIGENCE, STRICT LIABILITY IN TORT OR OTHERWISE, END USER'S EXCLUSIVE REMEDY FOR CLAIMS ARISING IN ANY WAY IN CONNECTION WITH THIS AGREEMENT, FOR ANY CAUSE WHATSOEVER, INCLUDING BUT NOT LIMITED TO ANY FAILURE OR

DISRUPTION OF SERVICE PROVIDED HEREUNDER, IS LIMITED TO PAYMENT OF DAMAGES IN AN AMOUNT NOT TO EXCEED THE AMOUNT PAID BY END USER FOR THE SERVICES DURING THE TWO-MONTH PERIOD PRECEDING THE DATE THE CLAIM AROSE.

- (ii) END USER AGREES TO INDEMNIFY AND HOLD HARMLESS THE UNDERLYING WIRELESS SERVICE CARRIER AND ITS OFFICERS, EMPLOYEES, AND AGENTS AGAINST ANY AND ALL CLAIMS. INCLUDING WITHOUT LIMITATION CLAIMS FOR LIBEL, SLANDER, OR ANY PROPERTY DAMAGE, PERSONAL INJURY OR DEATH, ARISING IN ANY WAY, DIRECTLY OR INDIRECTLY, IN CONNECTION WITH THIS AGREEMENT OR THE USE, FAILURE TO USE, OR INABILITY TO USE THE DEVICE EXCEPT WHERE THE CLAIMS RESULT FROM THE UNDERLYING CARRIER'S GROSS NEGLIGENCE OR WILLFUL MISCONDUCT. THIS INDEMNITY WILL SURVIVE THE TERMINATION OF THE AGREEMENT.
- (iii) END USER HAS NO PROPERTY RIGHT IN ANY NUMBER ASSIGNED TO THE DEVICE.
- (iv) END USER UNDERSTANDS THAT FORD AND THE UNDERLYING CARRIER CANNOT GUARANTY THE SECURITY OF WIRELESS TRANSMISSIONS, AND WILL NOT BE LIABLE FOR ANY LACK OF SECURITY RELATING TO THE USE OF THE SERVICES

THE SERVICE IS FOR [END USER'S] USE ONLY AND END USER MAY NOT RESELL THE SERVICE TO ANY OTHER PARTY END USER UNDERSTANDS THAT THE UNDERLYING CARRIER DOES NOT GUARANTEE ANY END USER UNINTERRUPTED SERVICE OR COVERAGE. THE UNDERLYING CARRIER DOES NOT WARRANT THAT END USERS CAN OR WILL BE LOCATED USING THE SERVICE. THE UNDERLYING CARRIER

MAKES NO WARRANTY, EXPRESS OR IMPLIED, OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, SUITABILITY, OR PERFORMANCE REGARDING ANY SERVICES OR GOODS. AND IN NO EVENT SHALL AT&T BE LIABLE, WHETHER OR NOT DUE TO ITS OWN NEGLIGENCE, FOR ANY: (A) ACT OR OMISSION OF A THIRD PARTY: (B) MISTAKES, OMISSIONS, INTERRUPTIONS, ERRORS, FAILURES TO TRANSMIT, DELAYS, OR DEFECTS IN THE SERVICE PROVIDED BY OR THROUGH THE UNDERLYING CARRIER; (C) DAMAGE OR INJURY CAUSED BY SUSPENSION OR TERMINATION BY THE UNDERLYING CARRIER; OR (D) DAMAGE OR INJURY CAUSED BY A FAILURE OR DELAY IN CONNECTING A CALL TO ANY ENTITY. INCLUDING 911 OR ANY OTHER EMERGENCY SERVICE. TO THE FULL EXTENT ALLOWED BY LAW. THE END USER RELEASES. INDEMNIFIES AND HOLDS THE UNDERLYING CARRIER HARMLESS FROM AND AGAINST ANY AND ALL CLAIMS OF ANY PERSON OR ENTITY FOR DAMAGES OF ANY NATURE ARISING IN ANY WAY FROM OR RELATING TO. DIRECTLY OR INDIRECTLY, SERVICES PROVIDED BY THE UNDERLYING CARRIER OR ANY PERSON'S USE THEREOF, INCLUDING CLAIMS ARISING IN WHOLE OR IN PART FROM THE ALLEGED NEGLIGENCE OF THE UNDERLYING CARRIER.

VII. China Territory

Personal Use Only

You agree to use this Data together with [insert name of Client Application] for the solely personal, non-commercial purposes for which you were licensed, and not for service bureau, time-sharing or other similar purposes. Accordingly, but subject to the restrictions set forth in the following paragraphs, you may copy this Data only as necessary for your personal use to (i)

view it, and (ii) save it, provided that you do not remove any copyright notices that appear and do not modify the Data in any way. You agree not to otherwise reproduce, copy, modify, decompile, disassemble or reverse engineer any portion of this Data, and may not transfer or distribute it in any form, for any purpose, except to the extent permitted by mandatory laws.

Restrictions

Except where you have been specifically licensed to do so by NAV2, and without limiting the preceding paragraph, you may not (a) use this Data with any products, systems, or applications installed or otherwise connected to or in communication with vehicles, capable of vehicle navigation, positioning, dispatch, real time route guidance, fleet management or similar applications; or (b) with or in communication with any positioning devices or any mobile or wireless-connected electronic or computer devices, including without limitation cellular phones, palmtop and handheld computers, pagers, and personal digital assistants or PDAs. You agree to cease using this Data if you fail to comply with these terms and conditions.

Limited Warranty

NAV2 warrants that (a) the Data will perform substantially in accordance with the accompanying written materials for a period of ninety (90) days from the date of receipt, and (b) any support services provided by NAV2 shall be substantially as described in applicable written materials provided to you by NAV2, and NAV2's support engineers will make commercially reasonable efforts to solve any problem issues.

Customer Remedies

NAV2 and its suppliers' entire liability and your exclusive remedy shall be, at NAV2's sole discretion, either (a) return of the price paid, if any, or (b) repair or replacement of the Data that do not meet NAV2's Limited Warranty and that are returned to NAV2 with a copy of your receipt. This Limited Warranty is void if failure of the Data has resulted from accident, abuse, or misapplication. Any replacement Data will be warranted for the remainder of the original warranty period or thirty (30) days, whichever is longer. Neither these remedies nor any product support services offered by NAV2 are available without proof of purchase from an authorized international source.

No Other Warranty:

EXCEPT FOR THE LMITED WARRANTY SET FORTH ABOVE AND TO THE EXTENT PERMITTED BY APPLICABLE LAW, NAV2 AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) DISCLAIM ANY WARRANTIES, EXPRESS OR IMPLIED, OF QUALITY, PERFORMANCE, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OWNERSHIP OR NON-INFRINGEMENT. Certain warranty exclusions may not be permitted under applicable law, so to that extent the above exclusion may not apply to you.

Limited Liability:

TO THE EXTENT PERMITTED BY APPLICABLE LAW, NAV2 AND ITS LICENSORS (INCLUDING THEIR LICENSORS AND SUPPLIERS) SHALL NOT BE LIABLE TO YOU: IN RESPECT OF ANY CLAIM, DEMAND OR ACTION, IRRESPECTIVE OF THE NATURE OF THE CAUSE OF THE CLAIM, DEMAND OR ACTION ALLEGING ANY LOSS, INJURY OR DAMAGES, DIRECT OR INDIRECT, WHICH MAY RESULT FROM THE USE OR POSSESSION OF THE INFORMATION; OR

FOR ANY LOSS OF PROFIT, REVENUE, CONTRACTS OR SAVINGS, OR ANY OTHER DIRECT, INDIRECT, INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF YOUR USE OF OR INABILITY TO USE THIS INFORMATION, ANY DEFECT IN THE INFROMATION, OR THE BREACH OF THESE TERMS OR CONDITIONS, WHETHER IN AN ACTION IN CONTRACT OR TORT OR BASED ON A WARRANTY, EVEN IF NAV2 OR ITS LICENSORS HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, UNDER NO CIRCUMSTANCES SHALL NAV2's OR ITS SUPPLIERS' LIABILITY HEREUNDER EXCEED THE PRICE PAID. Certain liability exclusions may not be permitted under applicable law, so to that extent the above exclusion may not apply to you.

Export Control

You agree not to export to anywhere any part of the Data provided to you or any direct product thereof except in compliance with, and with all licenses and approvals required under, applicable export laws, rules and regulations.

IP Protection

The Data are owned by NAV2 or its suppliers and are protected by applicable copyright and other intellectual property law and treaties. The Data are provided solely on the basis of a license to use, not sale.

Entire Agreement

These terms and conditions constitute the entire agreement between NAV2(and its licensors, including their licensors and suppliers) and you pertaining to the subject matter hereof, and supersedes in their entirety any and all written or oral agreements previously existing between us with respect to such subject matter.

Governing Law.

The above terms and conditions shall be governed by the laws of the People's Republic of China, without giving effect to (i) its conflict of laws provisions, or (ii) the United Nations Convention for Contracts for the International Sale of Goods, which is explicitly excluded. Any dispute arising from or in connection with the Data provided to you hereunder shall be submitted to the Shanghai International Economic and Trade Arbitration Commission for arbitration.

Gracenote® Copyright

CD and music-related data from Gracenote, Inc., copyright©

2000-2007 Gracenote. Gracenote Software, copyright © 2000-2007 Gracenote. This product and service may practice one or more of the following U.S. Patents 5,987,525; 6,061,680; 6,154,773; 6,161,132; 6,230,192; 6,230,207; 6.240,459; 6,330,593 and other patents issued or pending. Some services supplied under license from Open Globe, Inc. for U.S. Patent 6,304,523.

Gracenote and CDDB are registered trademarks of Gracenote. The Gracenote logo and logotype, and the "Powered by Gracenote™" logo are trademarks of Gracenote.

Gracenote® End User License Agreement (EULA)

This device contains software from Gracenote, Inc. of 2000 Powell Street Emeryville, California 94608 ("Gracenote").

The software from Gracenote (the "Gracenote Software") enables this device to do disc and music file identification and obtain music-related information, including name, artist, track, and title information ("Gracenote Data") from online servers

("Gracenote Servers"), and to perform other functions. You may use Gracenote Data only by means of the intended End User functions of this device. This device may contain content belonging to Gracenote's providers. If so, all of the restrictions set forth herein with respect to Gracenote Data shall also apply to such content and such content providers shall be entitled to all of the benefits and protections set forth herein that are available to Gracenote. You agree that you will use the content from Gracenote ("Gracenote Content"), Gracenote Data, the Gracenote Software, and Gracenote Servers for your own personal, non-commercial use only. You agree not to assign, copy, transfer or transmit the Gracenote Content, Gracenote Software or any Gracenote Data (except in a Tag associated with a music file) to any third party. YOU AGREE NOT TO USE OR EXPLOIT GRACENOTE CONTENT. GRACENOTE DATA, THE GRACENOTE SOFTWARE, OR GRACENOTE SERVERS. EXCEPT AS EXPRESSLY PERMITTED HEREIN.

You agree that your non-exclusive licenses to use the Gracenote Content, Gracenote Data, the Gracenote Software, and Gracenote Servers will terminate if you violate these restrictions. If your licenses terminate, you agree to cease any and all use of the Gracenote Content, Gracenote Data, the Gracenote Software, and Gracenote Servers.

Gracenote, respectively, reserve all rights in Gracenote Data, the Gracenote Software, and the Gracenote Servers and Gracenote Content, including all ownership rights. Under no circumstances will either Gracenote become liable for any payment to you for any information that you provide,

including any copyrighted material or music file information. You agree that Gracenote may enforce its respective rights, collectively or separately, under this agreement against you, directly in each company's own name.

Gracenote uses a unique identifier to track queries for statistical purposes. The purpose of a randomly assigned numeric identifier is to allow Gracenote to count queries without knowing anything about who you are. For more information, see the web page at www.gracenote.com for the Gracenote Privacy Policy.

THE GRACENOTE SOFTWARE, EACH ITEM OF GRACENOTE DATA AND THE GRACENOTE CONTENT ARE LICENSED TO YOU "AS IS". NEITHER GRACENOTE MAKES ANY REPRESENTATIONS OR WARRANTIES, EXPRESS OR IMPLIED. REGARDING THE ACCURACY OF ANY GRACENOTE DATA FROM THE GRACENOTE SERVERS OR GRACENOTE CONTENT. GRACENOTE COLLECTIVELY AND SEPARATELY RESERVE THE RIGHT TO DELETE DATA AND/OR CONTENT FROM THE COMPANIES' RESPECTIVE SERVERS OR, IN THE CASE OF GRACENOTE. CHANGE DATA CATEGORIES FOR ANY CAUSE THAT GRACENOTE DEEMS SUFFICIENT. NO WARRANTY IS MADE THAT EITHER GRACENOTE CONTENT OR THE GRACENOTE SOFTWARE OR GRACENOTE SERVERS ARE ERROR-FREE OR THAT THE FUNCTIONING OF THE GRACENOTE SOFTWARE OR GRACENOTE SERVERS WILL BE UNINTERRUPTED. GRACENOTE IS NOT OBLIGATED TO PROVIDE YOU WITH ANY ENHANCED OR ADDITIONAL DATA TYPES THAT GRACENOTE MAY CHOOSE TO PROVIDE IN THE FUTURE AND IS FREE TO DISCONTINUE ITS ONLINE SERVICES AT ANY TIME, GRACENOTE DISCLAIM ALL WARRANTIES EXPRESS OR IMPLIED. INCLUDING, BUT NOT LIMITED TO,

IMPLIED WARRANTIES OF
MERCHANTABILITY, FITNESS FOR A
PARTICULAR PURPOSE, TITLE, AND
NON-INFRINGEMENT. NEITHER
GRACENOTE WARRANTS THE RESULTS
THAT WILL BE OBTAINED BY YOUR USE
OF THE GRACENOTE SOFTWARE OR ANY
GRACENOTE SERVER. IN NO CASE WILL
GRACENOTE BE LIABLE FOR ANY
CONSEQUENTIAL OR INCIDENTAL
DAMAGES OR FOR ANY LOST PROFITS
OR LOST REVENUES FOR ANY REASON
WHATSOEVER. © Gracenote 2007.

Taiwan Territory

According to the "Technical Specifications for Low Power Radio Frequency Equipment" formulated by the National Communications and Communication Committee of the Executive Yuan: 3.8.2. For the low-power radio frequency equipment that has obtained the verification certificate, the company, firm or user shall not change the frequency, increase the power or change the characteristics and functions of the original design without authorization.

The use of low-power radio frequency equipment must not affect flight safety and interfere with legal communications: when the system detects interference, immediately stop using it until there is no interference.

The aforementioned legal communication refers to the wireless communication operated in accordance with the provisions of the Telecommunications Management Law. Low-power radio frequency equipment needs to endure the interference of legal communication or industrial, scientific and medical radio wave radiation electrical equipment.

SUNA TRAFFIC CHANNEL – TERMS AND CONDITIONS

By activating, using and/or accessing the SUNA Traffic Channel, SUNA Predictive or other content or material provided by Intelematics (together, **SUNA Products and/or Services**), you must accept certain terms and conditions. The following is a brief summary of the terms and conditions that apply to you. To view the full terms and conditions relevant to your use of the SUNA Products and/or Services, please consult:

Website

www.sunatraffic.com.au/termsandconditions/

1. Acceptance

By using SUNA Products and/or Services, you will be deemed to have accepted and agreed to be bound by the terms and conditions fully detailed at:

Website

www.sunatraffic.com.au/termsandconditions/

2. Intellectual Property

SUNA Products and/or Services are for your personal use. You may not record, or retransmit the content, nor use the content in association with any other traffic information or route guidance service or device not approved by Intelematics. You obtain no right of ownership in any Intellectual Property Rights (including copyright) in the data that is used to provide SUNA Products and/or Services.

3. Appropriate Use

SUNA Products and/or Services are intended as an aid to personal motoring and travel planning, and do not provide comprehensive or accurate information on all occasions. On occasions, you may experience additional delay as a result of using SUNA Products and/or Services. You acknowledge that it is not intended, or suitable, for use in applications where time of arrival or driving directions may impact the safety of the public or yourself.

4. Use of SUNA Products and Services while driving

You, and other authorized drivers of the vehicle in which SUNA Products and/or Services are available or installed and active, remain at all times responsible for observing all relevant laws and codes of safe driving. In particular, you agree to only actively operate SUNA Products and/or Services when the Vehicle is at a complete stop and it is safe to do so.

5. Service Continuity and Reception of the SUNA Traffic Channel

We will use reasonable endeavors to provide the SUNA Traffic Channel 24 hours a day, 365 days a year. The SUNA Traffic Channel may occasionally be unavailable for technical reasons or for planned maintenance. We will try to perform maintenance at times when congestion is light. We reserve the right to withdraw SUNA Products and/or Services at any time.

Also, we cannot assure the uninterrupted reception of the SUNA Traffic Channel RDS-TMC signal at any particular location.

6. Limitation of Liability

Neither Intelematics (nor its suppliers or the manufacturer of your device (the "**Suppliers**")) shall be liable to you or to any third party for any damages either direct, indirect, incidental, consequential or otherwise arising out of the use of or inability to use SUNA Products and/or

Services even if Intelematics or a Supplier has been advised of the possibility of such damages. You also acknowledge that neither Intelematics nor any Supplier guarantees nor make any warranties that relate to the availability, accuracy or completeness of SUNA Products and/or Services, and to the extent which it is lawful to do so, both Intelematics and each Supplier excludes any warranties which might otherwise be implied by any State or Federal legislation in relation to SUNA Products and/or Services.

7. Please Note

Great care has been taken in preparing this manual. Constant product development may mean that some information is not entirely up-to-date. The information in this document is subject to change without notice.

EMISSION LAW

WARNING: Do not remove or alter the original equipment floor covering or insulation between it and the metal floor of the vehicle. The floor covering and insulation protect occupants of the vehicle from the engine and exhaust system heat and noise. On vehicles with no original equipment floor covering insulation, do not carry passengers in a manner that permits prolonged skin contact with the metal floor. Failure to follow these instructions may result in fire or personal injury.

U.S. federal laws and certain state laws prohibit removing or rendering inoperative emission control system components. Similar federal or provincial laws may apply in Canada. We do not approve of any vehicle modification without first determining applicable laws.



Tampering with emissions control systems including related sensors or the Diesel

Exhaust Fluid system can result in reduced engine power and the illumination of the service engine soon light.

Tampering With a Noise Control System

Federal laws prohibit the following acts:

- Removal or rendering inoperative by any person other than for purposes of maintenance.
- Repair or replacement of any device or element of the design incorporated into a new vehicle for the purpose of noise control prior to its sale or delivery to the ultimate purchaser or while it is in use.
- The use of the vehicle after any person removes or renders inoperative any device or element of the design.

The U.S. Environmental Protection Agency may presume to constitute tampering as follows:

- Removal of hood blanket, fender apron absorbers, fender apron barriers, underbody noise shields or acoustically absorptive material.
- Tampering or rendering inoperative the engine speed governor, to allow engine speed to exceed manufacturer specifications.

If the engine does not start, runs rough, experiences a decrease in engine performance, experiences excess fuel consumption or produces excessive exhaust smoke, check for the following:

- A plugged or disconnected air inlet system hose.
- A plugged engine air filter element.
- Water in the fuel filter and water separator.

- A clogged fuel filter.
- Contaminated fuel.
- Air in the fuel system, due to loose connections.
- An open or pinched sensor hose.
- Incorrect engine oil level.
- Incorrect fuel for climatic conditions.
- Incorrect engine oil viscosity for climactic conditions.

Note: Some vehicles have a lifetime fuel filter that is integrated with the fuel tank. Regular maintenance or replacement is not needed.

Note: If these checks do not help you correct the concern, have your vehicle checked as soon as possible.

Noise Emissions Warranty, Prohibited Tampering Acts and Maintenance

On January 1, 1978, Federal regulation became effective governing the noise emission on trucks over 10,000 lb (4,536 kg) Gross Vehicle Weight Rating (GVWR). The preceding statements concerning prohibited tampering acts and maintenance, and the noise warranty found in the Warranty Guide, are applicable to complete chassis cabs over 10,000 lb (4,536 kg) GVWR.

EXPORT UNIQUE OPTIONS

For your particular global region, your vehicle may be equipped with features and options that are different from the features and options that are described in this Owner's Manual. A market unique supplement may be supplied that complements this book. By referring to the market unique supplement, if provided, you can properly identify those features, recommendations and specifications that are unique to your vehicle. This Owner's

Manual is written primarily for the U.S. and Canadian markets. Features or equipment listed as standard may be different on units built for export. **Refer to this Owner's Manual for all other required information and warnings.**

WARRANTY INFORMATION

The following warranties may apply to your vehicle:

- New vehicle limited warranties.
- Emissions warranties, if applicable. (Note: Fully-electric vehicles are not eligible for emissions warranties.)
- Other warranties, if applicable.

Detailed warranty information specific to your vehicle can be found in the Warranty Guide at www.owner.ford.com.

The following California Warranty Statement, required by California regulations, applies to vehicles certified to California emissions standards and registered in a state that requires California emissions warranty. If applicable, additional California Emissions Warranties can be found in the Warranty Guide at www.owner.ford.com.

CALIFORNIA EMISSION CONTROL WARRANTY STATEMENT

YOUR WARRANTY RIGHTS AND OBLIGATIONS

The California Air Resources Board and Ford Motor Company are pleased to explain the emission control system warranty on your (year) vehicle. In California, new motor vehicles must be designated, built and equipped to meet

the State's stringent anti-smog standards. Ford Motor Company must warrant the emission control system on your vehicle for the periods of time listed below provided there has been no abuse, neglect or improper maintenance of your vehicle.

Your emission control system may include parts such as the carburetor or fuel-injection system, the ignition system, catalytic converter and engine computer. Also included may be hoses, belts, connectors and other emission-related assemblies. Where a warrantable condition exists, Ford Motor Company will repair your vehicle at no cost to you including diagnosis, parts and labor.

MANUFACTURER'S WARRANTY COVERAGE:

(For 1990 and subsequent model passenger cars, light-duty trucks, and medium-duty vehicles.)

- For 3 years or 50,000 miles (whichever occurs first);
- 1) If your vehicle fails a Smog Check inspection, all necessary repairs and adjustments will be made by Ford Motor Company to ensure that your emission control system PERFORMANCE WARRANTY.
- 2) If any emission-related part on your vehicle is defective, the part will be repaired or replaced by Ford Motor Company. This is your short-term emission control system DEFECTS WARRANTY.
- For 7 years or 70,000 miles (whichever occurs first);
- 1) If an emission-related part listed in this warranty booklet specially noted with coverage for 7 years or 70,000 miles is defective, the part will be repaired or replaced by Ford Motor Company. This is your long-term emission control system DEFECTS WARRANTY.

OWNER'S WARRANTY RESPONSIBILITIES:

- As the vehicle owner, you are responsible for the performance of the required maintenance listed in your owner's manual. Ford Motor Company recommends that you retain all receipts covering maintenance on your vehicle, but Ford Motor Company cannot deny warranty solely for the lack of receipts or for your failure to ensure the performance of all scheduled maintenance.
- You are responsible for presenting your vehicle to a Ford or Lincoln dealer as soon as a problem exists. The warranty repairs should be completed in a reasonable amount of time, not to exceed 30 days.
- As the vehicle owner, you should also be aware that Ford Motor Company may deny you warranty coverage if your vehicle or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

If you have any questions regarding your warranty rights and responsibilities, you should contact Ford Customer Service at 1-800-392-3673 or the California Air Resource Board at 9528 Telstar Avenue, El Monte, CA 91731.

Appendices

ELECTROMAGNETIC COMPATIBILITY


warning: Do not place objects or mount equipment on or near the airbag cover, on the side of the front or rear seatbacks, or in areas that may come into contact with a deploying airbag. Failure to follow these instructions may increase the risk of personal injury in the event of a crash.

WARNING: Keep antenna and power cables at least 4 in (10 cm) from any electronic modules and airbags.

Note: We test and certify your vehicle to meet electromagnetic compatibility legislation. It is your responsibility to make sure that any equipment an authorized dealer installs on your vehicle complies with applicable local legislation and other requirements. Installation of some aftermarket electronic devices could degrade the performance of vehicle functions, which use radio frequency signals such as broadcast radio receiver, tire pressure monitoring system, push button start, **Bluetooth**® connectivity or satellite navigation.


Note: Any radio frequency transmitter equipment in your vehicle, such as, cellular telephones and amateur radio transmitters, must keep to the parameters in the following illustrations and table. We do not provide any other special provisions or conditions for installations or use.

Car




Appendices

Van



Truck



Appendices

Frequency Band MHz	Maximum Output Power Watt (Peak RMS)	Antenna Positions
1-30	50	1
50-54	50	2,3
68-88	50	2,3
142-176	50	2,3
380-512	50	2,3
806-870	10	2, 3

1	Adaptive Cruise Control Automatic
ı	Cancellation213
12V Battery307	Adaptive Cruise Control Indicators218
12V Battery Precautions307	Adaptive Cruise Control
Battery Management System	Limitations211
Limitations308	Adaptive Cruise Control
Changing the 12V Battery308	Precautions210
How Does the Battery Management	Adaptive Cruise Control –
System Work308	Troubleshooting223
Recycling and Disposing of the 12V	Adaptive Cruise Control – Information
	Messages223
Battery	Adjusting the Exterior Mirrors107
Resetting the Battery Sensor309	
What Is the Battery Management	Adjusting the Headlamps310
System307	Adjusting the Instrument Panel Lighting
12V Battery – Troubleshooting309	Brightness101
12V Battery – Information Messages310	Adjusting the Map425
12V Battery – Warning Lamps309	Changing the Format of the Map425
\cap	Zooming the Map In and Out425
9	Adjusting the Seatbelts During
	Pregnancy55
911 Assist69	Adjusting the Sound Settings389
٨	Adjusting the Speed Limit
A	Tolerance230
, , , , , , , , , , , , , , , , , , ,	Adjusting the Steering Wheel89
A/C	Adjusting the Volume388
See: Climate Control - Vehicles With: Dual	Aid Mode234
Automatic Temperature Control	How Does Aid Mode Work234
(DATC)119	What Is Aid Mode234
See: Climate Control - Vehicles With:	Airbag Precautions63
Electronic Automatic Temperature Control	Airbags60
(EATC)124	Front Passenger Sensing System64
About This Publication17	Air Conditioning
ABS	See: Climate Control - Vehicles With: Dual
See: Brakes181	Automatic Temperature Control
	(DATC)119
Accessing Apps421	See: Climate Control - Vehicles With:
Accessing Navigation425	
Accessing the Passive Key Backup	Electronic Automatic Temperature Control
Position158	(EATC)124
Accessing the Trip Computer116	Air Conditioning System Capacity and
Accessories430	Specification - 2.3L EcoBoost™376
Adaptive Cruise Control210	Air Conditioning System Capacity and
Adaptive Cruise Control –	Specification - 5.0L377
Troubleshooting223	Alert and Aid Mode234
Lane Centering218	How Does Alert and Aid Mode Work234
Predictive Speed Assist221	What Is Alert and Aid Mode234
Predictive Speed Assist –	Alert Mode233
Troubleshooting223	How Does Alert Mode Work234
_	What Is Alert Mode233

Alexa Built-In413	Applying the Electric Parking Brake -	
Alexa Built-In Requirements413	Manual Transmission, Vehicles	
Alexa Built-In Settings413	Without: EcoBoost™ Performance	
Ambient Lighting101	Package/GT Performance	
Switching Ambient Lighting On and	Package	185
Off101	App Precautions	
Anti-Lock Braking System181	App Requirements	
Anti-Lock Braking System Indicators181	Apps	
Anti-Lock Braking System	Audio System	
Limitations181	Audio System – Troubleshooting	
Anti-Theft Alarm System85	Digital Radio	
Arming the Anti-Theft Alarm System86	FM Radio	
Disarming the Anti-Theft Alarm	Satellite Radio	392
System86	Audio System Precautions	.388
How Does the Anti-Theft Alarm System	Audio System - Troubleshooting	.394
Work85	Audio System – Information	
What Are the Inclination Sensors86	Messages	394
What Are the Interior Sensors85	Auto-Dimming Exterior Mirror	
What Is the Anti-Theft Alarm System85	What Is the Auto-Dimming Exterior	
What Is the Perimeter Alarm85	Mirror	107
Anti-Theft Alarm System Settings86	Auto-Dimming Interior Mirror	106
Setting the Alarm Security Level86	Auto-Dimming Interior Mirror	
Switching Ask on Exit On and Off86	Limitations	106
What are the Alarm Security Levels86	What Is the Auto-Dimming Interior	
What Is Ask on Exit86	Mirror	
Appendices524	Auto Hold	
Applying the Electric Parking Brake -	Auto Hold Indicators	
Automatic Transmission, Vehicles	Autolamps	
With: EcoBoost™ Performance	Autolamp Settings	
Package/GT Performance	What Are Autolamps	
Package186	Autolock	
Applying the Electric Parking Brake -	Autolock Requirements	
Automatic Transmission, Vehicles	What Is Autolock	79
Without: EcoBoost™ Performance	Automatically Releasing the Electric	
Package/GT Performance	Parking Brake	188
Package186	Automatic Crash Shutoff	282
Applying the Electric Parking Brake in an	Automatic Crash Shutoff	
Emergency - Vehicles With:	Precautions	282
EcoBoost™ Performance Package/GT	Re-Enabling Your Vehicle	
Performance Package187	What Is Automatic Crash Shutoff	
Applying the Electric Parking Brake in an	Automatic Emergency Braking	
Emergency - Vehicles Without:	Switching Automatic Emergency Brakin,	
EcoBoost™ Performance Package/GT	On and Off	254
Performance Package187	What Is Automatic Emergency	
Applying the Electric Parking Brake -	Braking	253
Manual Transmission, Vehicles With:	Automatic Engine Stop	158
EcoBoost™ Performance Package/GT	How Does Automatic Engine Stop	
Performance Package185	Work	158

Overriding Automatic Engine Stop158	Park (P)	175
Switching Automatic Engine Stop On and	Reverse (R)	
Off158	Automatic Transmission	
What Is Automatic Engine Stop158	Precautions	175
Automatic High Beam Control98	Auto Mode	
Automatic High Beam Control	Auto Mode Indicators	121
Indicators100	Switching Auto Mode On and Off	121
Automatic High Beam Control	Switching Dual Mode On and Off	122
Limitations99	Auto-Start-Stop	
Automatic High Beam Control	Auto-Start-Stop – Troubleshooting	163
Precautions99	Auto-Start-Stop Indicators	163
Automatic High Beam Control	Auto-Start-Stop Precautions -	
Requirements99	Automatic Transmission	161
How Does Automatic High Beam Control	Auto-Start-Stop Precautions - Manu	Jal
Work98	Transmission	
Overriding Automatic High Beam	Auto-Start-Stop –	
Control100	Troubleshooting	163
Switching Automatic High Beam Control	Auto-Start-Stop – Frequently Asked	
On and Off100	Questions	165
Automatic High Beam Control –	Auto-Start-Stop – Information	
Troubleshooting100	Messages	163
Automatic High Beam Control –	Autounlock	79
Information Messages100	Autounlock Requirements	79
Automatic Locking Mode54	Switching Autounlock On and Off	79
Disengaging Automatic Locking Mode54	What Is Autounlock	79
Engaging Automatic Locking Mode54	Autowipers	91
What Is Automatic Locking Mode54	Adjusting the Sensitivity of the Rain	
When to Use Automatic Locking	Sensor	92
Mode54	Autowipers Settings	91
Automatic Transmission Audible	What Are Autowipers	91
Warnings177	Auxiliary Gauges	408
Automatic Transmission175		
Automatic Transmission Positions175	В	
Brake Shift Interlock178		
Manually Shifting Gears177	Blind Spot Assist	
Automatic Transmission Fluid Capacity	Blind Spot Assist Indicators	
and Specification379	Blind Spot Assist Limitations	
Automatic Transmission Position	How Does Blind Spot Assist Work	
Indicators - Vehicles With: Paddle	What Is Blind Spot Assist	
Shifters177	Blind Spot Information System	239
Automatic Transmission Position	Blind Spot Information System –	
Indicators - Vehicles Without: Paddle	Troubleshooting	241
Shifters176	Blind Spot Information System	
Automatic Transmission Positions175	Indicators	240
Drive (D)	Blind Spot Information System	
Low (L)176	Limitations	239
Manual (M)176	Blind Spot Information System	
Neutral (N)175	Precautions	239

Blind Spot Information System	Catalytic Converter –	
Requirements239	Troubleshooting	172
Blind Spot Information System –	Catalytic Converter – Warning	
Troubleshooting241	Lamps	172
Blind Spot Information System –	Center Console	
Information Messages241	Locking the Center Console	
Bluetooth®420	Opening the Center Console	
Body Control Module Fuse Box292	Center Display Limitations	
Accessing the Body Control Module Fuse	Center Display Overview	
Box292	Center Display Precautions	
Identifying the Fuses in the Body Control	Center Display Settings	
Module Fuse Box292	Changing a Flat Tire	
Locating the Body Control Module Fuse	Changing a Road Wheel	
Box292	Changing the Fuel Filter	305
Body Styling Kit Precautions324	Changing the Language	
Body Styling Kit Freedotions324	Changing the Measurement Unit	
Bonnet Lock	Changing the Remote Control	11
See: Opening and Closing the Hood296	Battery	72
Booster Seats48	Changing the Set Speed Limit	
Brake Fluid Specification182		
	Changing the Temperature Unit	
Brake Over Accelerator181	Changing the Vehicle Wi. Fi Hetenet	113
Brake Precautions181	Changing the Vehicle Wi-Fi Hotspot	206
8rakes	Name or Password	
Anti-Lock Braking System181	Charging a Device	
Brakes - Troubleshooting183	Charging a Wireless Device	
Brake Shift Interlock178	Checking the Brake Fluid Level	
Brake Shift Interlock Precautions	Checking the Clutch Fluid Level	
Using Brake Shift Interlock	Checking the Manual Transmission Flu	
What Is Brake Shift Interlock178	Level	1/3
Brakes – Troubleshooting183	Checking the Seatbelts	
Brakes – Frequently Asked	Checking the Tire Pressures	
Questions	Checking the Wiper Blades	
Brakes – Information Messages183	Children and Airbags	
Brakes – Warning Lamps183	Child Restraint Anchor Points	
Breaking-In275	Locating the Child Restraint Lower Anch	
$lue{}$	Points	
	Locating the Child Restraint Top Tether	
	Anchor Points	42
Calculating Payload264	What Are the Child Restraint Anchor	
Calculating the Load Limit264	Points	
Canceling the Set Speed209	Child Restraints	
Canceling the Set Speed Limit230	Child Restraint Position Information	
Capacities and Specifications363	Child Restraints Recommendation	
Catalytic Converter172	Child Safety	
Catalytic Converter –	Child Restraint Anchor Points	
Troubleshooting172	Child Restraints	
Catalytic Converter Precautions172	Installing Child Restraints	
	Child Safety Precautions	40

Cleaning Products318	Connected Vehicle —	
Cleaning the Exterior319	Troubleshooting	.384
Cleaning Camera Lenses and	Connected Vehicle – Frequently Asked	
Sensors320	Questions	384
Cleaning Chrome, Aluminium or Stainless	Connecting a Bluetooth® Device	.420
Steel319	Connecting the Vehicle to a Mobile	
Cleaning Headlamps and Rear	Network	.383
Lamps319	Connecting FordPass to the Modem	383
Cleaning Stripes or Graphics320	Enabling and Disabling the Modem	383
Cleaning the Convertible Top320	What Is the Modem	383
Cleaning the Exterior Precautions319	Connecting the Vehicle to a Wi-Fi	
Cleaning the Underbody320	Network	.383
Cleaning Wheels319	Connecting Your Phone	415
Cleaning Windows and Wiper Blades319	Contacting Us	15
Cleaning the Interior320	Convertible Top	273
Cleaning Carpets and Floor Mats322	Coolant	.302
Cleaning Displays and Screens321	Adding Coolant	
Cleaning Fabric321	Changing the Coolant	
Cleaning Leather321	Checking the Coolant Level	
Cleaning Plastic321	Coolant – Information Messages	
Cleaning Seatbelts322	Coolant – Warning Lamps	
Cleaning Storage Compartments322	Managing the Coolant Temperature	304
Cleaning the Instrument Panel320	Cooling System Capacity and	
Cleaning Vinyl322	Specification - 2.3L EcoBoost™	372
Climate Control119	Cooling System Capacity and	
Auto Mode121	Specification - 5.0L	
Climate Control Hints122	Crash and Breakdown Information	
Closing the Convertible Top274	Automatic Crash Shutoff	
Closing the Rear Luggage	Fail-Safe Cooling	
Compartment269	Jump Starting the Vehicle	
Closing the Rear Luggage Compartment	Post-Crash Alert System	
from Outside Your Vehicle269	Recovery Towing	
Cluster Theme409	Crash Sensors and Airbag Indicator	
Clutch Fluid Capacity and	Creating a Personal Profile	
Specification174	Creating a Vehicle Wi-Fi Hotspot	.386
Cold Weather Precautions275	Cross Traffic Alert	.24C
Configuring the Trip Computer116	Cross Traffic Alert –	2/0
Connected Navigation425	Troubleshooting	248 - 275
Connected Vehicle383	Cross Traffic Alert Indicators	
Connected Vehicle –	Cross Traffic Alert Dragovitions	
Troubleshooting384	Cross Traffic Alert Precautions	.240
Connecting the Vehicle to a Mobile	Cross Traffic Alert –	240
Network383	Troubleshooting	.248
Connected Vehicle Data24	Cross Traffic Alert – Information	240
Connected Vehicle Limitations383	Messages	245 יחו
Connected Vehicle Requirements383	Cross Traffic Braking	191
	Cross Traffic Braking –	100
	Troubleshooting	192

Cross Traffic Braking Indicators192	Autounlock	79
Cross Traffic Braking Precautions191	Doors and Locks - Troubleshooting	
Cross Traffic Braking –	Mislock	79
Troubleshooting192	Operating the Doors From Inside Your	
Cross Traffic Braking – Frequently Asked	Vehicle	78
Questions193	Operating the Doors From Outside Your	
Cross Traffic Braking – Information	Vehicle	78
Messages192	Doors and Locks –	
Cruise Control208	Troubleshooting	.80
Cruise Control Indicators209	Doors and Locks – Frequently Asked	
Cup Holders151	Questions	81
Cup Holder Precautions151	Doors and Locks – Information	
Custom Drive Mode408	Messages	80
Customer Information443	Doors and Locks - Warning Lamps	80
Radio Frequency Certification	Drive Belt Routing Overview - 2.3L	
Labels	EcoBoost™	306
Customizing the Instrument Cluster	Drive Belt Routing Overview - 5.0L	307
Display114	Drive Mode Control	
D	Drive Modes	227
D	Drive Modes	.227
	Custom	227
Data Privacy22	Drag Strip	227
Department of Transportation Uniform	Normal	227
Tire Quality Grades327	Slippery	.228
Digital Radio390	Sport	.228
Digital Radio Indicators391	Track	.228
Digital Radio Limitations391	Driver Alert	
How Does Digital Radio Work391	Driver Alert – Troubleshooting	261
Switching Digital Radio Reception On and	Driver Alert Indicators	.261
Off391	Driver Alert Limitations	260
What Is Digital Radio390	Driver Alert Precautions	260
Dinghy Tow	Driver Alert – Troubleshooting	.261
See: Recreationally Towing Your	Driver Alert – Information Messages	261
Vehicle286	Driving Economically	
Directing the Flow of Air121	Driving Hints	
Disposing of Airbags68	Driving on Snow and Ice	
Distance Alert253	Driving Through Shallow Water - Base	
Adjusting the Sensitivity of Distance	GT	.276
Alert253	Driving Through Shallow Water - Dark	
What Is Distance Alert253	Horse	.276
Distance Indication252	Drowsiness Monitor	
Distance Indication Indicator253	See: Driver Alert	.260
Switching Distance Indication On and	Г	
Off253		
What Is Distance Indication252		_
Doors and Locks Audible Warnings79	Easy Entry and Exit	84
Doors and Locks78	Electric Parking Brake Audible	
Autolock79	Warning	.188

Electric Parking Brake185	Resetting the Intelligent Oil Life	
Electric Parking Brake –	Monitor	300
Troubleshooting188	Engine Specifications - 2.3L	
Electric Parking Brake –	EcoBoost™	363
Troubleshooting188	Engine Specifications - 5.0L	364
Electric Parking Brake – Information	Environment	
Messages189	Evasive Steering Assist	
Electric Parking Brake – Warning	Evasive Steering Assist Limitations	
Lamps188	Switching Evasive Steering Assist On	
Electric Power Steering200	Off	
Electric Power Steering Precautions200	What Is Evasive Steering Assist	254
How Does Electric Power Steering	Event Data	
Work200	Exhaust Mode	409
Electromagnetic Compatibility524	Exit Warning	242
Emergency Call Limitations70	Exit Warning - Troubleshooting	244
Emergency Call Requirements69	Exit Warning Indicators	243
Emergency Call System Data - Vehicles	Exit Warning Limitations	242
With: Emergency Assistance25	Exit Warning Precautions	242
Emergency Towing286	Exit Warning - Troubleshooting	244
Emission Law521	Exit Warning - Information	
Enabling Apps on an Android	Messages	244
Device421	Export Unique Options	522
Enabling Apps on an iOS Device421	Extending the Remote Start	
Enabling or Disabling Personal	Duration	
Profiles423	Exterior Bulbs	
Enabling Remote Start117	Exterior Bulb Specification Chart	
End User License Agreement496	Exterior Lamps	
Engine Air Filter300	Exterior Lamp Indicators	
_ Changing the Engine Air Filter300	Exterior Lamps On Audible Warning	
Engine Block Heater155	Switching the Daytime Running Lamp	
Engine Block Heater Precautions155	and Off	9
How Does the Engine Block Heater	Switching Welcome Lighting On and	
Work156	Off	
Using the Engine Block Heater156	Using the Turn Signal Lamps	
Engine Coolant Temperature	Exterior Lighting Control	95
Gauge109	Exterior Lighting	95
Engine Oil Capacity and Specification -	Autolamps	
2.3L EcoBoost™369	Automatic High Beam Control	98
Engine Oil Capacity and Specification -	Automatic High Beam Control –	100
5.0L370	Troubleshooting	
Engine Oil	Exterior Lamps	
Adding Engine Oil299	Headlamps	95
Checking the Engine Oil Level299	Headlamps – Troubleshooting	
Engine Oil Capacity and	Exterior Mirrors	
Specification	Auto-Dimming Exterior Mirror	107
Engine Oil Dipstick Overview299		
Intelligent Oil Life Monitor300		

F	Front Seats	
	Heated Seats	
Fail-Safe Cooling283	Manual Seats	
Driving When Fail-Safe Mode Is	Power Seats	
Activated284	Ventilated Seats	135
Fail-Safe Cooling Indicators285	Fuel and Refueling	166
How Does Fail-Safe Cooling Work284	Fuel and Refueling –	
What Is Fail-Safe Cooling283	Troubleshooting	170
Fastening and Unfastening the	Fuel Quality	
Seatbelts52	Refueling	
Favorite399	Running Out of Fuel	
Federal Highway Administration	Fuel and Refueling Precautions	
Regulation495	Fuel and Refueling –	
Flat Tire	Troubleshooting	170
	Fuel and Refueling – Information	170
See: Changing a Flat Tire357	Messages	171
Flat Tow		
See: Recreationally Towing Your	Fuel and Refueling – Warning Lamps	
Vehicle	Fuel Gauge	
Floor Mats277	Fuel Gauge Limitations	
FM Radio390	Locating the Fuel Filler Door	
FM Radio Limitations390	What Is Distance to Empty	
Selecting an FM Radio Station390	What Is the Fuel Gauge	
Folding the Exterior Mirrors107	What Is the Low Fuel Reminder	
Ford Assistant411	Fuel Quality	
Ford Assistant – Frequently Asked	Selecting the Correct Fuel	166
Questions411	Fuel Tank Capacity - 2.3L	
Ford Assistant Settings411	EcoBoost™	
Using Ford Assistant411	Fuel Tank Capacity - 5.0L	375
Ford Protect431	Fuel Tank Capacity	170
Four Wheels Down Tow	Fuse Precautions	287
See: Recreationally Towing Your	Fuses	287
Vehicle286	Body Control Module Fuse Box	292
Front Exterior - Base, Convertible30	Fuses – Troubleshooting	295
Front Exterior - Base, Coupe31	High Current Fuse Box	294
Front Exterior - Dark Horse32	Under Hood Fuse Box	287
Front Exterior - GT, Convertible33	Fuses - Troubleshooting	295
Front Exterior - GT, Coupe34	Fuses – Frequently Asked Questions	
Front Passenger Sensing System64		
Front Passenger Sensing System	G	
Indicators67	•	
Front Passenger Sensing System	Garage Door Opener Additional	
Precautions66	Assistance	145
	Garage Door Opener	
How Does the Front Passenger Sensing	Garage Door Opener Introduction	
System Work64		
What Is the Front Passenger Sensing	Garage Door Opener Precautions an	
System64	Frequencies	
Front Seat Precautions129	General Maintenance Information	453

Glasses Holder1	52	Horn	.90
Locating the Glasses Holder		How Does 911 Assist Work	
Global Opening1		How Does Adaptive Cruise Control Wit	h
Switching Global Opening On and		Stop and Go Work - Automatic	
Off1	05	Transmission	210
Using Global Opening1		How Does Adaptive Cruise Control Wor	
What Is Global Opening1		- Manual Transmission	
Glossary of Tire Terminology3		How Does Auto Hold Work	
Glove Compartment		How Does Blind Spot Information	
Opening the Glove Compartment		System Work	239
		How Does Cross Traffic Alert	
H		Work2	46
1 1		How Does Cross Traffic Braking	
Headlamp Adjusting		Work	191
See: Adjusting the Headlamps	R10	How Does Drive Mode Control	.,,,,
Headlamps		Work2	226
Headlamp Indicators		How Does Driver Alert Work2	
Switching Headlamp Exit Delay On and		How Does Easy Entry and Exit	-00
Off		Work	84
Using the High Beam Headlamps		How Does Exit Warning Work	
Headlamps – Troubleshooting		How Does Hill Start Assist Work	
Headlamps – Frequently Asked		How Does Pre-Collision Assist	
Questions		Work2	249
Heated Seats1		How Does Speed Sign Recognition	- 1 /
Heated Seat Precautions		Work	257
Switching the Heated Seats On and		How Does Stability Control Work	
Off		How Does the Intelligent Speed Limite	
Heating	133		:1 229
See: Climate Control - Vehicles With: Dual		How Does the Lane Keeping System	
Automatic Temperature Control		Work	フマフ
(DATC)	110	How Does the Memory Function	ے کے
See: Climate Control - Vehicles With:	115	Work	140
Electronic Automatic Temperature Cont	rol	How Does the Personal Safety System	
(EATC)		Work	59
High Current Fuse Box2		How Does the Rear Occupant Alert	
Accessing the High Current Fuse Box2	94 04	System Work	128
Identifying the Fuses in the High Current		How Does the Safety Canopy™ Work -	
Fuse Box2		Coupe	
Locating the High Current Fuse Box2		How Does Traction Control Work	107
Hill Start Assist1		How Does Traction Control Work	
Hill Start Assist — Troubleshooting		How Do Fersonal Frontes Work How Do the Front Airbags Work	
Hill Start Assist Precautions1		How Do the Knee Airbags Work	
Hill Start Assist – Troubleshooting1		How Do the Knee Airbags Work How Do the Side Airbags Work	
Hill Start Assist – Information	シケ	I IOW DO THE SIDE AIIDAKS WOIK	.00
	0/	1	
Messages	94 00	I	
Home Screen31 Hood Lock	フフ	Icon Glossary	
	06	Icon Glossary	10
See: Opening and Closing the Hood2	90	See: Symbols Glossary	19

Icons	What Is the Interior Lamp Function	101
See: Symbols Glossary19	Interior Lighting	101
Identifying Fuse Types295	Ambient Lighting	101
Identifying the Climate Control	Interior Lamp Function	101
Unit119	Interior Lighting – Troubleshooting	102
Inflating the Tires339	Interior Lighting - Troubleshooting	102
Information On Demand Screen399	Interior Lighting – Frequently Asked	
Information on the Tire Sidewall328	Questions	102
Inspecting the Tire for Damage341	Interior Mirror	
Inspecting the Tire for Wear340	Auto-Dimming Interior Mirror	106
Inspecting the Wheel Valve	Interior Mirror Precautions	
Stems345	Introduction	17
Installing Child Restraints43		
Combining the Seatbelt and Lower Anchors	J	
for Attaching Child Restraints46		
Using Lower Anchors and Tethers for	Jump Starting the Vehicle	.279
Children45	Jump Starting Precautions	
Using Seatbelts43	Jump Starting the Vehicle	
Using Tether Straps46	Preparing the Vehicle	
Instrument Cluster Display114		
Instrument Cluster Indicators111	K	
Instrument Cluster108	• •	
Fuel Gauge109	Keyless Entry	82
Instrument Cluster Overview108	Keyless Entry Limitations	82
Instrument Cluster Warning	Keys and Remote Controls Audible	
Lamps109	Warnings	75
Instrument Panel28	Keys and Remote Controls	
Intelligent Speed Limiter Audible	Keys and Remote Controls –	
Warnings230	Troubleshooting	77
Intelligent Speed Limiter	Remote Rev	
Indicators230	Keys and Remote Controls –	
Intelligent Speed Limiter229	Troubleshooting	77
Intelligent Speed Limiter –	Keys and Remote Controls – Information	
Troubleshooting231	Messages	77
Intelligent Speed Limiter	•	
Precautions229		
Intelligent Speed Limiter –	_	
Troubleshooting231	Lane Centering	218
Intelligent Speed Limiter – Frequently	How Does Lane Centering Work	218
Asked Questions231	Lane Centering Alerts	
Intentionally Exceeding the Set Speed	Lane Centering Automatic	
Limit230	Cancellation	220
Interior Air Quality128	Lane Centering Indicators	
Interior Bulbs312	Lane Centering Limitations	
Interior Bulb Specification Chart312	Lane Centering Manual Cancellation	
Interior Lamp Function101	Lane Centering Precautions	
Switching the Interior Lamp Function On	Lane Centering Requirements	218
and Off101	Switching Lane Centering On and Off	

Lane Keeping System Indicators235	Locating the Wireless Accessory	
Lane Keeping System232	Charger	149
Aid Mode234	Locating Your Vehicle	72
Alert and Aid Mode234	Luggage Compartment	267
Alert Mode233	Closing the Rear Luggage	
Blind Spot Assist235	Compartment	269
Lane Keeping System –	Luggage Compartment –	
Troubleshooting237	Troubleshooting	269
Lane Keeping System Limitations232	Opening the Rear Luggage	
Lane Keeping System Precautions232	Compartment	267
Lane Keeping System Settings233	Luggage Compartment	
Lane Keeping System –	Precautions	267
Troubleshooting237	Luggage Compartment –	
Lane Keeping System – Frequently Asked	Troubleshooting	269
Questions238	Luggage Compartment – Informatior	
Lane Keeping System – Information	Messages	27C
Messages237	Luggage Compartment – Warning	
Limited Slip Differential180	Lamps	269
Linking or Unlinking a Personal Profile to	N 4	
a Device424	M	
Linking or Unlinking a Personal Profile to		
a Remote Control424	Maintenance	
Live Traffic425	12V Battery	
Switching Live Traffic On and Off425	12V Battery – Troubleshooting	
What Is Live Traffic425	Coolant	
Load Carrying262	Engine Air Filter	
Load Carrying Precautions262	Engine Oil	
Loading Your Trailer271	Exterior Bulbs	
Locating the Blind Spot Information	Interior Bulbs	
System Sensors240	Maintenance Precautions	
Locating the Brake Fluid Reservoir182	Making and Receiving a Phone Call	
Locating the Cabin Air Filter128	Manually Releasing the Electric Par	
Locating the Cross Traffic Alert	Brake - Vehicles With: EcoBoost™	VI
Sensors247	Performance Package/GT	100
Locating the Exit Warning Sensors244	Performance Package	188
Locating the Fuel Filler Funnel167	Manually Releasing the Electric Par	King
Locating the Memory Function	Brake - Vehicles Without: EcoBoo	ST™
Buttons140	Performance Package/GT	10-
Locating the Power Outlets148	Performance Package	I8/
Locating the Pre-Collision Assist	Manually Shifting Gears	
Sensors251	Shifting Using the Paddle Shifters	
Locating the Rear View Camera205	Manual Seats	
Locating the Safety Compliance	Accessing the Rear Seats	
Certification Labels263	Adjusting the Head Restraint	
Locating the Tire label327	Adjusting the Seat Backrest	
Locating the Tire Sealant and Inflator	Adjusting the Seat Height	
Kit347	Folding the Seat Backrest	
Locating the USB Ports146	Head Restraint Components	I3C

Installing the Head Restraint131	Opening and Closing the Windows -
Moving the Seat Backward and	Convertible103
Forward131	Opening and Closing the Windows -
Removing the Head Restraint131	Coupe104
Unfolding the Seat Backrest137	Opening the Convertible Top273
Manual Transmission Fluid Capacity and	Opening the Rear Luggage
Specification174	Compartment267
Manual Transmission173	Opening the Rear Luggage Compartment
Manual Transmission Precautions173	from Inside Your Vehicle267
Memory Function140	Opening the Rear Luggage Compartment
Memory Function Precautions140	from Outside Your Vehicle268
Mislock79	Opening the Rear Luggage Compartment
Mislock Limitations79	Using the Remote Control268
Switching Mislock On and Off79	Operating the Doors From Inside Your
What Is Mislock79	Vehicle78
Mobile Communications	Opening the Doors From Inside Your
Equipment495	Vehicle79
Mobile Device Data25	Unlocking and Locking the Doors Using the
Motorcraft Parts - 2.3L	Central Locking78
EcoBoost™367	Operating the Doors From Outside Your
Motorcraft Parts - 5.0L368	Vehicle78
Muting the Audio389	Unlocking and Locking the Doors Using the
My Color409	Key Blade78
My Mustang401	Unlocking and Locking the Doors Using the
Track Apps402	Remote Control78
My Mustang Overview401	Ordering a Canadian French Owner's
	Manual444
N	OTA
•	See: Software Update Settings427
Navigation Map Updates425	See: Vehicle Software Updates427
Navigation425	Overriding Cross Traffic Braking192
Adjusting the Map425	Overriding the Set Speed217
Live Traffic425	Over the air
Route Guidance426	See: Software Update Settings427
Setting a Destination425	Over-the-air
Waypoints426	See: Software Update Settings427
Neutral Towing	See: Vehicle Software Updates427
See: Recreationally Towing Your	See: Vehicle Software Updates427
Vehicle286	_
Neutral Tow	Р
See: Recreationally Towing Your	•
Vehicle286	Parking Aid Indicators204
Normal Scheduled Maintenance436	Parking Aid Precautions202
	Parking Aids202
	Parking Aids – Troubleshooting204
	Rear Parking Aid203
Opening and Closing the Hood 296	<u>-</u>

Parking Aids – Troubleshooting204	Pre-Collision Assist	249
Parking Aids – Information	Automatic Emergency Braking	
Messages204	Distance Alert	
Passive Anti-Theft System85	Distance Indication	
How Does the Passive Anti-Theft System	Evasive Steering Assist	254
Work85	Pre-Collision Assist –	
What Is the Passive Anti-Theft	Troubleshooting	.255
System85	Pre-Collision Assist —	
Perchlorate494	Troubleshooting	.255
Performing a System Reset429	Pre-Collision Assist – Frequently Asked	
Personalized Settings115	Questions	.256
Personal Profiles423	Pre-Collision Assist – Information	
Personal Safety System	Messages	.255
Components59	Pre-Collision Assist – Warning	
Personal Safety System™59	Lamps	.255
Phone Menu415	Predictive Speed Assist	
Phone415	Adjusting the Set Speed Tolerance	222
Phone Precautions415	How Does Predictive Speed Assist	
Playing Media Using Bluetooth®420	Work	22
Playing Media Using the USB Port146	Predictive Speed Assist Alerts	222
Playing or Pausing the Audio	Predictive Speed Assist Indicators	222
Source388	Predictive Speed Assist Limitations	222
Post-Collision Braking281	Predictive Speed Assist Precautions	22
Post-Crash Alert System281	Switching Predictive Speed Assist Mode	
How Does the Post-Crash Alert System	On and Off	222
Work281	Predictive Speed Assist –	
Post-Crash Alert System Limitations281	Troubleshooting	.223
Switching the Post-Crash Alert System	Predictive Speed Assist – Information	
Off281	Messages	223
What Is the Post-Crash Alert System281	Preparing Your Vehicle for	
Power Outlet148	Storage	.325
Power Outlet Precautions148	Programming the Garage Door	
Power Seats132	Opener	
Adjusting the Head Restraint133	Programming the Remote Control	
Adjusting the Lumbar Support134	Properly Adjusting the Driver and Fron	
Adjusting the Seat Backrest134	Passenger Seats	63
Adjusting the Seat Height134	Protecting the Environment	26
Head Restraint Components132	Puncture	
Installing the Head Restraint134	See: Changing a Flat Tire	
Moving the Seat Backward and	Push Button Ignition Switch	153
Forward134		
Removing the Head Restraint134	R	
Power-Up		
See: Software Update Settings427	Radio Frequency Certification	
See: Vehicle Software Updates427	Labels	
Pre-Collision Assist Limitations250	Antennas	.446
Pre-Collision Assist Precautions249	Blind Spot Information System	
	Sensors	.446

Body Control Module4	52	Zooming the Rear View Camera In and	
Cruise Control Module45	54	Out	206
Garage Door Opener45	59 F	Rebooting the Center Display4	400
Keys and Remote Controls45	59 F	Recalling a Preset Position	140
Radio Transceiver Module46		Recovery Towing	
SYNC46		Accessing the Front Towing Point	
Telematics Control Unit4	75	Installing the Towing Eye	282
Tire Pressure Monitoring System		Locating the Towing Eye	282
Sensors4	.77 F	Recreationally Towing Your	
Wireless Accessory Charging		Vehicle2	286
Module4	87 F	Refueling	169
Rear Axle Fluid Capacity and		Refueling System Overview	.169
Specification38	30	Refueling Your Vehicle	.169
Rear Axle18	30 F	Releasing the Electric Parking Brake if	
Rear Cross Traffic Braking		the Vehicle Battery Has Run Out of	
See: Cross Traffic Braking1	91	Charge	188
Rear Exterior - Base, Convertible	35 F	Remote Control Limitations	71
Rear Exterior - Base, Coupe	36 F	Remotely Starting and Stopping the	
Rear Exterior - Dark Horse	37	Vehicle	117
Rear Exterior - GT, Convertible	38 F	Remote Rev	
Rear Exterior - GT, Coupe	39	Remote Rev Limitations	76
Rear Occupant Alert System Audible		Using Remote Rev	76
Warnings13		What is Remote Rev	
Rear Occupant Alert System		Remote Start Limitations	
Indicators13		Remote Start Precautions	
Rear Occupant Alert System		Remote Start	117
Limitations13		Remote Start Settings	
Rear Occupant Alert System		Removing the Key Blade	72
Precautions13		Removing Your Vehicle From	
Rear Occupant Alert System13		Storage	
Rear Occupant Alert System		Repairing Minor Paint Damage	322
Settings13		Replacement Parts	
Rear Parking Aid20	03	Recommendation	494
Locating the Rear Parking Aid		Replacing a Lost Key or Remote	
Sensors20		Control	
Rear Parking Aid Audible Warnings20	03 F	Replacing the Cabin Air Filter	.128
Rear Parking Aid Limitations20		Replacing the Front Wiper Blades	92
What is the Rear Parking Aid20		Reporting Safety Defects in	
Rear Seats1		Canada	445
Manual Seats1		Reporting Safety Defects in the United	
Rear View Camera Guide Lines20		States2	444
Rear View Camera Precautions20		Resetting the Trip Computer	.116
Rear View Camera20		Restarting the Engine - Automatic	
Rear View Camera Settings20		Transmission	163
Rear View Camera Settings20		Restarting the Engine - Manual	
Switching Rear View Camera Delay On and		Transmission	162
Off20)6 F	Resuming the Set Speed - Automatic	
		Transmission	216

Resuming the Set Speed Limit230	Security – Information Messages	
Resuming the Set Speed - Manual	Selecting a Drive Mode	
Transmission216	Selecting the Audio Source	388
Resuming the Set Speed209	Sending and Receiving a Text	
Roadside Assistance278	Message	. 418
Route Guidance426	Sensitive Locking Mode	53
Adjusting the Guidance Prompt	How Does Sensitive Locking Mode	
Volume426	Work	53
Canceling Route Guidance426	What is Sensitive Locking Mode	53
Running-In	Service Data	23
See: Breaking-In275	Setting a Destination	425
Running Out of Fuel167	Setting a Destination Using a Point of	
Adding Fuel From a Portable Fuel	Interest	.426
Container168	Setting a Destination Using a Predictive	
Filling a Portable Fuel Container167	Destination	.426
	Setting a Destination Using a Recent	
S	Destination	.426
	Setting a Destination Using a Saved	
Satellite Radio392	Destination	.426
Locating the Satellite Radio Identification	Setting a Destination Using the Map	0
Number392	Screen	426
Satellite Radio Limitations392	Setting a Destination Using the Text Entr	
Satellite Radio Settings393	Screen	
Selecting a Channel392	Setting a Memory Preset	
What Is Satellite Radio392	Settings Data	202 24
Saving a Preset Position140	Setting the Adaptive Cruise Control	∠¬
Scheduled Maintenance433	Gap	215
Seatbelt Extensions57	Setting the Adaptive Cruise Control	
Seatbelt Precautions51	Speed - Automatic Transmission	21/
Seatbelt Reminder55	Setting the Adaptive Cruise Control	Z I '1
How Does the Seatbelt Reminder	Speed - Manual Transmission	212
Work55	Setting the Blower Motor Speed	
Seatbelt Reminder Audible Warnings56	Setting the Clock and Date	
Seatbelt Reminder Indicators55		
Switching the Seatbelt Reminder On and	Setting the Cruise Control Speed Setting the Speed Limit	
Off56		
Seatbelts51	Setting the Speed Sign Recognition Speed Tolerance	250
Automatic Locking Mode54	Setting the Speed Sign Recognition	250
Seatbelt Reminder55		250
	Speed Warning	200 120
Sensitive Locking Mode53	Setting the Temperature	
Security85	Shifting Into Reverse	
Anti-Theft Alarm System85	Shifting Your Vehicle Into Gear - Vehicle	
Anti-Theft Alarm System Settings86	With: Paddle Shifters	
Passive Anti-Theft System85	Shifting Your Vehicle Into Gear - Vehicle	
Security – Troubleshooting87	Without: Paddle Shifters	
Security – Troubleshooting87	Signing In to Your Account	
Security – Frequently Asked	Sitting in the Correct Position	
Questions88	Software Update Indicators	428

Software Update Settings427	Starting and Stopping the Engine –
Software Update	Warning Lamps159
See: Software Update Settings427	Starting the Engine154
See: Vehicle Software Updates427	Restarting the Engine After Stopping
Sounding the Panic Alarm72	It155
Special Operating Conditions Scheduled	Starting a Gasoline Engine154
Maintenance439	Status Bar398
Speed Control	Steering200
See: Cruise Control208	Electric Power Steering200
Speedometer108	Steering – Troubleshooting200
Speed Sign Recognition	Steering - Troubleshooting200
Indicators258	Steering – Information Messages201
Speed Sign Recognition	Steering – Warning Indicators200
Limitations257	Steering Wheel27
Speed Sign Recognition	Stopping the Engine - Automatic
Precautions257	Transmission162
Speed Sign Recognition257	Stopping the Engine - Manual
Speed Sign Recognition –	Transmission161
Troubleshooting258	Stopping the Engine156
Speed Sign Recognition –	Stopping the Engine When Your Vehicle is
Troubleshooting258	Moving157
Speed Sign Recognition – Frequently Asked	Stopping the Engine When Your Vehicle is
Questions259	Stationary156
Speed Sign Recognition – Information	Storage151
Messages258	Center Console151
Stability Control Indicator199	Cup Holders151
Stability Control198	Glasses Holder152
Stability Control – Troubleshooting199	Glove Compartment151
Stability Control –	Storing Your Vehicle325
Troubleshooting199	Suspension Specifications365
Stability Control – Information	Switching Adaptive Cruise Control On
Messages199	and Off - Automatic
Starting and Stopping the Engine –	Transmission213
Precautions153	Switching Adaptive Cruise Control On
Starting and Stopping the Engine153	and Off - Manual Transmission212
Automatic Engine Stop158	Switching Air Conditioning On and
Engine Block Heater155	Off119
Starting and Stopping the Engine –	Switching All of the Interior Lamps On
Troubleshooting159	and Off101
Starting the Engine154	Switching Android Auto On and
Stopping the Engine156	Off422
Starting and Stopping the Engine –	Switching Apple CarPlay On and
Troubleshooting159	Off422
Starting and Stopping the Engine –	Switching Auto Hold On and Off195
Frequently Asked Questions160	Switching Auto-Start-Stop On and
Starting and Stopping the Engine –	Off161
Information Messages159	Switching Blind Spot Information
	System On and Off239

Switching Climate Control On and	Switching the Heated Rear Window On	_
Off119 Switching Cross Traffic Alert On and	and Off12 Switching the Heated Steering Wheel	C
Off246	On and Off9	C
Switching Cross Traffic Braking On and	Switching the Intelligent Speed Limiter	
Off192	On and Off22	9
Switching Cruise Control On and	Switching the Lane Keeping System	. –
Off208 Switching Defrost On and Off119	Mode23 Switching the Lane Keeping System On	i Z
Switching Driver Alert On and Off260	and Off23	}=
Switching Easy Entry and Exit On and	Switching Traction Control On and	_
Off84	Off19	
Switching Exit Warning On and Off244	Symbols Glossary	
Ott	Symbols Used on Your Vehicle	ي
Switching From Adaptive Cruise Control to Cruise Control	System Update See: Software Update Settings42	27
Switching From Intelligent Speed Limiter	See: Vehicle Software Updates42	
to Speed Limiter230	_	
Switching Hill Start Assist On and Off -		
Automatic Transmission194	To also associate at 10	_
Switching Hill Start Assist On and Off - Manual Transmission194	Tachometer10 Technical Specifications	C
Switching Maximum Cooling On and	See: Capacities and Specifications36	5=
Off120	The Better Business Bureau Auto Line	<i>,</i> _
Switching Maximum Defrost On and	Program44	Ξ.
Off119	The Mediation and Arbitration	
Switching Parking Aid On and Off202	Program44	Ξ.
Switching Pre-Collision Assist On and Off251	Third Party Software Copyright Acknowledgment44	6
Switching Recirculated Air On and	Tire Care33	C
Off119	Tire Pressure Monitoring System	
Switching Repeat Mode On and	Limitations35	,4
Off389	Tire Pressure Monitoring System	
Switching Shuffle Mode On and	Overview35	こ
Off389 Switching Stability Control On and	Tire Pressure Monitoring System Precautions35	Z
Off199	Tire Pressure Monitoring System35	Ξ
Switching Text Message Notification On	Tire Pressure Monitoring System –	
and Off419	Troubleshooting35	55
Switching the Audio Unit On and	Tire Pressure Monitoring System –	
Off388 Switching the Display On and Off390	Troubleshooting35 Tire Pressure Monitoring System –	1
Switching the Display Off and Off	Information Messages35	١F
and Off101	Tire Pressure Monitoring System – Warning	
Switching the Hazard Flashers On and	Lamps35	55
Off279	Tire Replacement Requirements33	
Switching the Heated Mirrors On and	Tire Rotation34	۔:
Off120		

Tire Sealant and Inflator Kit	Using Alexa Built-In	413
Components348	Using Auto Hold1	95
Tire Sealant and Inflator Kit	Using Keyless Entry	.82
Precautions347	Using Snow Chains3	36
Tire Sealant and Inflator Kit347	Using Summer Tires3	36
Towing a Trailer Precautions - Base/	Using the Controls on the Steering	
GT271	Wheel	89
Towing a Trailer Precautions - Dark	Using the Instrument Cluster Display	
Horse271	Controls	114
Towing a Trailer271	Using the Rear Luggage Compartment	
Towing Weights and Dimensions272	Emergency Release2	69
Towing Weights and Dimensions272	Using the Remote Control	7
Recommended Towing Weights272	Using the Tire Sealant and Inflator	
Towing Your Vehicle Precautions286	Kit3	48
Towing Your Vehicle286	Using This Publication	
Track Apps402		
Acceleration Timer403	V	
Brake Performance403	•	
Drift Brake407	Vehicle Care3	318
Launch Control406	Cleaning the Exterior	319
Line Lock404	Cleaning the Interior3	320
Manual Lap Timer403	Vehicle Identification Number3	82
Performance Shift Indicator404	Locating the Vehicle Identification	
Rev Match406	Number3	382
Track Apps Overview402	Vehicle Identification Number	
Track Apps Precautions402	Overview3	382
Track Use - Dark Horse315	Vehicle Identification3	182
Track Use313	Vehicle Identification Number3	382
Traction Control Indicator197	Vehicle Interior	
Traction Control197	Vehicle Software Updates4	+2
Traction Control – Troubleshooting197	Vehicle System Reset4	-29
Traction Control –	Vehicle Wi-Fi Hotspot –	
Troubleshooting197	Troubleshooting3	18
Traction Control – Warning Lamps197	Vehicle Wi-Fi Hotspot – Frequently Asked	l
Transporting the Vehicle283	Questions3	
Trip Computer116	Vehicle Wi-Fi Hotspot3	86
1.1	Vehicle Wi-Fi Hotspot –	
U	Troubleshooting3	38.
	Ventilated Seats1	135
Under Hood Fuse Box287	Switching the Ventilated Seats On and	
Accessing the Under Hood Fuse Box287	Off	
Identifying the Fuses in the Under Hood	Ventilated Seat Precautions	135
Fuse Box288		
Locating the Under Hood Fuse Box287		
Under Hood Overview - 2.3L		
EcoBoost™297		
Under Hood Overview - 5.0L298		
USB Ports146		

Ventilation	What Is Remote Start	117
See: Climate Control - Vehicles With: Dual	What Is Speed Sign Recognition	.257
Automatic Temperature Control	What Is the Cabin Air Filter	128
(DATC)119	What Is the Catalytic Converter	172
See: Climate Control - Vehicles With:	What Is the Electric Parking Brake	185
Electronic Automatic Temperature Control	What Is the Gross Axle Weight	
(EATC)124	Rating	.263
Viewing the Tire Pressures355	What Is the Gross Combined Weight	
Visual Search27	Rating	.263
Voice Interaction411	What Is the Gross Vehicle Weight	
Ford Assistant411	Rating	.263
VA /	What Is the Intelligent Speed	
W	Limiter	.229
	What Is the Lane Keeping System	.232
Warranty Information522	What Is the Personal Safety	
Washer Fluid Specification377	System	59
Washers93	What Is the Power Outlet	148
Adding Washer Fluid94	What is the Rear Occupant Alert	
Switching the Courtesy Wipe On and	System	
Off93	What Is the Rear View Camera	.205
Using the Windshield Washer93	What Is the Tire Pressure Monitoring	
Washer Fluid Specification94	System	.353
Washer Precautions93	What Is the Tire Sealant and Inflator	
Washers	Kit	.347
See: Wipers and Washers91	What Is the Wireless Accessory	
Waxing Your Vehicle323	Charger	149
Waypoints426	What Is Traction Control	197
Adding a Waypoint426	Wheel and Tire Information	
Editing Waypoints426	Wheel Nuts	361
What Are the Instrument Cluster	Wi Fi	
Indicators111	See: Changing the Vehicle Wi-Fi Hotspo	
What Are the Instrument Cluster	Name or Password	.386
Warning Lamps109	See: Connecting the Vehicle to a Wi-Fi	
What Is 911 Assist69	Network	
What Is a Connected Vehicle383	See: Creating a Vehicle Wi-Fi Hotspot	
What is Alexa Built-In413	See: Vehicle Wi-Fi Hotspot	.386
What Is Auto-Start-Stop161	Window Bounce-Back	
What Is Blind Spot Information	Overriding Window Bounce-Back	
System239 What Is Cross Traffic Alert246	What Is Window Bounce-Back	
What Is Cross Traffic Alert246	Windows	
What Is Cross Traffic Braking191	Global Opening	
What Is Cruise Control208	Window Bounce-Back	105
What Is Drive Mode Control226	Wipers and Washers –	
What Is Driver Alert260	Troubleshooting	
What is Exit Warning242	Wipers and Washers – Frequently Asked	
What Is Ford Protect431	Questions	94
What Is Hill Start Assist194	Wipers and Washers – Warning	. .
What Is Pre-Collision Assist249	Lamps	94

Wipers and Washers	9
Autowipers	
Washers	
Wipers	
wipers and Washers –	
Troubleshooting	94
Wipers	
Switching Windshield Wipers On and	
Off	9 ⁻
Wiper Precautions	9 [.]
Wireless Accessory Charger	
Precautions	149
Wireless Accessory Charger	

_				
				1