

MUSTANG SEAT TRACK HEIGHT ADJUSTER SERVICE KIT INSTRUCTIONS

KIT - ER3Z-78617D66-A		
Part Number	Description	Quantity
ER33-617A00-AA	Height Adjuster	2
W790283-S900	7.9 x 21.5 Pin	2
W790282-S900	4.2 x 16 HC Screw	8
ER33-618K82-A	Thrust Disc	2
AU7J-19A506-DA	Syn-Tech Grease 12 Gram Tube	2
SKER3Z-78617D66-AD	Instruction Sheet	1

ISSUE:

Some 2005-2013 Mustang vehicles may exhibit a power seat binding during seat control tilt and/or lift adjustment operation. There may also be clicking or grinding noise heard from the seat track area, specifically coming from either the front tilt or rear vertical lift gearboxes.

SERVICE PROCEDURE:

- Operate the front driver and/or passenger seat by tilting the front of the seat or lifting the rear.
 - If clicking or binding is present, proceed to Step 2.
 - If no clicking or binding is present, discontinue with this article. Refer to the Workshop Manual (WSM), Section 501-10.
- Remove front driver or passenger seat. Refer to WSM, Section 501-10. Remove the four (4) seat module mounting plate screws and position aside.
- Remove and discard the clevis pin. (Refer to Figure 1 and View A).




FIGURE 1

SKER3Z-78617D66-AD SHEET 1 OF 4



CPR © 2014 FORD MOTOR COMPANY
DEARBORN, MICHIGAN 48121
2-14

MUSTANG SEAT TRACK HEIGHT ADJUSTER SERVICE KIT INSTRUCTIONS

- Remove the rear motor plastic spacer. (Refer to Figure 2).




FIGURE 2

- Disengage the motor driveshaft. (Refer to Figure 3).




FIGURE 3

- Remove the four (4) gearbox screws and separate the case gearbox housing halves. (Refer to Figure 6).




FIGURE 4

- Remove the thrust disc, drive gear and worm gear from the gearbox housing.
- Clean the gearbox housing halves of grease and/or broken plastic white gear pieces, using small brush. (Refer to Figure 5).

SKER3Z-78617D66-AD SHEET 2 OF 4



CPR © 2014 FORD MOTOR COMPANY
DEARBORN, MICHIGAN 48121
2-14

MUSTANG SEAT TRACK HEIGHT ADJUSTER SERVICE KIT INSTRUCTIONS




FIGURE 5

NOTE: DO not use any chemical spray or solvent to clean the parts. This could cause the plastic to deteriorate in the gears or gearbox housing halves.

- Apply a small amount of grease (supplied with the service kit) to the thrust disc and worm gear.
- Install the thrust disc and worm gear into the gearbox housing. (Refer to Figure 5).
- Apply grease (supplied with the service kit) to the drive gear. (Refer to Figure 6).




FIGURE 6

- Install drive gear assembly into the case gearbox housing. (Refer Figure 7).
 - If components are correctly installed, the gearbox housing halves will fit together with very little effort.




FIGURE 7

SKER3Z-78617D66-AD SHEET 3 OF 4



CPR © 2014 FORD MOTOR COMPANY
DEARBORN, MICHIGAN 48121
2-14

MUSTANG SEAT TRACK HEIGHT ADJUSTER SERVICE KIT INSTRUCTIONS

- Check for excessive gearbox free play, push/pull on metal drive nut. No perceived looseness should be noticed.

- Install gearbox housing screws and hand tighten. (Refer to Figure 8).




FIGURE 8

- Position rear gear assembly aside in order to gain access to the front gear assembly. (Refer to Figure 9).




FIGURE 9

- Repeat Steps 4 - 14 for the front gearbox assembly.
- Install drive cable for the front gearbox assembly.
 - Avoid excessive bending during installation.
- Install rear motor plastic spacer.
- Align drive nut to torsion bar link and install clevis pin. Use vise-grips or equivalent to squeeze the clevis pin in completely against the drive nut.
- Position back the seat module mounting plate and install the four (4) screws. Refer to WSM, Section 501-10.
- Install front driver and/or passenger seat. Refer to WSM, Section 501-10-01.
- While sitting in the seat, operate the front and rear tilt five (5) times.

SKER3Z-78617D66-AD SHEET 4 OF 4



CPR © 2014 FORD MOTOR COMPANY
DEARBORN, MICHIGAN 48121
2-14

MUSTANG SEAT TRACK HEIGHT ADJUSTER SERVICE KIT INSTRUCTIONS