Relay

Relay with Normally
Open Contacts N.O.

86   87

Coil

85   30

WHITE/PINK

GROUND

PIN 7
TRACTION CONTROL SW SIG

TRACTION CONTROL SWITCH

B+
RUN/ACC
START
SYSTEM GROUND
R FRONT SPKR +
R FRONT SPKR -
L FRONT SPKR +
L FRONT SPKR -
R REAR SPKR +
R REAR SPKR -
L REAR SPKR +
L REAR SPKR -

RADIO

RED/BLK

1) INSTALL WIRE CLIP ONTO RADIO WIRE RED/BLK AND WIRE TO (85) TERMINAL ON RELAY.
   OR USE ADD A FUSE TO PASSENGER SIDE FOOT WELL SMART JUNCTION BOX.
2) INSTALL WIRE CLIP ONTO TCS SWITCH WIRE WHT/PNK AND WIRE TO (30) TERMINAL ON RELAY.
3) INSTALL WIRE JUMPER FROM (86) TO (87) ON RELAY AND RUN WIRE TO GROUND.

Smart Junction Box
Passenger Side
Footwell

Fuse
20
10A