

# ILLUSTRATIONS

**1**

**2**

**3**

Clearance Height

**4**

**5**

Clearance Height

**6**

11.5° max.

FLATBED

STACKED 4X4

18"

36"

**7**

**CROSSBEAM/WITHOUT SPACER BLOCKS**

4x4 WOOD BLOCK

**MATERIAL - CROSSBEAMS**  
2 - 4x4x60" LONG 2 - 4x4x48" LONG

**8**

**V STRAP-FORGED CLUSTER HOOKS**

**9** **LOADING**

SHELBY GT500

TOW LINE

11.5° max.

FLATBED

STACKED 4X4

18"

36"

**10**

**CROSSBEAM/SPACER BLOCKS**

**MATERIAL - CROSSBEAMS**  
ONE 4x4x60" LONG - ONE 4x4x48" LONG  
for F-Super Duty

SECTION A

SPACER BLOCKS CAN BE FABRICATED AS SHOWN.

**MATERIAL-SPACER BLOCKS**  
FOUR - 2x4x8" LONG  
TWO - 2x4x3-1/2" LONG  
EIGHT - 1/4x7" CARRIAGE BOLT  
EIGHT - 1/4" NUT  
SIXTEEN - 1/4" WASHER

SECTION A

**Safety Chain Location Codes**

(T) = Tie Down T-Slot (FT) = Flatbed/Rollback T-Slot

(W) = Wrap Chain (FW) = Flatbed/Rollback Winch Location

**11**

FRONT

FW T&FT W FT

FW T&FT W FT

W FT

Use FT tie-downs for flatbed only.

Wrap rear axle for safety chains on wheel lift.