Convertible Top Side Rail

Removal and Installation

- 1. Remove the convertible top headliner. For additional information, refer to Convertible Top Headliner in this section.
- 2. Remove the screws and the side rail(s) from the convertible top frame bows.
- 3. **NOTE:** Manually operate the convertible top frame before installing the headliner, to be sure the frame operates smoothly, without binding.

To install, reverse the removal procedure.

• Make sure the door glass and quarter glass correctly seal against the convertible top side rail. If adjustment is necessary, refer to Section 501-11.

© Copyright 2023, Ford Motor Company.