

Run and Bracket Assembly

Removal

1. Remove door trim panel and watershield. Refer to [Section 01-05](#).
2. Support the glass in the full-up position.
3. Remove the glass-to-bracket attaching rivets. Refer to [Door Glass, Removal](#) as outlined.
4. Remove upper and lower retaining hardware from glass run.
5. Remove the regulator arm slide from the glass bracket C-channel and remove the run and bracket assembly from the door.

Installation

1. Install the glass bracket assembly onto the glass run and position them in the door.
2. Loosely install the upper and lower run retaining hardware.
3. Insert regulator slide into glass bracket C-channel.
4. Remove the glass prop and position the glass bracket to the glass. Install the retaining rivets or bolts. Refer to [Door Glass, Installation](#) as outlined.
5. Adjust glass as outlined.
6. Cycle the glass to check for proper operation.
7. Install the door trim panel and watershield. Refer to [Section 01-05](#).

