


REMOVAL AND INSTALLATION

Bumper — Exploded View, Rear



N0009795

Item	Part Number	Description
1	58403D24	Luggage compartment trim panel pin-type retainers (4 required)
2	63424A82	Luggage compartment trim panel

(Continued)

Item	Part Number	Description
3	S9CS600516	Rear bumper cover-to-bumper cover bracket screws (4 required)
4	13B519	Rear bumper cover pin-type retainers (3 required) (if equipped)

(Continued)

REMOVAL AND INSTALLATION (Continued)

Item	Part Number	Description
5	N621927-S	Rear bumper cover nuts (4 required)
6	17D781-B	Rear bumper cover
7	—	Rear bumper cover electrical connector (part of 14489)
8	011903	Rear bumper isolator pin-type retainers (2 required)
9	17E899-A	Rear bumper isolators
10	W708877-S	Rear bumper bolts (8 required)

(Continued)

Item	Part Number	Description
11	17906	Rear bumper
12	W611103-S	Rear bumper cover bracket bolts (12 required)
13	17E850	Rear bumper cover bracket

1. For additional information, refer to the procedures in this section.