

BUSSED ELECTRICAL CENTER (BEC) (continued)

Fuse	Amps	Circuits protected
F1	-	Not used
F2	30A	Blower motor relay
F3	40A	High speed engine cooling fan relay, Low speed engine cooling fan relay
F4	30A	Starter relay
F5	30A	Power window motor, left front
F6	30A	Subwoofer amplifier, luggage compartment left inboard, Subwoofer amplifier, luggage compartment right outboard
F7	30A	Power window motor, right front
F8	40A	Anti-lock Brake System (ABS) module
F9	30A	Subwoofer amplifier, luggage compartment right inboard, Subwoofer amplifier, luggage compartment left outboard
F10	30A	Windshield wiper motor
F11	30A	Power window motor, left rear
F12	30A	Power window motor, right rear
F13	40A	Convertible top raise relay, Convertible top lower relay
F14	30A	Seat adjust switch, driver side front, Lumbar adjust switch, left front
F15	30A	Seat adjust switch, passenger side front
F16	30A	Subwoofer amplifier, left front, Subwoofer amplifier, right front
F39	15A	Automatic transmission, Transmission shift selector, Charge air cooler pump relay, Reverse lockout solenoid
F40	15A	Ignition transformer capacitor, Ignition coil
F41	15A	Fuel pump relay, Fuel injectors
F42	15A	Powertrain Control Module (PCM)
F43	10A	Generator

Fuse	Amps	Circuits protected
F44	10A	Smart Junction Box (SJB), Accessory delay relay
F45	10A	Powertrain Control Module (PCM)
F46	25A	Horn relay
F47	15A	A/C clutch relay, EVAP canister vent control solenoid, EGR system module, Heated oxygen sensors (HO2S), Variable valve timing solenoid, Charge Motion Control Valve (CMCV) module, Automatic transmission, EVAP canister purge valve, Mass Air Flow (MAF) sensor, Brake pedal position switch, Heated Positive Crankcase Ventilation (PCV) valve
F49	15A	A/C clutch relay
F50	15A	High beam relay
F51	10A	Convertible top raise relay, Convertible top lower relay
F52	30A	Rear window defrost relay
F54	20A	Headlamp relay, left (HID only)
F55	20A	Headlamp relay, right (HID only)
F56	20A	Audio Control Module (ACM)
F57	20A	Luggage compartment lid release relay
F58	15A	Fog lamp relay
F59	30A	Smart Junction Box (SJB)
F61	20A	Cigar lighter, front
F62	20A	Smart Junction Box (SJB), Driver door unlock relay, Door unlock relay, Door lock relay
F63	30A	Smart Junction Box (SJB)
F64	20A	Power point
F65	30A	Anti-lock Brake System (ABS) module
F66	25A	Auxiliary relay box 1 (5.4L), Heated seat relay box (4.0L, 4.6L)
F67	30A	Smart Junction Box (SJB)
F68	20A	Ignition switch