


REMOVAL AND INSTALLATION

Exterior Mirrors — Exploded View



Item	Part Number	Description
1	17K707	Exterior mirror glass
2	—	Exterior mirror motor screws (3 per side required)
3	17D696	Exterior mirror motor
4	17K709	Sail panel
5	17B676	Exterior mirror control switch

(Continued)

Item	Part Number	Description
6	N621907	Exterior mirror mounting nuts (3 per side required)
7	17682/17683	Exterior mirror (RH/LH)

1. For additional information, refer to the procedures in this section.