## Symptom Chart — Door Lock Control System, Electronic

Use Rotunda Digital Volt-Ohmmeter 014-00407 or Rotunda Dwell-Tach-Volt-Ohms Tester 164-R0254 or equivalent to perform Pinpoint Tests.

**Door Lock Control System, Electronic** 

Condition	Possible Source	Action
Doors Do Not Lock or Unlock Using Keyless Entry Remote Transmitter	<ul><li>Circuitry open/shorted.</li><li>Electronic door lock control processor.</li></ul>	GO to Pinpoint  Test A.
Illuminated Entry Does Not Work From Keyless Entry Remote Transmitter	<ul> <li>Circuitry open/shorted.</li> <li>Keyless entry remote transmitter.</li> <li>Electronic door lock control transmitter.</li> </ul>	GO to <u>Pinpoint</u> <u>Test B</u> .
Anti-Theft System Does Not Arm or Disarm	<ul><li>Circuitry open/shorted.</li><li>Electronic door lock control processor.</li></ul>	GO to Pinpoint     Test C.
Personal Security Alarm Does Not Work From Keyless Entry Remote Transmitter	<ul><li>Circuitry open/shorted.</li><li>Electronic door lock control processor.</li></ul>	GO to <u>Pinpoint</u> <u>Test D</u> .
Courtesy Lamps Do Not Turn Off if Left On	<ul> <li>Circuitry open/shorted.</li> <li>Electronic door lock control processor.</li> <li>Switches.</li> <li>Headlamp switch.</li> </ul>	GO to <u>Pinpoint</u> <u>Test E</u> .
Luggage Compartment Door Will Not Unlock	<ul> <li>Circuitry open/shorted.</li> <li>Electronic door lock control processor.</li> <li>Switch.</li> <li>Luggage compartment door latch.</li> </ul>	GO to <u>Pinpoint</u> <u>Test F</u> .