Step 2: No DTCs Present Symptom Chart Index

	System/Symptom	Oasis Number	Chart Numbe
Driveability			
Starting Concerns	Hard Start/Long Crank/Erratic Start/Erratic Crank	602300	2
	Stall after start	607000	1
	No crank	601300	23
	No start (engine cranks)	603300	3
Unique Idle Concerns	Slow return to idle	617400	4
	Rolling idle	618400	1
	<u>Fast idle</u>	619400	5
	Low/Slow idle	607400	6
Priveability - Performance While I	Driving Concerns		
Stalls/Quits	Idle/Acceleration/Cruise	607x00	1
	Deceleration	607700	6
uns Rough		608x00	1
lisses		609x00	1
<u>uck/Jerk</u>		610x00	1
esitation/Stumble		611x00	1
urge		612x00	1
ackfires		613x00	7
s stall see a f D see as		614x00	8
ack/Loss of Power		615x00	9

Additional Driveability Concerns

Diesels/Runs On	621000	5
Poor Fuel Economy	622000	10
		r

System/Symptom		Oasis Number	Chart Number
Emissions Compliance		623000	11
Electrical			
	Malfunction indicator lamp (MIL)	698298	12
	Transmission control indicator lamp (TCIL)	698298	12
Marriag Indiastora	Power take off (PTO)	507000	12
Warning Indicators	Temperature warning indicator lamp or gauge (applications with CHT sensor only)	206000	12
	Check fuel cap indicator lamp	206000	12
<u> </u>	Electronic throttle control (ETC) indicator lamp	698298	12
Climate Control	Lack of A/C cooling, A/C not functioning	208200	21
	A/C always on or A/C compressor runs continuously	208999	21
	Tachometer inoperative	204000	14
1	Speedometer/odometer inoperative	204000	14
Instrumentation	Boost gauge indicates higher than normal boost (supercharger applications)	204000	14
	Fuel gauge inoperative	204000	14
Engine			
	High oil consumption	401000	15
Oil System Concerns	Leaks	401000	15
	Electric cooling fan(s) does not operate (low, medium, high or variable speed)	402000	16
Cooling System Concerns	Electric cooling fan(s) always runs	402000	17
External System Concerns	Visible smoke	403000	18
Exhaust System Concerns	Odor (sulfur or rotten egg smell)	403000	22
Fuel System Concerns		404000	19
<u>Engine Noise (under hood)</u>		497000	20
Driveline			
	<u>Upshift</u>	501000	13
Automatic Transmission (A/T) Shift Concerns	Downshift	502000	13
	Engagement	503000	13
Power Take Off			<u>.</u>
PTO Concerns		507000	12
	© Copyright 2023, Ford Motor Company.		,