## Light Sensor

	Card	
N0102028		
ltem	Part Number	Description

ltem	Part Number	Description
1	13A018	Light sensor
2	—	Light sensor electrical connector (part of 14401)

## **Removal and Installation**

- Using a suitable tool (such as a pocket screwdriver), remove the light sensor.
  Disconnect the electrical connector.
- 2. To install, reverse the removal procedure.

© Copyright 2024, Ford Motor Company.