


Instrument Cluster (IC) Lens

Removal and Installation

1. Remove the Instrument Cluster (IC) . For additional information, refer to [Instrument Cluster \(IC\)](#) in this section.
2. Release the retaining tabs and remove the IC lens.



3. To install, reverse the removal procedure.