DESCRIPTION AND OPERATION

Anti-Lock Control

Anti-Lock Brake System (ABS) with Traction Control

The anti-lock brake system consists of the following components:

- hydraulic control unit (HCU)
- ABS module
- front wheel speed sensors
- front wheel speed sensors rings

- rear wheel speed sensors
- rear wheel speed sensor rings
- traction control switch
- traction control switch indicator
- trac off indicator
- yellow ABS warning indicator