


## REMOVAL AND INSTALLATION

### Speaker Enclosure



Item	Part Number	Description
1	W505433	Speaker enclosure bolts (3 required)
2	W705047	Speaker enclosure nut
3	14N128	Speaker enclosure electrical connectors
4	19A067	Speaker enclosure
5	W505416	L-bracket screws (2 required)
6	19B187	L-bracket

#### Removal and Installation

- Remove the 3 speaker enclosure bolts.
  - To install, tighten to 11 Nm (8 lb-ft).
- Remove the nut and the speaker enclosure.
  - To install, tighten to 11 Nm (8 lb-ft).
  - Disconnect the electrical connectors.
- To install, reverse the removal procedure.