
C117
Coil On Plug
(COP) 7
C1186
Fuel injector 6
C116
Coil On Plug
(COP) 6
C1185
Fuel injector 5
C115
Coil On Plug
(COP) 5
C1312
Fuel injector 7
12B637
C118
Coil On Plug
(COP) 8
S108
C1313
Fuel injector 8
S109
C134
S106
S119
C1035b
Bussed Electrical
Center (BEC)
C191
Intake Manifold
Runner Control
(IMRC) module
S101
S107
12A690
C107
Cylinder head
temperature
sensor
C197B
Starter motor
C100
A/C clutch field
coil
C108
Knock sensor
C101
Crankshaft position
sensor
front of vehicle