
C277
Deactivator
switch
(7C534)
C257
Clutch pedal
position switch
(9C872)
C278
Brake pedal posi-
tion switch (13480)
C215
Auxiliary relay box 1
C2993b
C2993a
Subwoofer amplifier,
left front channel
(18B849)
C214
S216
S217
G204
C282
Inertia Fuel
Shutoff (IFS)
switch (9341)
14A005
C2040
Accelerator pedal
position sensor
C2314
Stoplamp switch 1
S212
C3209
Side impact
sensor, driver 1
(14B345)
C311
C367
Side air bag module, left
C3108
Resistor cap 2
C211
S215
front of vehicle

LH A–pillar